JVC

SERVICE MANUAL

DIGITAL VIDEO CAMERA

GR-DVL220U,DVL320U,DVL520U, DVL522U,DVL720U



Mini DV NTSC

DSC DIGITAL STILL CAMERA

SPECIFICATIONS *(The specifications shown pertain specifically to the model GR-DVL320/DVL520/DVL720)*

Camcorder

General

Power supply : DC 11.0 V ⎓ (Using AC Adapter)
DC 7.2 V ⎓ (Using battery pack)

Power consumption
LCD monitor off, viewfinder on : Approx. 4.3 W
LCD monitor on, viewfinder off : Approx. 5.3 W

Video light : Approx. 3.5 W

Dimensions (W x H x D) : 79 mm x 89 mm x 167 mm (3-1/8" x 3-9/16" x 6-5/8") (with the LCD monitor closed and the viewfinder pushed down)

Weight : Approx. 570 g (1.3 lbs) (GR-DVL720)
Approx. 560 g (1.3 lbs) (GR-DVL520)
Approx. 550 g (1.3 lbs) (GR-DVL320)

Operating temperature : 0°C to 40°C (32°F to 104°F)

Operating humidity : 35% to 80%

Storage temperature : –20°C to 50°C (–4°F to 122°F)

Pickup : 1/4" CCD

Lens : F 1.8, f = 3.8 mm to 38 mm, 10:1 power zoom lens

Filter diameter : ø37 mm

LCD monitor : 3.5" diagonally measured, LCD panel/TFT active matrix system (GR-DVL720)
2.5" diagonally measured, LCD panel/TFT active matrix system (GR-DVL520/DVL320)

Viewfinder : Electronic viewfinder with 0.24" black/white LCD

Speaker : Monaural

Digital Video Camera

Format : DV format (SD mode)

Signal format : NTSC standard

Recording/Playback format : Video: Digital component recording
: Audio: PCM digital recording, 32 kHz 4-channel (12-bit), 48 kHz 2-channel (16-bit)

Cassette : Mini DV cassette

Tape speed : SP: 18.8 mm/s
LP: 12.5 mm/s

Maximum recording time (using 80 min. cassette) : SP: 80 min.
LP: 120 min.

Digital Still Camera Function (GR-DVL720/DVL520 only)

Storage media : SD Memory Card/MultiMediaCard

Compression system : JPEG (compatible)

File size : 2 modes (1024 x 768 pixels, 640 x 480 pixels)

Picture quality : 2 modes (FINE/STANDARD)

Approximate number of storable images with memory card [8 MB] (provided)
FINE : 20 (1024 x 768 pixels), 45 (640 x 480 pixels)
STANDARD : 65 (1024 x 768 pixels), 160 (640 x 480 pixels)

For other memory cards, ☞ g. 27.

Connectors

S-Video
Output : Y:1 V (p-p), 75 Ω, analog
C:0.29 V (p-p), 75 Ω, analog

AV
Video output : 1 V (p-p), 75 Ω, analog
Audio output : 300 mV (rms), 1 k, analog, stereo

DV
Output : 4-pin, IEEE 1394 compliant
Input : 4-pin, IEEE 1394 compliant

USB (GR-DVL720/DVL520 only) : 5-pin

PC (GR-DVL320 only) : ø2.5 mm, 3-pole

EDIT (GR-DVL720/DVL520 only) : ø3.5 mm, 2-pole

JLIP (GR-DVL320 only) : ø3.5 mm, 4-pole

AC Adapter

Power requirement
U.S.A. and Canada : AC 120 V ∿, 60 Hz
Other countries : AC 110 V to 240 V ∿, 50 Hz/60 Hz

Output : DC 11 V ⎓, 1 A

Specifications shown are for SP mode unless otherwise indicated. E & O.E.
Design and specifications subject to change without notice.

This service manual is printed on 100% recycled paper.
COPYRIGHT © 2001 VICTOR COMPANY OF JAPAN, LTD.

No. 86658
December 2001

TABLE OF CONTENTS

Section	Title	Page
	Important Safety Precautions	
	INSTRUCTIONS	
	1. DISASSEMBLY	
1.1	BEFORE ASSEMBLY AND DISASSEMBLY	1-1
1.1.1	Precautions	1-1
1.1.2	Assembly and disassembly	1-1
1.1.3	Destination of connectors	1-1
1.1.4	Disconnection of Connectors (Wires)	1-1
1.2	JIGS AND TOOLS REQUIRED FOR DISASSEMBLY, ASSEMBLY AND ADJUSTMENT	1-2
1.2.1	Tools required for adjustments	1-2
1.3	DISASSEMBLY/ASSEMBLY OF CABINET PARTS AND BOARD ASSEMBLY	1-2
1.3.1	Disassembly flow chart	1-2
1.3.2	Disassembly method	1-3
1.4	④ MONITOR ASSEMBLY	1-7
1.4.1	Disassembly/assembly of monitor assembly (for 2.5"-type LCD)	1-7
1.4.2	Disassembly/assembly of hinge assembly (for 2.5"-type LCD)	1-7
1.4.3	Disassembly/assembly of monitor assembly (for 3.5"-type LCD)	1-8
1.4.4	Disassembly/assembly of hinge assembly (for 3.5"-type LCD)	1-8
1.5	⑤ E. VF ASSEMBLY	1-9
1.5.1	Disassembly/assembly of E.VF assembly (for the B/W VF)	1-9
1.6	DISASSEMBLY/ASSEMBLY OF ⑩ OP BLOCK ASSEMBLY/CCD BOARD ASSEMBLY	1-10
1.6.1	Precautions	1-10
1.6.2	How to remove CCD board assembly and CCD base assembly	1-10
1.6.3	How to assemble CCD base assembly and CCD board assembly	1-10
1.6.4	Replacement of service repair parts	1-10
1.7	EMERGENCY DISPLAY	1-11
1.8	SERVICE NOTE	1-12
	2. MECHANISM ADJUSTMENT	
2.1	PRELIMINARY REMARKS ON ADJUSTMENT AND REPAIR	2-1
2.1.1	Precautions	2-1
2.1.2	Notes on procedure for disassemby/assembly	2-1
2.2	JIGS AND TOOLS REQUIRED FOR DISASSEMBLY, ASSEMBLY AND ADJUSTMENT	2-2
2.2.1	Tools required for adjustments	2-2
2.3	DISASSEMBLY/ASSEMBLY OF MECHANISM ASSEMBLY	2-3
2.3.1	General statement	2-3
2.3.2	Explanation of mechanism mode	2-3
2.3.3	Mechanism timing chart	2-4
2.4	DISASSEMBLY/ASSEMBLY OF MECHANISM ASSEMBLY	2-5
2.4.1	Follow chart	2-5
2.4.2	Disassembly/assembly	2-8
2.4.3	List of procedures for disassembly	2-14
2.5	CHECKUP AND ADJUSTMENT OF MECHANISM PHASE	2-15
2.6	MECHANISM ADJUSTMENTS	2-16
2.6.1	Assembling slide deck assembly and main deck assembly	2-16
2.6.2	Locating tension pole	2-17
2.7	SERVICE NOTE	2-18
2.8	JIG CONNECTOR CABLE CONNECTION	2-20
	3. ELECTRICAL ADJUSTMENT	
3.1	Precaution	3-1
3.2	SETUP	3-2
	4. CHARTS AND DIAGRAMS	
	NOTES OF SCHEMATIC DIAGRAM	4-1
	CIRCUIT BOARD NOTES	4-2
4.1	BOARD INTERCONNECTIONS	4-3
4.2	MAIN IF SCHEMATIC DIAGRAM	4-5
4.3	SYSCON SCHEMATIC DIAGRAM	4-7
4.4	PC IF SCHEMATIC DIAGRAM	4-8
4.5	DECKCPU SCHEMATIC DIAGRAM	4-11
4.6	MDA SCHEMATIC DIAGRAM	4-13
4.7	AUDIO SCHEMATIC DIAGRAM	4-15
4.8	DVMAIN SCHEMATIC DIAGRAM	4-17
4.9	PRE/REC SCHEMATIC DIAGRAM	4-10
4.10	V OUT SCHEMATIC DIAGRAM	4-21
4.11	CAM.DSP SCHEMATIC DIAGRAM	4-23
4.12	OP DRV SCHEMATIC DIAGRAM	4-25
4.13	TG SCHEMATIC DIAGRAM	4-27
4.14	REG SCHEMATIC DIAGRAM	4-29
4.15	MONITOR SCHEMATIC DIAGRAM	4-31
4.16	LCD BL SCHEMATIC DIAGRAM	4-33
4.17	CCD SCHEMATIC DIAGRAM	4-35
4.18	JUNCTION SCHEMATIC DIAGRAM	4-36
4.19	JACK SCHEMATIC DIAGRAM	4-37
4.20	REAR SCHEMATIC DIAGRAM	4-38
4.21	B/W VF SCHEMATIC DIAGRAM	4-39
4.22	DSC SCHEMATIC DIAGRAM [DVL520/DVL522/DVL720]	4-41
4.23	MAIN CIRCUIT BOARD [DVL220/DVL320/DVL520]	4-43
4.24	MAIN CIRCUIT BOARD [DVL522/DVL720]	4-49
4.25	MONITOR CIRCUIT BOARD	4-55
4.26	LCD BL CIRCUIT BOARD	4-57
4.27	CCD AND JUNCTION CIRCUIT BOARDS	4-59
4.28	JACK AND VF CIRCUIT BOARDS	4-61
4.29	REAR CIRCUIT BOARD	4-63
4.30	DSC CIRCUIT BOARD [DVL520/DVL522/DVL720]	4-65
4.31	VOLTAGE CHARTS	4-67
4.32	POWER SYSTEM BLOCK DIAGRAM	4-71
4.33	VIDEO SYSTEM BLOCK DIAGRAM	4-73
4.34	REGULATOR SYSTEM BLOCK DIAGRAM	4-77
	5. PARTS LIST	
5.1	PACKING AND ACCESSORY ASSEMBLY <M1>	5-1
5.2	FINAL ASSEMBLY <M2>	5-3
5.3	MECHANISM ASSEMBLY <M3>	5-6
5.4	ELECTRONIC VIEWFINDER ASSEMBLY <M4>	5-8
5.5	MONITOR ASSEMBLY <M5> [GR-DVL220U, 320U, 520U, 522U]	5-9
5.5	MONITOR ASSEMBLY <M5> [GR-DVL720U]	5-10
5.6	ELECTRICAL PARTS LIST	5-11
	MAIN BOARD ASSEMBLY <01>	5-11
	MONITOR BOARD ASSEMBLY <02>	5-19
	LCD BL BOARD ASSEMBLY <03>	5-20
	CCD BOARD ASSEMBLY <04>	5-20
	JUNCTION BOARD ASSEMBLY <05>	5-20
	JACK BOARD ASSEMBLY <06>	5-20
	REAR BOARD ASSEMBLY <07>	5-21
	B/W VF BOARD ASSEMBLY <08>	5-21
	DSC BOARD ASSEMBLY <10> (E,F,G)	5-21

The following table lists the differing points between Models GR-DVL220U,GR-DVL320U, GR-DVL520U,GR-DVL522U and GR-DVL720U in this serise.

	GR-DVL220U	GR-DVL320U	GR-DVL520U	GR-DVL522U	GR-DVL720U
LCD MONITOR	2.5"	2.5"	2.5"	2.5"	3.5"
VIDEO LIGHT	NOT USED	USED	USED	USED	USED
DIGITAL STILL CAMERA	NOT USED	NOT USED	USED	USED	USED
MEMORY CARD	NOT USED	NOT USED	USED	USED	USED
EDITING CABLE	NOT USED	NOT USED	NOT USED	USED	USED
RCU UNIT	RM-V715U	RM-V715U	RM-V715U	RM-V717U	RM-V717U

Important Safety Precautions

Prior to shipment from the factory, JVC products are strictly inspected to conform with the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

● Precautions during Servicing

1. Locations requiring special caution are denoted by labels and inscriptions on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.

2. Parts identified by the ⚠ symbol and shaded ( ) parts are critical for safety.
   Replace only with specified part numbers.
   Note: Parts in this category also include those specified to comply with X-ray emission standards for products using cathode ray tubes and those specified for compliance with various regulations regarding spurious radiation emission.

3. Fuse replacement caution notice.
   Caution for continued protection against fire hazard.
   Replace only with same type and rated fuse(s) as specified.

4. Use specified internal wiring. Note especially:
   1) Wires covered with PVC tubing
   2) Double insulated wires
   3) High voltage leads

5. Use specified insulating materials for hazardous live parts. Note especially:
   1) Insulation Tape 3) Spacers 5) Barrier
   2) PVC tubing 4) Insulation sheets for transistors

6. When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.) wrap ends of wires securely about the terminals before soldering.



Fig.1

7. Observe that wires do not contact heat producing parts (heatsinks, oxide metal film resistors, fusible resistors, etc.)

8. Check that replaced wires do not contact sharp edged or pointed parts.

9. When a power cord has been replaced, check that 10-15 kg of force in any direction will not loosen it.



Fig.2

10. Also check areas surrounding repaired locations.

11. Products using cathode ray tubes (CRTs)
    In regard to such products, the cathode ray tubes themselves, the high voltage circuits, and related circuits are specified for compliance with recognized codes pertaining to X-ray emission.
    Consequently, when servicing these products, replace the cathode ray tubes and other parts with only the specified parts. Under no circumstances attempt to modify these circuits.
    Unauthorized modification can increase the high voltage value and cause X-ray emission from the cathode ray tube.

12. Crimp type wire connector
    In such cases as when replacing the power transformer in sets where the connections between the power cord and power transformer primary lead wires are performed using crimp type connectors, if replacing the connectors is unavoidable, in order to prevent safety hazards, perform carefully and precisely according to the following steps.

    1) Connector part number : E03830-001
    2) Required tool : Connector crimping tool of the proper type which will not damage insulated parts.
    3) Replacement procedure
    (1) Remove the old connector by cutting the wires at a point close to the connector.
    Important : Do not reuse a connector (discard it).



Fig.3

(2) Strip about 15 mm of the insulation from the ends of the wires. If the wires are stranded, twist the strands to avoid frayed conductors.



Fig.4

(3) Align the lengths of the wires to be connected. Insert the wires fully into the connector.



Fig.5

(4) As shown in Fig.6, use the crimping tool to crimp the metal sleeve at the center position. Be sure to crimp fully to the complete closure of the tool.



Fig.6

(5) Check the four points noted in Fig.7.


Not easily pulled free
Crimped at approx. center of metal sleeve
Conductors extended
Wire insulation recessed more than 4 mm

Fig.7

● Safety Check after Servicing

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts and wires have been returned to original positions, Afterwards, perform the following tests and confirm the specified values in order to verify compliance with safety standards.

1. Insulation resistance test

Confirm the specified insulation resistance or greater between power cord plug prongs and externally exposed parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table 1 below.

2. Dielectric strength test

Confirm specified dielectric strength or greater between power cord plug prongs and exposed accessible parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table 1 below.

3. Clearance distance

When replacing primary circuit components, confirm specified clearance distance (d), (d') between soldered terminals, and between terminals and surrounding metallic parts. See table 1 below.



Fig. 8

4. Leakage current test

Confirm specified or lower leakage current between earth ground/power cord plug prongs and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).

Measuring Method : (Power ON)

Insert load Z between earth ground/power cord plug prongs and externally exposed accessible parts. Use an AC voltmeter to measure across both terminals of load Z. See figure 9 and following table 2.



Fig. 9

5. Grounding (Class 1 model only)

Confirm specified or lower grounding impedance between earth pin in AC inlet and externally exposed accessible parts (Video in, Video out, Audio in, Audio out or Fixing screw etc.).

Measuring Method:

Connect milli ohm meter between earth pin in AC inlet and exposed accessible parts. See figure 10 and grounding specifications.



Fig. 10

Grounding Specifications

Region	Grounding Impedance (Z)
USA & Canada	Z ≦ 0.1 ohm
Europe & Australia	Z ≦ 0.5 ohm

AC Line Voltage	Region	Insulation Resistance (R)	Dielectric Strength	Clearance Distance (d), (d')
100 V	Japan	R ≧ 1 MΩ/500 V DC	AC 1 kV 1 minute	d, d' ≧ 3 mm
100 to 240 V			AC 1.5 kV 1 miute	d, d' ≧ 4 mm
110 to 130 V	USA & Canada	1 MΩ ≦ R ≦ 12 MΩ/500 V DC	AC 1 kV 1 minute	d, d' ≧ 3.2 mm
110 to 130 V 200 to 240 V	Europe & Australia	R ≧ 10 MΩ/500 V DC	AC 3 kV 1 minute (Class Ⅱ) AC 1.5 kV 1 minute (Class Ⅰ)	d ≧ 4 mm d' ≧ 8 mm (Power cord) d' ≧ 6 mm (Primary wire)

Table 1 Specifications for each region

AC Line Voltage	Region	Load Z	Leakage Current (i)	a, b, c
100 V	Japan	1 kΩ	i ≦ 1 mA rms	Exposed accessible parts
110 to 130 V	USA & Canada	0.15 μF, 1.5 kΩ	i ≦ 0.5 mA rms	Exposed accessible parts
110 to 130 V 220 to 240 V	Europe & Australia	2 kΩ	i ≦ 0.7 mA peak i ≦ 2 mA dc	Antenna earth terminals
		50 kΩ	i ≦ 0.7 mA peak i ≦ 2 mA dc	Other terminals

Table 2 Leakage current specifications for each region

Note: These tables are unofficial and for reference only. Be sure to confirm the precise values for your particular country and locality.

SECTION 1
DISASSEMBLY

1.1 BEFORE ASSEMBLY AND DISASSEMBLY

1.1.1 Precautions

1. Be sure to remove the power supply unit prior to mounting and soldering of parts.
2. When removing a component part that needs to disconnect the connector and to remove the screw for removing itself, first disconnect the connecting wire from the connector and then remove the screw beforehand.
3. When connecting and disconnecting the connectors, be careful not to damage the wire.
4. Carefully remove and handle the part to which some spacer or shield is attached for reinforcement or insulation.
5. When replacing chip parts (especially IC parts), desolder completely first (to prevent peeling of the pattern).
6. Tighten screws properly during the procedures.
   Unless specified otherwise, tighten screws at a torque of 0.088N•m(0.9kgf•cm).

1.1.2 Assembly and disassembly

STEP No.	PART	Fig.No.	POINT	NOTE
① / ②	UPPER CASE ASSY (Inc. MONITOR ASSY / E.VF ASSY)	Fig. 1-3-1	5(S①a), 4(S①b), 3(S①c), CN①	–
	DSC BOARD ASSY		(S②), CN②a, CN②b	–
③	COVER (HINGE)	Fig. 1-3-2	2(S③)	–

(1) (2) (3) (4) (5)

(1) Indicate the disassembly steps. When assembling, perform in the reverse order of these steps. This number corresponds to the number in the disassembly diagram.

(2) Indicates the name of disassembly/assembly parts.

(3) Indicates the number in the disassembly diagram.

(4) Indicates parts and points such as screws, washers, springs which must be removed during disassembly/assembly.

Symbol	Name, Point
S	Screw
L	Lock, Pawl, Hook
SD	Soldering

(Example)
- 2 (S①) : Remove the two screws (S①) for removing the part 1.
- CN① : Disconnect the connector①.
- SD① : Unsolder at the point SD①.

(5) Precautions on disassembly/assembly.

1.1.3 Destination of connectors

Note: *Three kinds of double-arrows in connection tables respectively show kinds of connector/wires.*
↔ : Wire
⇔ : Flat wire
⬌ : Board to Board connector

[Example]

CONN. No.	CONNECTOR					Pin No.
CN①	MAIN	CN101	⇔	MONITOR	CN761	40

1.1.4 Disconnection of Connectors (Wires)

Connector
Pull both ends of the connector in the arrow direction, remove the lock and disconnect the flat wire.



Fig. 1-1-1 Connector 1

Extend the locks in the direction of the arrow for unlocking and then pull out the wire. After removing the wire, immediately restore the locks to their original positions because the locks are apt to come off the connector.



Fig. 1-1-2 Connector 2

B-B connector
Pull the board by both the sides in the direction of the arrow for disconnecting the B-B connector.



Fig. 1-1-3 Connector 3



Fig. 1-1-4 Connector 4

1.2 JIGS AND TOOLS REQUIRED FOR DISASSEMBLY, ASSEMBLY AND ADJUSTMENT

1.2.1 Tools required for adjustments

1 Torque Driver YTU94088	2 Bit YTU94088-003
	
3 Tweezers P-895	4 Chip IC Replacement Jig PTS40844-2
	
5 Cleaning Cloth KSMM-01	
	

Table 1-2-1

1. **Torque driver**
   Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.
2. **Bit**
   This bit is slightly longer than those set in conventional torque drivers.
3. **Tweezers**
   To be used for removing and installing parts and wires.
4. **Chip IC replacement jig**
   To be used for adjustment of the camera system.
5. **Cleaning cloth**
   Recommended cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

1.3 DISASSEMBLY/ASSEMBLY OF CABINET PARTS AND BOARD ASSEMBLY

1.3.1 Disassembly flow chart

This flowchart indicates the disassembly step for the cabinet parts and board assembly in order to gain access to item(s) to be serviced. When reassembling, perform the step(s) in reverse order.


① / ② UPPER CASE ASSY (Inc. MONITOR ASSY / E.VF ASSY) / DSC BOARD ASSY
③ COVER (HINGE)
④ MONITOR ASSY
⑤ E.VF ASSY
⑥ MONITOR BOARD ASSY
⑦ / ⑧ / ⑨ FRONT ASSY (Inc. DC LIGHT, MIC) / DC LIGHT / LIGHT COVER / MIC
⑩ OP BLOCK ASSY
⑪ REAR UNIT ASSY
⑫ LOWER CASE ASSY
⑬ JUNCTION BOARD ASSY
⑭ MAIN BOARD ASSY
⑮ / ⑯ JACK BOARD ASSY / MECHANISM ASSY

Table 1-3-1

1.3.2 Disassembly method

STEP No.	PART	Fig.No.	POINT	NOTE
① / ②	UPPER CASE ASSY (Inc. MONITOR ASSY / E.VF ASSY)	Fig. 1-3-1	6(S①a), 4(S①b), 3(S①c), CN①	–
	DSC BOARD ASSY		(S②), CN②a, CN②b	–
③	COVER (HINGE)	Fig. 1-3-2	2(S③)	–
④	MONITOR ASSY	Fig. 1-3-3	CN④, 2(S④)	–
⑤	E.VF ASSY	Fig. 1-3-4	CN⑤, 2(S⑤)	–
⑥	MONITOR BOARD ASSY	Fig. 1-3-5	CN⑥, 5(S⑥a), (S⑥b), 4(S⑥c), BRACKET (MONITOR), SPEAKER	NOTE⑥
⑦ / ⑧ / ⑨	FRONT ASSY (Inc. DC LIGHT,MIC)	Fig. 1-3-6	COVER (JACK), CN⑦, 2(S⑦), (L⑦a), (L⑦b)	NOTE⑦
	DC LIGHT / LIGHT COVER		2(L⑧c)	
	MIC		(S⑨)	
⑩	OP BLOCK ASSY	Fig. 1-3-7	CN⑩a, CN⑩b, (S⑩a), (S⑩b)	NOTE⑩
⑪	REAR UNIT ASSY	Fig. 1-3-8	CN⑪a, CN⑪b, COVER(DC), 3(S⑪)	NOTE⑪
⑫	LOWER CASE ASSY	Fig. 1-3-9	CN⑫, 2(S⑫a), 3(S⑫b)	–
⑬	JUNCTION BOARD ASSY	Fig. 1-3-10	(S⑬a), (S⑬b), CN⑬a, CN⑬b, CN⑬c, CN⑬d	NOTE⑬a NOTE⑬b
⑭	MAIN BOARD ASSY	Fig. 1-3-11	(S⑭a), (L⑭a), SHIELD PLATE, CN⑭a, CN⑭b, CN⑭c, 2(S⑭b)	–
⑮ / ⑯	JACK BOARD ASSY	Fig. 1-3-12	2(S⑮a), CN⑮a	–
	MECHANISM ASSY		2(S⑯a), (S⑯b)	

Table 1-3-2

Note: *Remove the parts marked in .*

CONN. No.	CONNECTOR					Pin No.
CN①	MAIN	CN101	⇔	MONITOR	CN761	40
CN②a	DSC	CN8002	⇔	MONITOR	CN762	10
CN②b	DSC	CN8001	⬌	MAIN	CN111	80
CN④	MONITOR	CN764	⇔	LCD BL	CN751	33/32
CN⑤	MONITOR	CN763	⇔	E.VF ASSY	CN721	20
CN⑥	MONITOR	CN765	⇔	SPEAKER	—	2
CN⑦	MAIN	CN106	⇔	MIC		3
			⇔	DC LIGHT		2
CN⑩a	MAIN	CN108	⇔	OP BLOCK ASSY	—	24
CN⑩b	MAIN	CN107	⇔	CCD	—	20
CN⑪a	MAIN	CN103	⇔	REAR UNIT	CN551	12
CN⑪b	MAIN	CN104	⇔	REAR UNIT	CN552	6
CN⑫	MAIN	CN109	⇔	ZOOM UNIT	—	15
CN⑬a	JUNCTION	CN571	⇔	MAIN	CN113	33
CN⑬b	JUNCTION	CN574	⇔	LOADING MOTOR	—	6
CN⑬c	JUNCTION	CN573	⇔	DRUM MOTOR	—	11
CN⑬d	JUNCTION	CN572	⇔	SENSOR	—	15
CN⑭a	MAIN	CN110	⇔	HEAD	—	8
CN⑭b	MAIN	CN112	⇔	CAPSTAN MOTOR	—	18
CN⑭c	MAIN	CN102	⇔	JACK	CN502	24
CN⑮a	JACK	CN501	⇔	ROTARY ENCODER	—	6

Table 1-3-3

NOTE⑥ : *Be careful not to lose any parts.*

NOTE⑦ : *As screw No.31 is hidden behind the COVER (JACK), open the COVER (JACK) to enable removal of the screw.*

NOTE⑩ : *Remove the connector.*

NOTE⑪ : *Open the COVER (DC).*

NOTE⑬a : *As the CN572 is located at the back of the assembly, unplug the three connectors and remove the screws bofore disconnecting the CN572.*

NOTE⑬b : *Be coreful not to damage any of the switches.*



Fig. 1-3-1



Fig. 1-3-2



Fig. 1-3-4



Fig. 1-3-3



Fig. 1-3-5



Fig. 1-3-6



Fig. 1-3-7



Fig. 1-3-8



Fig. 1-3-9



Fig. 1-3-11



Fig. 1-3-10



Fig. 1-3-12

1.4 ④ MONITOR ASSEMBLY

Note: *The shape of the monitor assembly varies by the size of the LCD screen.*

For the 2.5"-type LCD, refer to Fig. 1-4-1.

1.4.1 Disassembly/assembly of monitor assembly (for 2.5"-type LCD)

Note: *Be careful not to soil or scratch the monitor screen through the disassembly/assembly work.*

1. Remove the four screws 1 to 4 in numerical order. While disengaging the six hooks (L④a to L④f) in alphabetical order, remove the monitor cover assembly.
2. Unlock the connector ⓐ and then disconnect the FPC while lifting the hinge assembly upwards to remove it together with the FPC.

Note④a: *For disconnecting the FPC, unlock the connector first and then lift the hinge assembly upwards. Accordingly, the FPC is disconnected together with the hinge assembly.*

Note④b: *Treat the wires carefully.*

3. Unplug the wires and FPCs from the two connectors ⓑ, ⓒ, and then remove the MONITOR BL board assembly, holder (PWB) and backlight in that order.
4. Remove the LCD module.

1.4.2 Disassembly/assembly of hinge assembly (for 2.5"-type LCD)

1. Remove the three screws (5 to 7), and then remove the hinge covers (1) and (2) by disengaging a total of four hooks (L④g, L④h) at the two sides.
2. Separate the SW board assembly and the FPC from the hinge assembly.

Note④c: *When connecting the FPC, arrange the FPC wire by winding it around the shaft (hinge pin) of the hinge assembly by two and a half turns while paying heed to the orientation of the hinge assembly and FPC.*

Note④d: *When disassembling/assembling the hinge assembly, pay careful attention to every part not to damage anything.*



Fig. 1-4-1

Note: *The shape of the monitor assembly varies by the size of the LCD screen.*

For the 3.5”-type LCD, refer to Fig. 1-4-2.

1.4.3 Disassembly/assembly of monitor assembly (for 3.5”-type LCD)

Note: *Be careful not to soil or scratch the monitor screen through the disassembly/assembly work.*

1. Remove the four screws 1 to 4 in numerical order. While disengaging the six hooks (L④a to L④f) in alphabetical order, remove the monitor cover assembly.

Note④e: *When removing the monitor cover assembly, be careful not to damage the FPC and connector.*

2. Unlock the connector ⓐ and then disconnect the FPC while lifting the hinge assembly upwards to remove it together with the FPC.

Note④f: *For disconnecting the FPC, unlock the connector first and then lift the hinge assembly upwards. Accordingly, the FPC is disconnected together with the hinge assembly.*

Note④g: *Treat the wires carefully.*

3. Unplug the wires and FPCs from the two connectors ⓑ, ⓒ, and then remove the MONITOR BL board assembly, holder (PWB) and backlight in that order.
4. Remove the LCD module while disengaging it from the four hooks (L④g, L④h, L④j, L④k,).

1.4.4 Disassembly/assembly of hinge assembly (for 3.5”-type LCD)

1. Remove the three screws (5 to 7), and then remove the hinge covers (1) and (2) by disengaging a total of four hooks (L④m, L④n) at the two sides.
2. Separate the SW board assembly and the FPC from the hinge assembly.

Note④h: *When disassembling/assembling the hinge assembly, pay careful attention to every part not to damage anything.*

Note④j: *When connecting the FPC, arrange the FPC wire by winding it around the shaft (hinge pin) of the hinge assembly by two and a half turns while paying heed to the orientation of the hinge assembly and FPC.*



Fig. 1-4-2

1.5 ⑤ E. VF ASSEMBLY

1.5.1 Disassembly/assembly of E.VF assembly (for the B/W VF)

1. Remove the EYE CUP.
2. Remove the three screws (1 to 3) and then remove the CASE B (VF).
3. Remove the screw (4) to remove the LEVER (VF) and pull out the LENS ASSY.

Note⑤a: *Be careful not to lose the SPRING (VF).*

4. Remove the three screws (5 to 7) and then remove the VF HINGE ASSY.

Note⑤b: *Be careful not to damage the FPC and not to break any wires during the operation.*

5. Remove the screw (8) and the remove the CAP (VF).
6. Remove the FPC from the CASE A (VF) so that the CASE A (VF) may be unlocked.
7. Remove the HOLDER LCD (VF) while unlocking it by the both side.



Fig. 1-5-1

1.6 DISASSEMBLY/ASSEMBLY OF ⑩ OP BLOCK ASSEMBLY/CCD BOARD ASSEMBLY

1.6.1 Precautions

1. Take care in handling the CCD image sensor, optical LPF and lens components when performing maintenance etc., especially with regard to surface contamination, attached dust or scratching. If fingerprints are present on the surface they should be wiped away using either a silicon paper, clean chamois or the cleaning cloth.
2. The CCD image sensor may have been shipped with a protective sheet attached to the transmitting glass. When replacing the CCD image sensor, do not peel off this sheet from the new part until immediately before it is mounted in the OP Block Assembly.
3. The orientation of the optical LPF is an important factor for installation. If there is some marking on the LPF, be sure to note it down before removing and to reassemble it very carefully as it was referring to the marking.

1.6.2 How to remove CCD board assembly and CCD base assembly

1. Unsolder the CCD board assembly by the 14 points (SD⑩) and then remove it.
2. Remove the two screws (1, 2) and remove the CCD base assembly.

Note⑩a: *When removing the CCD base assembly, pay heed to the CCD image sensor because the spacer rubber and optical LPF are occasionally removed together with the CCD image sensor.*

Note ⑩b: *When replacing the CCD image sensor, don't replace it individually but replace the CCD base assembly in whole with a new one.*

1.6.3 How to assemble CCD base assembly and CCD board assembly

1. Install the optical LPF with the spacer rubber attached to its CCD side in the OP block assembly.

Note⑩c: *Pay careful attention to the orientation of the LPF.*

2. Set the CCD base assembly with careful attention to the spacer rubber not to come off the right position, and fasten them together with the two screws (1, 2).
3. Set the CCD board assembly in the CCD base assembly, and then solder it by the 14 points (SD⑩).

1.6.4 Replacement of service repair parts

The service repair parts for the OP Block Assembly are as listed below.

Before replacement of these parts, remove the bracket (OP assembly) as required.

Take special care not to disconnect any of the FPC wires or cause any damage due to soldering (excessive heating).

1. Focusing motor
2. Zoom motor
3. Iris motor unit

Note⑩d: *When replacing the focusing motor or the zoom motor, solder the FPC at a space of about 1 mm above the terminal pin.*

Note⑩e: *The iris motor unit includes the FPC Assembly and two sensors.*



Fig. 1-6-1

1.7 EMERGENCY DISPLAY

Whenever some abnormal signal is input to the syscon CPU, an error number (E01, as an example) is displayed on the LCD monitor or (in the electronic view finder).
In every error status, such the message as shown below alternately appear over and over.

- In an emergency mode, all operations except turning on/off the POWER switch are ineffectual.

Example (in case of the error number E01):



LCD display	Emergency mode	Details	Possible cause
E01	LOADING	In the case the encoder position is not shifted to the next point though the loading motor has rotated in the loading direction for 4 seconds or more. This error is defined as [E01].	1. The mechanism is locked during mode shift. 2. The mechanism is locked at the mechanism loading end, because the encoder position is skipped during mechanism mode shift. 3. No power is supplied to the loading MDA.
E02	UNLOADING	In the case the encoder position is not shifted to the next point though the loading motor has rotated in the unloading direction for 4 seconds or more. This error is defined as [E02].	1. The mechanism is locked during mode shift. 2. The mechanism is locked at the mechanism loading end, because the encoder position is skipped during mechanism mode shift.
E03	TU & SUP REEL FG	In the case no REEL FG is produced for 4 seconds or more in the capstan rotation mode after loading was complete, the mechanism mode is shifted to STOP with the pinch roller set off. This error is defined as [E03]. However, no REEL EMG is detected in the SLOW/STILL mode.	1. The idler gear does not engage with the reel disk well. 2. Though the idler gear and reel disk are engaged with each other, the tape is not wound because of overload to the mechanism. 3. No FG pulse is output from the reel sensor. 4. No power is supplied to the reel sensor. 5. Tape transport operation takes place with a cassette having no tape inside. 6. The tape slackens and no pulse is produced until the slack is taken up and the tape comes into the normal status.
E04	DRUM FG	In the case there is no DRUM FG input in the drum rotation mode for 4 seconds or more. This error is defined as [E04], and the mechanism mode is shifted to STOP with the pinch roller set off.	1. The drum cannot be started or drum rotation is stopped because tape transport load is too high. 1) Tape tension is extremely high. 2) The tape is damaged or soiled with grease, etc. 2. The DRUM FG signal is not received by the syscon CPU. 1) Disconnection in the middle of the signal line. 2) Failure of the DRUM FG pulse generator (hall element). 3. No drum control voltage is supplied to the MDA. 4. No power is supplied to the DRUM MDA.
E05	–	–	–
E06	CAPSTAN FG	In the case no CAPSTAN FG is produced in the capstan rotation mode for 2 seconds or more. This error is defined as [E06], and the mechanism mode is shifted to STOP with the pinch roller set off. However, no CAPSTAN EMG is detected in the STILL/FF/REW mode.	1. The CAPSTAN FG signal is not received by the syscon CPU. 1) Disconnection in the middle of the signal line. 2) Failure of the CAPSTAN FG pulse generator (MR element). 2. No capstan control voltage is supplied to the MDA. 3. No power is supplied to the CAPSTAN MDA. 4. The capstan cannot be started or capstan rotation is stopped because tape transport load is too high. 1) Tape tension is extremely high. (Mechanical locking) 2) The tape is damaged or soiled with grease, etc. (Tape tangling occurs, etc.)

(DVC_03)

Table 1-7-1

Symbol No. →	①													②	③		④		⑤	
Removing order of screw →	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Place to stick screw →																	✻	✻	✻	✻
Reference drawing →	Fig. 1-3-1														Fig. 1-3-2		Fig. 1-3-3		Fig. 1-3-4	
Screw tightening torque →	I																II		I	

Symbol No. →	⑥										⑦ / ⑧ / ⑨			⑩		⑪			⑫				
Removing order of screw →	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43
Place to stick screw →							✻	✻	✻	✻					✻						✻	✻	✻
Reference drawing →	Fig. 1-3-5										Fig. 1-3-6			Fig. 1-3-7		Fig. 1-3-8			Fig. 1-3-9				
Screw tightening torque →	I																						

Symbol No. →	⑬		⑭			⑮				
Removing order of screw →	44	45	46	47	48	49	50	51	52	53
Place to stick screw →	✻									
Reference drawing →	Fig. 1-3-10		Fig. 1-3-11			Fig. 1-3-12				
Screw tightening torque →			I							

	MONITOR ASSY						
Removing order of screw →	1	2	3	4	5	6	7
Place to stick screw →			✻	✻			
Reference drawing →	Fig. 1-4-1 ~ 2						
Screw tightening torque →	III		II		IV		

	B/W VF ASSY								OP BLOCK ASSY								
Removing order of screw →	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	9
Place to stick screw →																	
Reference drawing →	Fig. 1-5-1								Fig. 1-6-1								
Screw tightening torque →	V								VI								

< NOTE >

1) ✻ : Don't reuse the screw, because screw lock bond was applied to them.

2) Pay careful attention to tightening torque for each screw.

I : 0.088N·m (0.9kgf·cm) II : 0.147N·m (1.5kgf·cm) III : 0.098N·m (1.0kgf·cm)

IV : 0.069N·m (0.7kgf·cm) V : 0.078N·m (0.8kgf·cm) VI : 0.118N·m (1.2kgf·cm)

Table 1-8-1

SECTION 2
MECHANISM ADJUSTMENT

2.1 PRELIMINARY REMARKS ON ADJUSTMENT AND REPAIR

2.1.1 Precautions

1. When fastening parts, pay careful attention to the tightening torque of each screw. Unless otherwise specified, tighten a screw with the torque of 0.039 N•m (0.4 kgf•cm).
2. Be sure to disconnect the set from the power supply before fastening and soldering parts.
3. When disconnecting/connecting wires, be careful not to get them and their connectors damaged. (Refer to the Section 1.)
4. When replacing parts, be very careful neither to damage other parts nor to fit wrong parts by mistake.

2.1.2 Notes on procedure for disassemby/assembly

The disassembling procedure table (Table 2-4-1 on page 2-6, a part of the table is shown below for reference)shows the procedure to disassemble/reassemble mechanism parts.
Carefully read the following explanation before starting actual disassembling/reassembling work. The item numbers (circled numbers)in the following explanation correspond to those appearing under respective columns of the table.

(1) Circled numbers appearing in this column indicate the order to remove parts. When reassembling, follow these numbers in the reverse order. Circled numbers in this column correspond to those appearing in drawings of this section.

(2) This column shows part names corresponding to circled numbers in the left column.

(3) The symbol (T or B)appearing in this column shows the side which the objective part is mounted on.
T =the upper side, B =the lower side

(4) Symbols appearing in this column indicate drawing numbers.
Step Part Name Fig. Point Note Remarks

(5) This column indicates parts and points such as screws, washers, springs, and others to be removed/fitted for disassembling/reassembling the mechanism. Besides such the parts, this column occasionally indicates working points.

P = Spring
W = Washer
S = Screw
* = Lock (L),soldering (SD),shield,connector (CN), etc.

Example
- Remove (W1)=Washer W1.
- *Remove the solder at (SD①)=Point SD①.
- *Disconnect Ⓐ =Connector Ⓐ .

(6) Numbers in this column represent the numbers of notes in the text. For example, "①" means "Note ①".
(For parts that need phase adjustment after reassembling, refer to "2.6 MECHANISM ADJUSTMENTS".)

(7) This column indicates required after disassembling/reassembling work such as phase adjustment or mechanism adjustment.

NO.	PART NAME		FIG.	POINT	NOTE	REMARKS
Ⓐ	Cassette housing assembly	T	Fig. 2-4-5	3(S1),(L1a)-(L1d)	1a, 1b, 1c, 1d	Adjustment
2a	Reel disk (SUP) assembly	T	Fig. 2-4-6	(W2)	2a, 2b	
2b	Reel disk (TU) assembly	T		(W2)	2a, 2b	
2c	Reel cover assembly	T		(S2b),2(S2a),(W2)	2d	
3a	Tension arm assembly	T	Fig. 2-4-7	(W3a)	3b	
3b	Release guide assembly	T		-	3a	
3c	Idler arm assembly	T		(W3b)	-	
3d	Guide arm assembly	T		-	3a	
3e	Pinch roller arm assembly	T		(W3a)	-	
4a	Cleaner arm assembly	T	Fig. 2-4-8	(L4a)	4a	
4b	Slant pole arm assembly	T		(W4),(L4b),(P4a),(P4b)	4b	
4c	Drum assembly	T		3(S4)	-	
5a	Guide roller (S) assembly	T	Fig. 2-4-9	(P5)	5a	
5b	Rail assembly	T		3(W5a), (W5b)	5b, 5c	

(1) (2) (3) (4) (5) (6) (7)

2.2 JIGS AND TOOLS REQUIRED FOR DISASSEMBLY, ASSEMBLY AND ADJUSTMENT

2.2.1 Tools required for adjustments

1 Torque Driver YTU94088	2 Bit YTU94088-003
	
3 Tweezers P-895	4 Chip IC Replacement Jig PTS40844-2
	
5 Guide Driver YTU94148A	6 Adjustment Driver YTU94028
	
7 Slit Washer Installation Jig YTU94121A	8 Jig Connector cable YTU93082C
	
9 Communication cable YTU93107A	10 PC cable QAM0099-002
	
11 Service Support System YTU94057-57	12 Alignment Tape MC-1
	
13 Cleaning Cloth KSMM-01	
	

Table 2-2-1

1. **Torque Driver**
   Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.
2. **Bit**
   This bit is slightly longer than those set in conventional torque drivers.
3. **Tweezers**
   To be used for removing and installing parts and wires.
4. **Chip IC replacement Jig**
   To be used for adjustment of the camera system.
5. **Guide Driver**
   To be used to turn the guide roller to adjustment of the linarity of playback envelope.
6. **Adjustment Driver**
   To be used for adjustment.
7. **Slit washer Installation Jig**
   To be used to install slit washers.
8. **Jig Connector cable**
   Connected to CN105 of the main board and used for electrical adjustment, etc.
9. **Communication cable**
   Connect the Communication cable between the PC cable and Jig connector cable when performing a PC adjustment.
10. **PC cable**
    To be used to connect the VideoMovie and a personal computer with each other when a personal computer is used for adjustment.
11. **Service Support System**
    To be used for adjustment with a personal computer.
12. **Alignment Tape**
    To be used for check and adjustment of interchangeability of the mechanism.
13. **Cleaning Cloth**
    Recommended cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

2.3 DISASSEMBLY/ASSEMBLY OF MECHANISM ASSEMBLY

2.3.1 General statement

The mechanism should generally be disassembled/assembled in the EJECT mode (ASSEMBLY mode). (Refer to Fig. 2-3-1.)
However, when the mechanism is removed from the main body, it is set in the STOP mode. Therefore, after the mechanism is removed from the main body, supply 3 V DC to the electrode on the top of the loading motor to enter the mechanism mode into the EJECT mode compulsory.

<Mechanism assembly/Cassette housing assembly>



<Back side of the mechanism assembly>



Fig. 2-3-1

2.3.2 Explanation of mechanism mode

The mechanism mode of this model is classified into six modes as shown in Table 2-3-1. Each mechanism mode can be distinguished from others by the relative position of "○" mark on the sub cam gear to the inner or outer protrusion on the main deck.
Refer to Fig. 2-3-2 to 2-3-8 below.
The EJECT mode, C IN mode and SHORT FF mode should be recognized by the relative position of the "○" mark to the inner protrusion, while the STOP mode, REV mode and PLAY mode should be recognized by that to the outer protrusion.



Fig. 2-3-2



Fig. 2-3-3



Fig. 2-3-4



Fig. 2-3-5



Fig. 2-3-6



Fig. 2-3-7



Fig. 2-3-8

2.3.3 Mechanism timing chart

MODE / PARTS	EJECT	C IN	SHORT FF	STOP	REV	PLAY
MAIN CAM (ø10.4)	0	31.7 45.6 49.5	74.04	129.5 156.6 169.2	211.5	280.3
SUB CAM (ø11)	0	30 43.1 46.8	70	122.5 148.1 160	200	265
ENCODER (ø10)	0	33 47.4 51.5	77	134.7 162.9 176	220	291.5



MAIN CAM (ø10.4)	47.2 52.0	155.5	265.0
SUB CAM (ø11)	44.6 49.2	147.0	250.5
ENCODER (ø10)	49.1 54.1	161.7	275.6

Table 2-3-1

2.4 DISASSEMBLY/ASSEMBLY OF MECHANISM ASSEMBLY

2.4.1 Follow chart

1. Configuration



Fig. 2-4-1

2. Procedures for disassembly



Fig. 2-4-2

3. Disassembling procedure table

NO.	PART NAME		FIG.	POINT	NOTE	REMARKS
Ⓐ	Cassette housing assembly	T	Fig. 2-4-5	3(S1),(L1a)-(L1d)	1a, 1b, 1c, 1d	Adjustment
2a	Reel disk (SUP) assembly	T	Fig. 2-4-6	(W2)	2a, 2b	
2b	Reel disk (TU) assembly	T		(W2)	2a, 2b	
2c	Reel cover assembly	T		(S2b),2(S2a),(W2)	2d	
3a	Tension arm assembly	T	Fig. 2-4-7	(W3a)	3b	
3b	Release guide assembly	T		-	3a	
3c	Idler arm assembly	T		(W3b)	-	
3d	Guide arm assembly	T		-	3a	
3e	Pinch roller arm assembly	T		(W3a)	-	
4a	Cleaner arm assembly	T	Fig. 2-4-8	(L4a)	4a	
4b	Slant pole arm assembly	T		(W4),(L4b),(P4a),(P4b)	4b	
4c	Drum assembly	T		3(S4)	-	
5a	Guide roller (S) assembly	T	Fig. 2-4-9	(P5)	5a	
5b	Rail assembly	T		3(W5a), (W5b)	5b, 5c	
Ⓑ	Slide deck assembly / Ⓒ Main deck assembly	T	Fig. 2-4-10	(W6),(L6a)-(L6d)	6a, 6b	(Adjustment)
Ⓑ	Slide deck assembly					
7a	Loading brake assembly	T	Fig. 2-4-11	(W7),(L7a),(P7a)	7e	Adjustment
7b	Guide pin (S)	T		(S7a)	-	
7c	Pad arm assembly	T		(W7),(L7b),(P7b)	7d	
7d	Slide guide plate assembly	T		(S7b)	7c	Adjustment
7e	Collar	T		-	7a	
7f	Collar	T		-	7a	
7g	Sub brake assembly	T		(W7),(L7c),(P7c)	7b	
7h	Control plate assembly	T		2(W7),(L7d),(P7d)	7b	
Ⓒ	Main deck assembly					
8a	Tension lever assembly	T	Fig. 2-4-12	-	8c	
8b	Slide lever assembly	T		-	8b	
8c	Brake control lever assembly	T		-	8a	
9a	Loading guide	T	Fig. 2-4-13	(S9)	-	
9b	Timing belt	T		-	9b	
9c	Center gear assembly	T		-	-	
9d	Motor bracket assembly	T		2(S9)	9a	
9e	Worm wheel	T		(W9)	-	(Phase adjustment)
9f	Gear holder	T		(S9)	-	
10a	Main cam gear	T	Fig. 2-4-14	(S10)	10b	Phase adjustment
10b	Brake control plate	T		(L10)	10b	Phase adjustment
10c	Rotary encoder	T		(S10),(W10a)	10a	Phase adjustment
10d	Connect gear	T		(W10a)	-	(Phase adjustment)
10e	Reel drive pulley assembly	T		(W10b)	-	
11a	Catcher (T) assembly	T	Fig. 2-4-15	2(S11)	-	
11b	Capstan motor	T		2(S11)	-	
11c	Charge arm assembly	T		(W11)	11	
11d	Sub cam gear	T		(S11)	-	Phase adjustment
11e	PWB holder	B		2(S11)	-	

Table 2-4-1

< TOP VIEW >



Fig. 2-4-3

< BOTTOM VIEW >



Fig. 2-4-4

2.4.2 Disassembly/assembly

1. Ⓐ Cassette housing assembly



Fig. 2-4-5



Note 1a:
Shift the mechanism mode from the STOP mode to the EJECT mode.

Note 1b:
Reassemble the cassette housing assembly to the mechanism as the cancel lever is moved in the direction of the arrow.

Note 1c:
When reassembling the cassette housing to the mechanism, make sure that there is no deformation in the frame or no damage to the switches, etc.

Note 1d:
After reassembling the component parts, check the mechanism operation in the PLAY mode.
For details of checking method, refer to "2.6.1 assembling slide deck assembly and main deck assembly".

2. (2a) Reel disk (SUP) assembly
(2b) Reel disk (TU) assembly
(2c) Reel cover assembly



Fig. 2-4-6

Note 2a:
When removing the reel disk assembly, be careful not to break the brake pad which applies lateral pressure to the reel disk.

Note 2b:
Be careful not to make a mistake in installing the reel disk. The SUP reel disk and TU reel disk can be distinguished from each other by the appearance as shown below.



Note 2c:
When reassembling the cassette housing to the mechanism, make sure that there is no deformation in the frame or no damage to the switches, etc.

Note 2d:
When fitting the reel cover assembly to the set, carefully tighten the screw with the specified tightening torque of 0.069N•m (0.7kgf•cm).

3. (3a) Tension arm assembly/ (3b) Release guide assembly (3c) Idler arm assembly/ (3d) Guide arm assembly (3e) Pinch roller arm assembly



Fig. 2-4-7

Note 3a:
When removing the reel cover assembly, pay heed to release guide assembly and guide arm assembly. For the guide arm assembly is just inserted into the slide deck assembly from the upside and it is apt to come off after the reel cover assembly is removed.

Note 3b:
Reassemble the tension arm assembly to the mechanism as the pad arm assembly is moved to the extent in the direction of the arrow.



4. (4a) Cleaner arm assembly/ (4b) Slant pole arm assembly (4c) Drum assembly



Fig. 2-4-8

Note 4a:
When removing the cleaner arm assembly, it is recommended to remove the slant pole arm assembly together with it except the case of a single unit replacement, because the hook (L4a) is hard to disengage.

Note 4b:
How to set the coil spring (P4b).



5. (5a) Guide roller (S) assembly/ (5b) Rail assembly



Fig. 2-4-9

Note 5a:
When reassembling, insert the tip of the guide roller with the coil spring put on it into the hole on the main deck. Tighten the guide roller by about 6 turns so that the height of the guide roller assembly is 19 mm or so as shown in the figure.



Note 5b:
Pay careful attention to the spring not to lose it.

Note 5c:
Pay careful attention to the engagement of the rail assembly's arm ends because they easily come off the engagement. Moreover, make sure that there is neither deformation nor damage observed in them.

Note 5d:
When removing the rail assembly, check to see if the collar is securely set in the arm groove.

6. (B) Slide deck assembly/ (C) Main deck assembly



Fig. 2-4-10

Note 6a:
When removing the slide deck assembly, pay heed to the three components of the following because they are apt to come off after the slide deck assembly is removed.

(8a) Tension lever assembly/ (8b) Slide lever assembly
(8c) Brake control lever assembly
For reassembling those components, refer to Fig. 2-4-12.

Note 6b:
When reassembling the slide deck assembly to the main deck assembly, combine them with each other by the side grooves and then slide the slide deck assembly by 1 mm or so.



7. (7a) Loading brake assembly/ (7b) Guide pin (S)
(7c) Pad arm assembly/ (7d) Slide guide plate assembly
(7e) Collar/ (7f) Collar/ (7g) Sub brake assembly
(7h) Control plate assembly



Fig. 2-4-11

8. (8a) Tension lever assembly/ (8b) Slide lever assembly
(8c) Brake control lever assembly



Fig. 2-4-12

Note 7a:
Don't remove these parts unreasonably. If they are removed for some reason, be very careful not to lose them.

Note 7b:
When reinstalling the sub brake assembly, set the control plate assembly so that its hook is set in the □ part of the sub brake assembly.



Note 7c:
Since the slide guide plate assembly controls the slide deck assembly so that it exactly slides the main deck assembly, it must exactly be assembled in the PLAY mode. Therefore, temporarily fix the slide guide plate assembly in this stage. For details of reassembling procedure, refer to "2.6.1 Assembling slide deck assembly and main deck assembly" .

Note 7d:
The pad arm assembly controls the tension level of the tension arm assembly. For adjustment of the tension arm assembly, refer to "2.6.2 Locating tension pole".

Note 7e:
When reinstalling the load brake assembly, slightly lift the slide deck assembly upwards because the lower part of the load brake assembly sticks out of the slide deck assembly.

Note 8a, 8b, 8c:
For refitting the respective parts, refer to the following figures

(8a) Tension lever assembly



(8b) Slide lever assembly



(8c) Brake control lever assembly



9. (9a) Loading guide/ (9b) Timing belt
(9c) Center gear assembly/ (9d) Motor bracket assembly
(9e) Worm wheel/ (9f) Gear holder



Fig. 2-4-13

Note 9a:
Carefully handle the DEW sensor. (Don't touch the sensor surface in particular.)

Note 9b:
When engaging the timing belt, make sure that it securely engages with the gears of both the center gear assembly and reel drive pulley assembly.

10. (10a) Main cam gear/ (10b) Brake control plate
(10c) Rotary encoder/ (10d) Connect gear
(10e) Reel drive pulley assembly



Fig. 2-4-14

Note 10a:
When removing/refitting parts, pay careful attention to the flexible board and so on not to damage them.

Note 10b:
When reinstalling the main cam gear and the brake control plate, first fit them together so that the protrusion on the brake control plate is set in the slot on the main cam gear as shown below, next install the two together to the main deck assembly.



11. (11a) Catcher (T) assembly/ (11b) Capstan motor
(11c) Charge arm assembly/ (11d) Sub cam gear
(11e) PWB holder



Fig. 2-4-15

Note 11:
The following figure shows how to put the charge arm assembly and sub cam gear assembly together.



2.4.3 List of procedures for disassembly



Note)

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-P	AA
Oil	YTU94027	BB

Fig. 2-4-16

2.5 CHECKUP AND ADJUSTMENT OF MECHANISM PHASE



<Connect gear> (Note 2)
Set the connect gear so that its locating hole meets the hole on the main deck assembly.

<Rotary encoder>
Set the "■" of the rotary part at the tapped hole as shown in the figure.

<Worm wheel> (Note 2)
Set the worm wheel so that its locating hole meets the hole on the main deck assembly.

<Sub cam gear>
Set the sub cam gear so that its locating hole meets the hole on the main deck assembly. This state represents that the mechanism is in the EJECT mode, which is the "mechanism assembly mode".

<Main cam gear /Brake control plate>
After fitting the main cam gear and brake control plate together,set them together so that their locating holes meet the hole on the main deck assembly.

<Connect gear 2> (Note 2)
Set the connect gear 2 so that its locating hole meets the hole on the main deck assembly.

Note 1:
Since the connect gear 2 is tightly fixed to the main deck by caulking, adjust its phase with the connect gear and sub cam gear.

Note 2:
The part that needs phase adjustment by the hole on the main deck assembly must exactly be set as the specified phase. There is a fear that some part is installed in a wrong phase because assembling of the mechanism is automated. If so, set every part in the correct phase whenever the mechanism is reassembled.

Fig. 2-5-1

2.6 MECHANISM ADJUSTMENTS

2.6.1 Assembling slide deck assembly and main deck assembly



Fig. 2-6-1

Assembling procedure

1. Loosen the screw Ⓐ.
2. Set the mechanism in the PLAY mode.
   (Refer to “2.3.2 Explanation of mechanism mode”.)
3. Press the end face Ⓑ of the slide deck assembly (reel disk side) and the end face Ⓒ of the main deck assembly (drum assembly side) with uniform force so that the two assemblies are tightly pressed to each other. Furthermore, press the part Ⓓ and tighten the screw Ⓐ.

Note : *Tightening torque for screw Ⓐ: 0.069 N·m (0.7 kgf·cm)*

2.6.2 Locating tension pole



Fig. 2-6-2

Locating procedure

1. Enter the mechanism assembly into the PLAY mode. (Refer to “2.3.2 Explanation of mechanism mode”.)
2. When the “ ▶-----◀ ” part is positioned down, make sure that the part “a” of the tension arm assembly is located within the range of “b”.
3. If the part “a” is out of the range, turn the pin “c” to adjust the position.

2.7 SERVICE NOTE

Use the following chart to manage mechanism parts that are removed for disassembling the mechanism.

<table>
<tr><td>1</td><td colspan="5">(A) Cassette housing assembly
 
S1×3</td></tr>
<tr><td rowspan="2">2</td><td colspan="2">(2a) Reel disk (SUP) assembly
 
W2×1</td><td colspan="3" rowspan="2">(2c) Reel cover assembly
 
S2a×2 S2b×1 W2×1</td></tr>
<tr><td colspan="2">(2b) Reel disk (TU) assembly
 
W2×1</td></tr>
<tr><td>3</td><td>(3a) Tension arm assembly

W3a×1</td><td>(3b) Release guide assembly
 </td><td>(3c) Idler arm assembly
 
W3b×1</td><td>(3d) Guide arm assembly
  </td><td colspan="2">(3e) Pinch roller arm assembly

W3a×1</td></tr>
<tr><td>4</td><td>(4a) Cleaner arm assembly
 </td><td colspan="2">(4b) Slant pole arm assembly
 
W4×1 P4a×1 P4b×1</td><td colspan="2">(4c) Drum assembly
 
S4×3</td></tr>
<tr><td>5</td><td>(5a) Guide roller (S) assembly
 
P5×1</td><td colspan="4">(5b) Rail assembly
 
W5a×3 W5b×1</td></tr>
</table>

Table 2-7-1a

6	B Slide deck assembly  W6×1	7	7a Loading brake assembly W7×1 P7a×1	7b Guide pin (S) S7a×1	7c Pad arm assembly W7×1 P7b×1	7d Slide guide plate assembly S7b×1
			7e Collar	7f Collar	7g Sub brake assembly W7×1 P7c×1	7h Control plate assembly  W7×2 P7d×1
8	C Main deck assembly 		8a Tension lever assembly 	8b Slide lever assembly 	8c Brake control lever assembly 	
9	9a Loading guide  S9×1	9b Timing belt 	9c Center gear assembly	9d Motor bracket assembly  S9×2	9e Worm wheel W9×1	9f Gear holder S9×1
10	10a Main cam gear S10×1	10b Brake control plate 	10c Rotary encoder  S10×1 W10a×1	10d Connect gear W10a×1	10e Reel drive pulley assembly W10b×1	
11	11a Catcher (T) assembly  S11×2	11b Capstan motor  S11×2	11c Charge arm assembly  W11×1	11d Sub cam gear  S11×1	11e PWB holder  S11×2	

Table 2-7-1b

2.8 JIG CONNECTOR CABLE CONNECTION

Remove one screw (1) first and the cover (JIG) next.



Fig. 2-8-1 Jig connector cable connection



Fig. 2-8-2 Jig connector cable schematic diagram

SECTION 3
ELECTRICAL ADJUSTMENT

3.1 PRECAUTION

1. Precaution

Both the camera and deck sections of this model needs a personal computer for adjustment except simple adjustment with potentiometers. If some of the following parts is replaced for repair or other reason, the repaired set must be adjusted with a personal computer.

- OP block
- E^2PROM (IC1003 of MAIN board)
- MONITOR
- E^2PROM (IC7603 of MONITOR board)

In the event of malfunction with electrical circuits, trouble-shooting with the aid of proper test instruments most be done first, and then commence necessary repair, replacement and adjustment, etc.

1. In case of wiring to chip test points for measurement, use IC clips, etc. to avoid any stress.
2. Since connectors are fragile, carefully handle them in disconnecting and connecting.
3. Shortcircuit between operation and DECK chassis.

2. Required test equipment

1. Color TV monitor.
2. AC adapter
3. Oscilloscope (dual-trace type, observable 100 MHz or higher frequency)

Note : *It is recommended to use one observable 300 MHz or higher frequency.*

4. Digital voltmeter
5. Frequency counter (with threshold level adjuster)
6. Personal computer

3. Tools required for adjustments

1 Torque Driver YTU94088	2 Bit YTU94088-003
	
3 Tweezers P-895	4 Chip IC Replacement Jig PTS40844-2
	
5 Jig Connector Cable YTU93082C	6 Communication Cable YTU93107A
	
7 PC Cable QAM0099-002	8 Service Support System YTU94057-57
	
9 Alignment Tape MC-1	10 INF Adjustment Lens YTU92001B
	
11 INF Adjustment Lens Holder YTU94087	12 Camera Stand YTU93079
	
13 Light box Assembly YTU93096A	14 Gray Scale Chart YTU94133A
	
15 Color Bar Chart YTU94133C	
	

Table 3-1-1

1. **Torque driver**
   Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.
2. **Bit**
   This bit is slightly longer than those set in conventional torque drivers.
3. **Tweezers**
   To be used for removing and installing parts and wires.
4. **Chip IC replacement jig**
   To be used for adjustment of the camera system.
5. **Jig connector cable**
   Connected to CN105 of the main board and used for electrical adjustment, etc.
6. **Communication Cable**
   Connect the Communication cable between the PC cable and Jig connector cable when performing a PC adjustment.
7. **PC cable**
   To be used to connect the VideoMovie and a personal computer with each other when a personal computer is used for adjustment.
8. **Service support system**
   To be used for adjustment with a personal computer.
9. **Alignment tape**
   To be used for check and adjustment of interchangeability of the mechanism.
10. **INF adjustment lens**
    To be used for adjustment of the camera system.
11. **INF adjustment lens holder**
    To be used together with the camera stand for operating the VideoMovie in the stripped-down condition such as the status without the exterior parts or for using commodities that are not yet conformable to the interchangeable ring.
12. **Camera stand**
    To be used together with the INF adjustment lens holder.
13. **Light box assembly**
    To be used for adjustment of the camera system.
14. **Gray scale chart (for Light box assembly)**
    To be used for adjustment of the camera system.
15. **Color bar chart (for Light box assembly)**
    To be used for adjustment of the camera system.

3.2 SETUP

1. Setup for electrical adjustment with personal computer.

   NOTE: *Remove one screw (1) first and the cover (JIG) next.*



Fig. 3-2-1 Connection for Service support system

SECTION 5
PARTS LIST

SAFETY PRECAUTION

Parts identified by the ⚠ symbol are critical for safety. Replace only with specified part numbers.

5.1 PACKING AND ACCESSORY ASSEMBLY <M1>

The instruction manual to be provided with this product will differ according to the destination.



#	⚠	REF No.	PART No.	PART NAME, DESCRIPTION

****

PACKING AND ACCESSORY ASSEMBLY <M1>

	1	LY32567-001A	PACKING CASE,B
		LY32567-001B	PACKING CASE,A
		LY32567-003A	PACKING CASE,G
		LY32567-006B	PACKING CASE,E,F
	2	LY32568-001A	CUSHION
	3	LY30023-008A	POLY BAG
	4	QPA02003506	POLY BAG
⚠	5	LYT0869-001A	INST.BOOK(EN),B
⚠		LYT0869-001B	INST.BOOK(EN),E,G
⚠		LYT0869-002A	INST.BOOK(FR),B
⚠		LYT0869-002B	INST.BOOK(FR),E,G
⚠		LYT0869-003A	INST.BOOK(SP),B
⚠		LYT0869-003B	INST.BOOK(SP),E,G
⚠		LYT0872-001A	INST.BOOK(EN),F
⚠		LYT0872-002A	INST.BOOK(FR),F
⚠		LYT0872-003A	INST.BOOK(SP),F
⚠		LYT0946-001A	INST.BOOK(EN),A
⚠		LYT0946-002A	INST.BOOK(FR),A
⚠		LYT0946-003A	INST.BOOK(SP),A
⚠	6	LYT0873-001B	INST.BOOK(SOFT.EN),B
⚠		LYT0873-003B	INST.BOOK(SOFT.FR),B
⚠		LYT0873-005B	INST.BOOK(SOFT.SP),B
⚠		LYT0912-001A	INST.BOOK(SOFT.EN),E,F,G
⚠		LYT0912-003A	INST.BOOK(SOFT.FR),E,F,G
⚠		LYT0912-005A	INST.BOOK(SOFT.SP),E,F,G
	7	LYT0934-001A	SHEET(AGREMENT),B,E,F,G
	8	YU10350	Q.CARD(JCA)
	9	BT-51005-5	WARRANTY INF.
	10	LYT0974-001A	SHEET(ATT.),B
	15	QPA01703005	POLY BAG
	16	QAM0211-001	CABLE ASSY,AUDIO/VIDEO CABLE
	17	QQR0918-002	CORE FILTER
	18	PEAC0428-150	CABLE ASSY,EDITING CABLE,F,G
	19	QQR0491-002	CORE FILTER,F,G
	20	QAM0324-001	USB CABLE,E,F,G
	21	QQR0918-002	CORE FILTER,E,F,G
	22	QAM0084-001	PC CONNECTION CABLE,B
	23	QQR0491-002	CORE FILTER,B
⚠	24	LY20848-001B	AC ADAPTER,AP-V12U
	25	QQR0490-002	CORE FILTER
⚠	30	LY32566-001A	BATTERY PACK ASSY,BN-V408U-B
	31	LY20186-001A	SHOULDER STRAP
	32	LY20750-001A	REMOTE CONTROL UNIT,RM-V717U,F,G
		LY42129-001A	REMOTE CONTROL UNIT,RM-V715U,A,B,E
	33	–	BATTERY,AAA(R03),X2
	34	LY32210-022A	CD ROM ASSY,B
		LY32210-023A	CD ROM ASSY,E,F,G
	35	LY32210-009A	CD ROM ASSY
	36	LY43294-002A	CAP(HOOD)ASSY
	37	QAM0404-002	MEMORY CARD,8MB(SD),E,F,G
	38	BT-51028-1	REGIST.CARD

MODEL	MARK
GR-DVL220U	A
GR-DVL320U	B
GR-DVL520U	E
GR-DVL522U	F
GR-DVL720U	G

• INSTRUCTIONS

EN ..... ENGLISH
FR ..... FRENCH
SP ..... SPANISH

5.2 FINAL ASSEMBLY <M2>





# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION
**********		

FINAL ASSEMBLY <M2>

101	LY20774-001B	UPPER CASE(2.5)ASSY,B
	LY20774-002B	UPPER CASE(2.5)ASSY,A
	LY20774-003B	UPPER CASE(2.5)ASSY,E,F
	LY20797-001B	UPPER CASE(3.5)ASSY,G
101A	LY20775-001A	TOP COVER(2.5),A,B,E,F
	LY20776-001A	TOP COVER(3.5),G
101B	LY32371-001A	PLATE(UPPER),E,F,G
	LY32371-002A	PLATE(UPPER),B
	LY32371-004A	PLATE(UPPER),A
101C	LY40664-001A	SPACER,X2
101D	LY31019-001A	BASE
101E	LY32375-001A	COVER(SD),E,F,G
101F	LY43292-001A	SHAFT,E,F,G
101G	LY43293-001A	SPRING,E,F,G
101H	LY43261-001A	HOOK(UPPER)
101J	LY43540-001A	EARTH SHEET(2.5),A,B,E,F
	LY43541-001A	EARTH SHEET(3.5),G
101K	LY30018-023A	SPECIAL SCREW,X2
101L	LY30018-084A	SPECIAL SCREW,X2
101M	LY30018-038A	SPECIAL SCREW,X2,G
	LY30018-084A	SPECIAL SCREW,X2,A,B,E,F
101N	LY32376-001A	COVER(SD)DUMMY,A,B
101P	LY30018-023A	SPECIAL SCREW,A,B
102	LY30018-0D6A	SPECIAL SCREW,X2
103	LY32373-001A	BRACKET(MONITOR)
104	LY30018-066A	SPECIAL SCREW,X4
105	LY20777-001A	COVER(HINGE)
106	LY30018-047A	SPECIAL SCREW,X2
107	LY43263-001A	KNOB(SLIDE),B,E,F,G
108	LY43263-002A	KNOB(SLIDE),E,F,G
109	QAS0048-001	SPEAKER
110	LY30018-023A	SPECIAL SCREW,X5
111	LY30018-047A	SPECIAL SCREW
112	QUQ105-4007AA	FFC WIRE,MONI CN761-MAIN CN101
113	QUQ105-1011AA	FFC WIRE,MONI CN762-DSC CN8002,E,F,G
114	LY30018-084A	SPECIAL SCREW,X2
115	LY30018-084A	SPECIAL SCREW
116	LY30018-047A	SPECIAL SCREW,X2
117	LY30018-047A	SPECIAL SCREW
118	LY30018-064A	SPECIAL SCREW,X2
119	LY32378-009A	WINDOW(MONI2.5),A,B,E,F
	LY32379-005A	WINDOW(MONI3.5),G
120	LY43566-001A	STICKER(SIDE),A
	LY43566-002A	STICKER(SIDE),B
	LY43566-003A	STICKER(SIDE),E,F,G
121	LY30018-084A	SPECIAL SCREW
125	LY32382-001A	FRONT COVER ASSY,B,E,F,G
	LY32382-002A	FRONT COVER ASSY,A
125A	LY32383-001A	HOOD
125B	LY32384-001A	RING
125C	LY32385-001A	HOOD(SCREW)
125D	LY30018-084A	SPECIAL SCREW
125E	LY30018-0A7A	SPECIAL SCREW,X4
125F	LY32343-001A	MIC
125G	LY32388-001A	BASE(LIGHT),B,E,F,G
125H	LY32338-001A	DC LIGHT ASSY,B,E,F,G
125J	LY32410-001A	COVER(LIGHT),A
126	LY43567-001A	STICKER(TOP),A,B
	LY43567-005A	STICKER(TOP),E,F,G
130	LY10317-001A	REAR UNIT
130A	LY32408-001A	KNOB(BATT.RELE)
130B	LY30001-018A	TENSION SPRING
130C	LY32409-001A	TERMINAL BASE
130D	LY43291-001A	TERMINAL(R),X2
130E	LY43290-001A	TERMINAL(L),X3
130F	LY30018-084A	SPECIAL SCREW,X3
131	LY30018-084A	SPECIAL SCREW,X3
132	LY30018-0C9A	SPECIAL SCREW,X2
133	LY30018-0C9A	SPECIAL SCREW
134	LY41691-001A	COVER(JIG)
135	LY30018-037A	SPECIAL SCREW
140	LY20769-002B	LOWER CASE ASSY,A,B
	LY20769-003B	LOWER CASE ASSY,E,F,G
140A	LY32363-001A	COVER(JACK)
140B	LY32364-001A	COVER(DC)
140C	LY40592-001A	CAP(GRIP BELT)
140D	LY20770-001A	ARM ASSY
140E	LY30029-0T9A	SPACER(A)
140F	LY32365-001A	PLATE
140G	LY20780-001A	GRIP BELT
140H	LY10304-001A	ZOOM UNIT
140J	LY10309-001A	CASSETTE COVER
140K	LY43254-001A	LOCK ASSY
140L	LY30018-084A	SPECIAL SCREW,X4
140M	LY30018-038A	SPECIAL SCREW
140N	LY30018-038A	SPECIAL SCREW,X3
140P	LY30018-0D1A	SPECIAL SCREW
140R	LY30018-084A	SPECIAL SCREW,X3
140S	LY30018-023A	SPECIAL SCREW,X4
140T	LY30018-038A	SPECIAL SCREW,X4
140U	LY43609-001A	SPACER(B)
141	LY30018-084A	SPECIAL SCREW,X2
142	LY30018-084A	SPECIAL SCREW,X2
143	LY30018-0C9A	SPECIAL SCREW
144	LY43256-001A	PLATE(ADJUST)
150	LY20778-001A	BRACKET(MECHA)
151	YQ43893-4	MINI SCREW
152	LY30019-026A	SPECIAL SCREW,X2
153	QYSPSPT1730R	SCREW,X3
154	LY40698-002A	LABEL(HOUSING)
155	LY40699-002A	LABEL(PUSH)
156	LY30018-084A	SPECIAL SCREW,X2
157	LY30018-066A	SPECIAL SCREW
158	LY30018-066A	SPECIAL SCREW,X2
159	LY30018-038A	SPECIAL SCREW
160	LY30019-038A	SPECIAL SCREW,X2
161	LY32081-001A	SHIELD PLATE
162	YQ43893-4	MINI SCREW
163	WJT0066-001A	E-CARD WIRE,MAIN CN113-JUNC CN571
164	LY30019-038A	SPECIAL SCREW,E,F,G
165	LY30029-0V6A	SPACER(A)
170	LY43257-001B	BRACKET(OP)ASSY
170A	LY42796-001A	BUSH,X3
171	LY30018-084A	SPECIAL SCREW
172	LY30018-066A	SPECIAL SCREW
173	LY30019-029B	SPECIAL SCREW,X3

– OPTICAL BLOCK SECTION –

251	J7A-153A	OPTICAL BLOCK ASSY
251A	LY30723-001B	ZOOM MOTOR
251B	LY30724-001B	FOCUS MOTOR
251C	LY30727-002A	SCREW,X5
251D	LY30727-001A	SCREW,X2
251E	LY42936-001A	OPTICAL LPF
251F	LY31639-003A	SPACER RUBBER
251G	LYH30375-002A	CCD BASE ASSY
251H	QYSPSGU1750Z	SCREW,X2
251J	LY32560-001A	IRIS MOTOR

5.3 MECHANISM ASSEMBLY <M3>



Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-P	AA
Oil	YTU94027	BB

NOTE: The section marked in **AA** and **BB** indicate lubrication and greasing areas.

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION
**********		

MECHANISM ASSEMBLY <M3>

400	YMA0025VCC/E	MECHA(A)ASSY
401	LY10240-001D	MAIN DECK ASSY
402	LY30436-001J	SLANT POLE ARM ASSY
403	YQ44246	SLIT WASHER
405	LY10080-001V	RAIL ASSY
406	YQ44246	SLIT WASHER,X3
407	LY40353-001D	GUIDE ROLLER(S)ASSY
408	LY30002-006C	COMPRESSION SPRING
409	QAR0026-002	CAPSTAN MOTOR
410	LY30504-001C	CATCHER(T)ASSY
411	YQ43893	MINI SCREW,X4
413	LY30448-001E	MOTOR BRACKET ASSY
414	YQ43893	MINI SCREW,X2
415	LY31840-001A	WORM WHEEL
416	YQ44246	SLIT WASHER
417	LY40496-001C	ROTARY ENCODER
418	YQ43893	MINI SCREW
419	YQ44246	SLIT WASHER
420	LY42632-001A	GEAR HOLDER
421	YQ43893-6	MINI SCREW
422	LY31841-001A	MAIN CAM
423	LY31842-001A	BRAKE CONTROL PLATE
424	YQ43893	MINI SCREW
425	LY42633-001A	TAKE UP CONTROL LEVER ASSY
426	LY31844-001A	SLIDE LEVER ASSY
427	LY31846-001A	CONNECT GEAR
428	YQ44246	SLIT WASHER
429	LY31847-001A	SUB CAM
430	YQ43893	MINI SCREW
431	LY31785-001A	PINCHI ROLLER ARM UNIT
432	YQ44246	SLIT WASHER
433	LY31850-001A	CHARGE ARM ASSY
434	YQ44246	SLIT WASHER
435	LY42643-001A	BRAKE CONTROL LEVER ASSY
436	LY42645-001A	REEL DRIVE PULLEY ASSY
437	YQ44246-2	SLIT WASHER
438	LY40391-002B	CENTER GEAR ASSY
439	LY40396-001A	TIMING BELT
440	LY40413-001A	COLLAR,X2
441	LY31854-001A	GUIDE ARM ASSY
442	LY31786-001A	SLIDE GUIDE PLATE UNIT
443	YQ43893-2	MINI SCREW
444	LY42651-001B	TENSION ARM ASSY
445	YQ44246	SLIT WASHER
446	LY30471-001D	PAD ARM ASSY
447	YQ44246	SLIT WASHER
448	LY42745-001A	IDLER ARM ASSY
449	YQ44246-2	SLIT WASHER
450	LY31861-001A	GUIDE PIN(SUPPLY)
451	YQ43893	MINI SCREW
452	LY40441-001B	REEL DISK(SUPPLY)ASSY
453	YQ44246	SLIT WASHER
454	LY40443-001B	REEL DISK(TAKE UP)ASSY
455	YQ44246	SLIT WASHER
456	LY31788-001A	CONTROL PLATE UNIT
457	YQ44246	SLIT WASHER,X2
458	LY40444-001E	LOADING BRAKE ASSY
459	YQ44246	SLIT WASHER
460	LY40452-001C	SUB BRAKE ASSY

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION
461	YQ44246	SLIT WASHER
462	LY31863-001B	RELEASE GUIDE ASSY
463	YQ44246	SLIT WASHER
464	LY20146-001H	REEL COVER ASSY
465	YQ43893-4	MINI SCREW,X2
466	YQ43893	MINI SCREW
467	YQ44246	SLIT WASHER
468	YDV2086S(CX)	DRUM ASSY
469	YQ43893	MINI SCREW,X3
470	LY20630-001A	PWB HOLDER
471	YQ43893	MINI SCREW,X2
472	LY10242-001A	SLIDE DECK ASSY
473	LY31833-001A	LOADING GUIDE
474	YQ43893	MINI SCREW
478	LY31832-001D	DECK ASSY
480	LY41573-001A	WASHER
481	LY31867-001B	CASSETTE HOUSING ASSY
482	YQ43893-4	MINI SCREW,X3

5.4 ELECTRONIC VIEWFINDER ASSEMBLY <M4>



#	⚠	REF No.	PART No.	PART NAME, DESCRIPTION

****

ELECTRONIC VIEWFINDER ASSEMBLY <M4>

		301	LY32349-001A	EYE CUP
		302	LY20766-001A	CASE A(VF)
		304	LY32351-001A	CAP(VF)
		305	LY20824-001B	VF HINGE ASSY
		306	QLD0193-001	LCD MODULE
		307	QAL0380-002	FPC
		309	LY30018-0F1A	SPECIAL SCREW,X3
		312	LY41701-002A	SHEET(CAUTION)1
		314	LY43041-002A	LABEL(VF)
		321	LY20767-001B	CASE B(VF)
		322	LY30019-037A	SPECIAL SCREW
		323	LY43231-001B	LEVER(VF)
		324	LY32472-002A	LENS ASSY
		324A	LY43356-001A	LENS(A)
		324B	LY43357-001A	LENS(B)
		325	LY43404-001A	SPRING(VF)
		331	LY43236-001A	SHEET
		332	LY43246-001A	SHEET2(POLA)
		333	LY32347-001B	HOLDER LCD(VF)
		334	LY43245-001A	SHEET(CUSION)
		335	LY43234-001A	SHEET1(POLA)
		336	LY43232-001A	SHEET(VF)
		337	LY43235-001A	SHEET(DIFF)
		338	LY43238-001A	HOLDER(LED)
		339	LY43239-001A	GUIDE(VF),X2
		340	LY30018-060A	SPECIAL SCREW,X4
		341	LY30029-0U6A	SPACER(A)
		342	LY43489-001B	PLATE(VF)

5.5 MONITOR ASSEMBLY <M5> [GR-DVL220U, 320U, 520U, 522U]



#	⚠	REF No.	PART No.	PART NAME, DESCRIPTION

****

MONITOR ASSEMBLY <M5>

		500	LYH20246-036B	MONITOR ASSY,A,B
			LYH20246-040B	MONITOR ASSY,E,F
		501	LY20808-001A	MONITOR COVER(2.5)ASSY,A,B
			LY20808-002A	MONITOR COVER(2.5)ASSY,E,F
		501A	LY31620-004A	KNOB(LOCK 1)
		501B	LY42180-002A	KNOB(LOCK 2)
		501C	LY30002-044A	COMPRESSION SPRING
		501D	LY30018-084A	SPECIAL SCREW,X2
		501E	LY42883-001A	MARK
		502	LY10264-001A	MONITOR CASE(2.5)
		504	LY20674-001A	HOLDER(2.5)
		505	LY31622-001A	BRACKET(EARTH)
		506	QLL0121-001	BACK LIGHT
		507	QLD0154-001	LCD MODULE
		508	LY32695-001A	MONITOR FPC ASSY
		508A	LY32574-001A	MONITOR FPC ASSY
		508B	LY32079-001A	HINGE ASSY
		508C	LY32380-001A	HINGE COVER(U)
		508D	LY32381-001A	HINGE COVER(L)
		508E	LY30018-058A	SPECIAL SCREW,X2
		508F	LY30018-023A	SPECIAL SCREW
		508G	LY30029-0Q5A	SPACER(A)
		509	QYSPSPT1730R	SCREW,X2
		510	LY30018-0F2A	SPECIAL SCREW,X2

5.5 MONITOR ASSEMBLY <M5> [GR-DVL720U]



#	⚠	REF No.	PART No.	PART NAME, DESCRIPTION

****

MONITOR ASSEMBLY <M5>

500	LYH20246-037B	MONITOR ASSY
501	LY20809-002A	MONITOR COVER(3.5)ASSY
501A	LY31620-004A	KNOB(LOCK 1)
501B	LY42180-002A	KNOB(LOCK 2)
501C	LY30002-044A	COMPRESSION SPRING
501D	LY30018-084A	SPECIAL SCREW,X2
501E	LY42883-001A	MARK
502	LY20598-002A	MONITOR CASE ASSY
502A	LY42388-001A	EARTH MON(2)
504	LY20568-001A	HOLDER(3.5PWB)
505	LY31622-001A	BRACKET(EARTH)
506	QLL0123-001	BACK LIGHT
507	QLD0203-001	LCD MODULE
508	LY32695-001A	MONITOR FPC ASSY
508A	LY32574-001A	MONITOR FPC ASSY
508B	LY32079-001A	HINGE ASSY
508C	LY32380-001A	HINGE COVER(U)
508D	LY32381-001A	HINGE COVER(L)
508E	LY30018-058A	SPECIAL SCREW,X2
508F	LY30018-023A	SPECIAL SCREW
508G	LY30029-0Q5A	SPACER(A)
509	QYSPSPT1730R	SCREW,X2
510	LY30018-0F2A	SPECIAL SCREW,X2

5.6 ELECTRICAL PARTS LIST

MODEL	MARK	MODEL	MARK
GR-DVL220U	A	GR-DVL522U	F
GR-DVL320U	B	GR-DVL720U	G
GR-DVL520U	E		

#	⚠	REF No.	PART No.	PART NAME, DESCRIPTION

****

MAIN BOARD ASSEMBLY <01>

		PW1	YB10359A-01	MAIN BOARD ASSY,B
			YB10359B-01	MAIN BOARD ASSY,A
			YB10359C-01	MAIN BOARD ASSY,E
			YB10359C-02	MAIN BOARD ASSY,F,G
		IC1001	UPD703039F1-A22	IC(MICRO C ROM),A,B
			UPD703039F1-A25	IC(MICRO C ROM),E,F,G
			or UPD70F3040F1A22	IC(MICRO C ROM),A,B
			or UPD70F3040F1A25	IC(MICRO C ROM),E,F,G
		IC1002	RS5C314	IC
		IC1003	X25170S8I-2.5-X	IC
			or 25LC160-I/SN-X	IC
			or CAT25C16SI	IC
			or AT25160N-10SC-X	IC
		IC1004	TC75S56FU	IC
		IC1005	TC7S00FU	IC
			or SN74AHC1G00K	IC
		IC1006	MB90097PFV145	IC(MICRO C ROM)
		IC1007	TC74VHC08FT	IC(DIGITAL)
			or SN74LV08APW	IC
		IC1008	IC-PST3423U-X	IC
		IC1301	SN74LV08APW	IC,A,B
		IC1302	MAX3221CAE	IC,A,B
			or ICL3221CA	IC,A,B
		IC1303	SN74LV02APW	IC
		IC1401	UPD703040YF-M06	IC(MICRO C ROM)
			or UPD70F3040YFM06	IC(MICRO C ROM)
		IC1402	TC7W66FU	IC(DIGITAL),A,B
			or SN74AHC2G66T	IC,A,B
	⚠	IC1601	BD6631KV	IC
		IC1602	TC7W14FU	IC(DIGITAL)
			or SN74AHC2G14T	IC
		IC2001	AK4560AVQ	IC
		IC3001	JCY0152	IC
		IC3005	JCY0136	IC
		IC3501	JCY0132	IC
		IC3502	SN74AHC1G04K	IC
		IC3701	BA7665FS	IC
		IC4201	HD49334F	IC
		IC4202	MM1385HN	IC
		IC4301	JCY0150	IC
		IC4302	TMS4C2973-28-X	IC
		IC4802	TA75W01FU	IC
		IC4803	TA75W01FU	IC
		IC4804	LM358DR2	IC
		IC4851	UPD16879GS	IC
		IC5501	JCY0117	IC
		IC6001	S-80842ANNP-W	IC
		IC6101	FA3698F	IC
		Q1001	DTC124EE	TRANSISTOR
			or UN9212J	TRANSISTOR
		Q1002	2SC4617/QR/-X	TRANSISTOR
			or 2SD2216J/QR/-X	TRANSISTOR
		Q1003	DTC143EE	TRANSISTOR
			or UN921LJ	TRANSISTOR
		Q1005	2SJ347	MOS FET
		Q1006	DTA114EE	TRANSISTOR
			or PDTA114EE	TRANSISTOR
			or UN9111J	TRANSISTOR
		Q1007	DTC144EE	TRANSISTOR
			or PDTC144EE	TRANSISTOR
			or UN9213J	TRANSISTOR
		Q1008	DTA114EE	TRANSISTOR
			or PDTA114EE	TRANSISTOR
			or UN9111J	TRANSISTOR
		Q1009	DTC144EE	TRANSISTOR
			or PDTC144EE	TRANSISTOR
			or UN9213J	TRANSISTOR
		Q1301	2SC4617/QR/-X	TRANSISTOR
			or 2SD2216J/QR/-X	TRANSISTOR
		Q1401	DTA114EE	TRANSISTOR
			or PDTA114EE	TRANSISTOR
			or RN2102	TRANSISTOR
			or UN9111J	TRANSISTOR
		Q1402	UMC3N	TRANSISTOR
		Q1403	UMC3N	TRANSISTOR
		Q1601	UMC3N	TRANSISTOR
		Q2001	UMX1N	PAIR TRANSISTOR
		Q2002	2SC4617/RS/-X	TRANSISTOR
		Q3001	2SC4617/RS/-X	TRANSISTOR
		Q3002	2SC4617/RS/-X	TRANSISTOR
		Q3701	UMT2N	PAIR TRANSISTOR
			or XP6401	TRANSISTOR
		Q3702	UMZ1N	PAIR TRANSISTOR
			or XP4601	TRANSISTOR
		Q4301	UMT2N	PAIR TRANSISTOR
			or XP6401	TRANSISTOR
		Q4302	UMT2N	PAIR TRANSISTOR
			or XP6401	TRANSISTOR
		Q4801	2SC4655/BC/-X	TRANSISTOR
		Q4802	2SC4617/RS/-X	TRANSISTOR,E,F,G
		Q4803	DTC143EE	TRANSISTOR,E,F,G
		Q4804	DTA144EE	TRANSISTOR,E,F,G
		Q4805	DTA143EE	TRANSISTOR,E,F,G
		Q4806	2SC4617/QR/-X	TRANSISTOR
		Q4851	2SC4617/RS/-X	TRANSISTOR
		Q6001	DTC144EE	TRANSISTOR
			or PDTC144EE	TRANSISTOR
			or RN1104	TRANSISTOR
			or UN9213J	TRANSISTOR
		Q6002	MCH6613	MOS FET
		Q6004	2SB1188/QR/-W	TRANSISTOR
		Q6201	MCH3308	MOS FET
		Q6202	2SA1577/RS/-X	TRANSISTOR
		Q6203	MCH3308	MOS FET
		Q6204	CPH3314	MOS FET
		Q6205	CPH3101	TRANSISTOR
		Q6206	2SC4617/RS/-X	TRANSISTOR
		Q6207	2SD2444K	TRANSISTOR,B,E,F,G
		Q6208	MCH3308	MOS FET
		Q6210	MCH3308	MOS FET
		Q6211	MCH3308	MOS FET
		Q6212	HN1C01FU/G/-X	PAIR TRANSISTOR
			or PUMX1	PAIR TRANSISTOR
			or UMX1N	PAIR TRANSISTOR
		Q6213	2SA1577/RS/-X	TRANSISTOR
		Q6214	DTC144EE	TRANSISTOR
			or PDTC144EE	TRANSISTOR
			or RN1104	TRANSISTOR
			or UN9213J	TRANSISTOR
		Q6215	HN1A01FU/G/-X	PAIR TRANSISTOR
			or PUMT1	PAIR TRANSISTOR
			or UMT1N	PAIR TRANSISTOR

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
	Q6216	2SC4617/RS/-X	TRANSISTOR
	Q6217	UMZ1N	PAIR TRANSISTOR,B,E,F,G
	Q6701	CPH3314	MOS FET
	D1001	DA221	DIODE
	D1301	1SS376	DIODE
	D1302	1SS376	DIODE
	D1602	DAP222	DIODE
	D1603	DAP222	DIODE
	D1604	DAP222	DIODE
	D3001	EC2C01C	VARI CAP DIODE
	D3002	EC2C01C	VARI CAP DIODE
	D3003	EC2C01C	VARI CAP DIODE
	D3004	MA2Z720	SB DIODE
	D5501	1SS355	DIODE
⚠	D6002	RB715F	SB DIODE
	D6201	CRS01	SB DIODE
	D6202	CRS01	SB DIODE
	D6203	CRS01	SB DIODE
	D6204	CRS01	SB DIODE
	D6205	CRS01	SB DIODE
	D6206	RB480Y	SB DIODE
	D6207	UDZS9.1B	ZENER DIODE
	D6208	RB480Y	SB DIODE
	D6701	EP10HY03	SB DIODE
	D6702	EP10HY03	SB DIODE
	R101	NRSA63J-0R0X	MG RESISTOR 0Ω,1/16W
	R102	NRSA63J-0R0X	MG RESISTOR 0Ω,1/16W
	R1001	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1002	NRSA6AJ-224W	MG RESISTOR 220kΩ,1/16W
	R1003	NRSA6AJ-472W	MG RESISTOR 4.7kΩ,1/16W
	R1004	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1005	NRSA6AJ-153W	MG RESISTOR 15kΩ,1/16W
	R1006	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1007	NRSA6AJ-334W	MG RESISTOR 330kΩ,1/16W
	R1008	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1009	NRSA6AJ-561W	MG RESISTOR 560Ω,1/16W
	R1010	NRSA6AJ-561W	MG RESISTOR 560Ω,1/16W
	R1015	NRSA6AJ-474W	MG RESISTOR 470kΩ,1/16W
	R1016	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1017	NRSA6AJ-561W	MG RESISTOR 560Ω,1/16W
	R1018	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1019	NRSA6AJ-623W	MG RESISTOR 62kΩ,1/16W
	R1020	NRSA6AJ-331W	MG RESISTOR 330Ω,1/16W
	R1021	NRSA6AJ-331W	MG RESISTOR 330Ω,1/16W
	R1022	NRSA6AJ-331W	MG RESISTOR 330Ω,1/16W
	R1023	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1024	NRSA6AJ-823W	MG RESISTOR 82kΩ,1/16W
	R1026	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1027	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1029	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1030	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1031	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1032	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1036	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1037	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1038	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1039	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1044	NRSA6AJ-123W	MG RESISTOR 12kΩ,1/16W
	R1045	NRSA6AJ-822W	MG RESISTOR 8.2kΩ,1/16W
	R1046	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1047	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1048	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1049	NRSA6AJ-393W	MG RESISTOR 39kΩ,1/16W

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
	R1050	NRSA6AJ-223W	MG RESISTOR 22kΩ,1/16W
	R1051	NRSA6AJ-272W	MG RESISTOR 2.7kΩ,1/16W
	R1052	NRSA6AJ-183W	MG RESISTOR 18kΩ,1/16W
	R1053	NRSA6AJ-154W	MG RESISTOR 150kΩ,1/16W
	R1054	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1055	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1056	NRSA6AJ-472W	MG RESISTOR 4.7kΩ,1/16W
	R1057	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1058	NRSA6AJ-222W	MG RESISTOR 2.2kΩ,1/16W
	R1059	NRSA6AJ-0R0W	MG RESISTOR,A,B 0Ω,1/16W
	R1060	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1066	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1071	NRSA6AJ-474W	MG RESISTOR 470kΩ,1/16W
	R1072	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1076	NRSA6AJ-0R0W	MG RESISTOR 0Ω,1/16W
	R1077	NRSA6AJ-0R0W	MG RESISTOR 0Ω,1/16W
	R1078	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1079	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1080	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1081	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1082	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1083	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1302	NRSA6AJ-472W	MG RESISTOR 4.7kΩ,1/16W
	R1306	NRSA6AJ-472W	MG RESISTOR 4.7kΩ,1/16W
	R1307	NRSA6AJ-0R0W	MG RESISTOR,E,F,G 0Ω,1/16W
	R1308	NRSA6AJ-0R0W	MG RESISTOR,E,F,G 0Ω,1/16W
	R1401	NRSA6AJ-105W	MG RESISTOR 1MΩ,1/16W
	R1402	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1403	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1404	NRSA6AJ-472W	MG RESISTOR 4.7kΩ,1/16W
	R1405	NRSA6AJ-332W	MG RESISTOR 3.3kΩ,1/16W
	R1406	NRSA6AJ-332W	MG RESISTOR 3.3kΩ,1/16W
	R1407	NRSA6AJ-332W	MG RESISTOR 3.3kΩ,1/16W
	R1408	NRSA6AD-753W	MG RESISTOR 75kΩ,1/16W
	R1409	NRSA6AJ-334W	MG RESISTOR 330kΩ,1/16W
	R1411	NRSA6AJ-332W	MG RESISTOR 3.3kΩ,1/16W
	R1412	NRSA6AJ-332W	MG RESISTOR 3.3kΩ,1/16W
	R1413	NRSA6AJ-332W	MG RESISTOR 3.3kΩ,1/16W
	R1414	NRSA6AJ-332W	MG RESISTOR 3.3kΩ,1/16W
	R1415	NRSA6AJ-472W	MG RESISTOR,E,F,G 4.7kΩ,1/16W
	R1416	NRSA6AJ-472W	MG RESISTOR,E,F,G 4.7kΩ,1/16W
	R1417	NRSA6AJ-101W	MG RESISTOR 100Ω,1/16W
	R1420	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1421	NRSA6AJ-103W	MG RESISTOR 10kΩ,1/16W
	R1422	NRSA6AJ-153W	MG RESISTOR 15kΩ,1/16W
	R1423	NRSA6AJ-820W	MG RESISTOR 82Ω,1/16W
	R1424	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1425	NRSA6AJ-473W	MG RESISTOR 47kΩ,1/16W
	R1427	NRSA6AJ-104W	MG RESISTOR,A,B 100kΩ,1/16W
	R1601	NRSA6AJ-681W	MG RESISTOR 680Ω,1/16W
	R1602	NRSA6AJ-124W	MG RESISTOR 120kΩ,1/16W
	R1603	NRSA6AJ-472W	MG RESISTOR 4.7kΩ,1/16W
	R1604	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1605	NRV142F-R22X	CMF RESISTOR 0.22Ω,1/4W
	R1609	NRV142F-R33X	CMF RESISTOR 0.33Ω,1/4W
	R1610	NRSA6AJ-471W	MG RESISTOR 470Ω,1/16W
	R1611	NRSA6AJ-471W	MG RESISTOR 470Ω,1/16W
	R1612	NRSA6AJ-104W	MG RESISTOR 100kΩ,1/16W
	R1613	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1614	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1615	NRSA6AJ-102W	MG RESISTOR 1kΩ,1/16W
	R1616	NRSA6AJ-391W	MG RESISTOR 390Ω,1/16W
	R1617	NRSA6AJ-683W	MG RESISTOR 68kΩ,1/16W

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
R1618	NRSA6AJ-683W	MG RESISTOR	68kΩ,1/16W
R1619	NRSA6AJ-393W	MG RESISTOR	39kΩ,1/16W
R1620	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R1621	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R1622	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R1624	NRVA6AD-123W	CMF RESISTOR	12kΩ,1/16W
R1625	NRSA6AJ-181W	MG RESISTOR	180Ω,1/16W
R1626	NRSA6AJ-181W	MG RESISTOR	180Ω,1/16W
R1628	NRVA6AD-271W	CMF RESISTOR	270Ω,1/16W
R1629	NRSA6AJ-564W	MG RESISTOR	560kΩ,1/16W
R1630	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R1631	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R1635	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R1636	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R1637	NRSA6AJ-154W	MG RESISTOR	150kΩ,1/16W
R2001	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R2004	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R2006	NRSA6AJ-100W	MG RESISTOR	10Ω,1/16W
R2007	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R2008	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R2009	NRSA6AJ-332W	MG RESISTOR	3.3kΩ,1/16W
R2014	NRSA6AJ-820W	MG RESISTOR	82Ω,1/16W
R2015	NRSA6AJ-820W	MG RESISTOR	82Ω,1/16W
R2016	NRSA6AJ-820W	MG RESISTOR	82Ω,1/16W
R2017	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R2018	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R2019	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω,1/16W
R2020	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω,1/16W
R2023	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R2024	NRSA6AJ-183W	MG RESISTOR	18kΩ,1/16W
R2025	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R2028	NRSA6AJ-224W	MG RESISTOR	220kΩ,1/16W
R2029	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R2103	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R2104	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R2105	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R2106	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R2107	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R2108	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R2109	NRSA6AJ-182W	MG RESISTOR	1.8kΩ,1/16W
R2110	NRSA6AJ-182W	MG RESISTOR	1.8kΩ,1/16W
R2111	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R2112	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R2113	NRSA6AJ-222W	MG RESISTOR	2.2kΩ,1/16W
R2114	NRSA6AJ-222W	MG RESISTOR	2.2kΩ,1/16W
R2115	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R2116	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R2117	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R2118	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R2119	NRSA6AJ-332W	MG RESISTOR	3.3kΩ,1/16W
R2120	NRSA6AJ-332W	MG RESISTOR	3.3kΩ,1/16W
R2121	NRSA6AJ-473W	MG RESISTOR	47kΩ,1/16W
R2122	NRSA6AJ-473W	MG RESISTOR	47kΩ,1/16W
R2123	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R2124	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R2127	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R2128	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R2201	NRSA6AJ-122W	MG RESISTOR	1.2kΩ,1/16W
R2202	NRSA6AJ-122W	MG RESISTOR	1.2kΩ,1/16W
R3002	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3004	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3005	NRSA6AJ-100W	MG RESISTOR	10Ω,1/16W
R3006	NRSA6AJ-100W	MG RESISTOR	10Ω,1/16W

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
R3007	NRSA6AJ-562W	MG RESISTOR	5.6kΩ,1/16W
R3008	NRSA6AJ-222W	MG RESISTOR	2.2kΩ,1/16W
R3009	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3010	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3011	NRSA6AJ-224W	MG RESISTOR	220kΩ,1/16W
R3013	NRSA6AJ-242W	MG RESISTOR	2.4kΩ,1/16W
R3014	NRSA6AJ-392W	MG RESISTOR	3.9kΩ,1/16W
R3015	NRSA6AJ-392W	MG RESISTOR	3.9kΩ,1/16W
R3016	NRVA6AD-560W	CMF RESISTOR	56Ω,1/16W
R3017	NRVA6AD-560W	CMF RESISTOR	56Ω,1/16W
R3018	NRVA6AD-560W	CMF RESISTOR	56Ω,1/16W
R3019	NRVA6AD-560W	CMF RESISTOR	56Ω,1/16W
R3020	NRVA6AD-512W	CMF RESISTOR	5.1kΩ,1/16W
R3025	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R3027	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3029	NRSA6AJ-682W	MG RESISTOR	6.8kΩ,1/16W
R3030	NRSA6AJ-224W	MG RESISTOR	220kΩ,1/16W
R3031	NRSA6AJ-224W	MG RESISTOR	220kΩ,1/16W
R3032	NRSA6AJ-105W	MG RESISTOR	1MΩ,1/16W
R3033	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3034	NRSA6AJ-222W	MG RESISTOR	2.2kΩ,1/16W
R3036	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3037	NRSA6AJ-681W	MG RESISTOR	680Ω,1/16W
R3050	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R3051	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R3057	NRSA6AJ-100W	MG RESISTOR	10Ω,1/16W
R3059	NRSA6AJ-101W	MG RESISTOR	100Ω,1/16W
R3066	NRSA6AJ-561W	MG RESISTOR	560Ω,1/16W
R3067	NRSA6AJ-561W	MG RESISTOR	560Ω,1/16W
R3068	NRSA6AJ-271W	MG RESISTOR	270Ω,1/16W
R3069	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R3071	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R3074	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3501	NRSA6AJ-471W	MG RESISTOR	470Ω,1/16W
R3502	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R3503	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R3504	NRSA6AD-241W	MG RESISTOR	240Ω,1/16W
R3505	NRSA6AD-241W	MG RESISTOR	240Ω,1/16W
R3506	NRSA6AD-241W	MG RESISTOR	240Ω,1/16W
R3507	NRSA6AD-241W	MG RESISTOR	240Ω,1/16W
R3508	NRSA6AJ-223W	MG RESISTOR	22kΩ,1/16W
R3511	NRSA6AJ-101W	MG RESISTOR	100Ω,1/16W
R3521	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R3522	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R3701	NRSA6AD-241W	MG RESISTOR	240Ω,1/16W
R3702	NRSA6AD-241W	MG RESISTOR	240Ω,1/16W
R3703	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R3706	NRSA6AD-221W	MG RESISTOR	220Ω,1/16W
R3707	NRSA6AD-221W	MG RESISTOR	220Ω,1/16W
R3708	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R3711	NRSA6AD-680W	MG RESISTOR	68Ω,1/16W
R3712	NRSA6AD-680W	MG RESISTOR	68Ω,1/16W
R3713	NRSA6AD-680W	MG RESISTOR	68Ω,1/16W
R3714	NRSA6AJ-123W	MG RESISTOR	12kΩ,1/16W
R3715	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3717	NRSA6AJ-561W	MG RESISTOR	560Ω,1/16W
R3718	NRSA6AJ-561W	MG RESISTOR	560Ω,1/16W
R3719	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R3724	NRSA6AJ-392W	MG RESISTOR	3.9kΩ,1/16W
R4202	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4203	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4205	NRSA6AJ-333W	MG RESISTOR	33kΩ,1/16W
R4206	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
R4207	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4208	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4301	NRSA6AJ-101W	MG RESISTOR	100Ω,1/16W
R4302	NRSA6AJ-221W	MG RESISTOR,E,F,G	220Ω,1/16W
R4303	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4305	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4307	NRSA6AD-333W	MG RESISTOR	33kΩ,1/16W
R4308	NRSA6AD-682W	MG RESISTOR	6.8kΩ,1/16W
R4309	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4311	NRSA6AD-272W	MG RESISTOR	2.7kΩ,1/16W
R4312	NRSA6AD-272W	MG RESISTOR	2.7kΩ,1/16W
R4313	NRSA6AD-272W	MG RESISTOR	2.7kΩ,1/16W
R4314	NRSA6AD-123W	MG RESISTOR	12kΩ,1/16W
R4315	NRSA6AD-103W	MG RESISTOR	10kΩ,1/16W
R4316	NRSA6AD-131W	MG RESISTOR	130Ω,1/16W
R4317	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4318	NRSA6AJ-152W	MG RESISTOR	1.5kΩ,1/16W
R4319	NRSA6AD-131W	MG RESISTOR	130Ω,1/16W
R4320	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4321	NRSA6AJ-152W	MG RESISTOR	1.5kΩ,1/16W
R4322	NRSA6AD-131W	MG RESISTOR	130Ω,1/16W
R4323	NRSA6AD-820W	MG RESISTOR	82Ω,1/16W
R4324	NRSA6AJ-152W	MG RESISTOR	1.5kΩ,1/16W
R4326	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4327	NRSA6AJ-152W	MG RESISTOR	1.5kΩ,1/16W
R4328	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4329	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4333	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4336	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4337	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4338	NRSA6AJ-220W	MG RESISTOR	22Ω,1/16W
R4339	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4340	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4341	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4343	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4344	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4346	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R4347	NRSA6AJ-223W	MG RESISTOR	22kΩ,1/16W
R4348	NRSA6AJ-223W	MG RESISTOR	22kΩ,1/16W
R4349	NRSA6AJ-223W	MG RESISTOR	22kΩ,1/16W
R4350	NRSA6AJ-223W	MG RESISTOR	22kΩ,1/16W
R4351	NRSA6AJ-223W	MG RESISTOR	22kΩ,1/16W
R4804	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4805	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R4806	NRSA6AJ-683W	MG RESISTOR	68kΩ,1/16W
R4807	NRSA6AJ-823W	MG RESISTOR	82kΩ,1/16W
R4808	NRSA6AJ-243W	MG RESISTOR	24kΩ,1/16W
R4809	NRSA6AJ-681W	MG RESISTOR	680Ω,1/16W
R4810	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R4811	NRSA6AJ-824W	MG RESISTOR	820kΩ,1/16W
R4812	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R4814	NRSA6AJ-105W	MG RESISTOR	1MΩ,1/16W
R4815	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R4816	NRSA6AJ-105W	MG RESISTOR	1MΩ,1/16W
R4817	NRSA6AJ-334W	MG RESISTOR	330kΩ,1/16W
R4818	NRSA6AJ-154W	MG RESISTOR	150kΩ,1/16W
R4819	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R4820	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R4821	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R4822	NRSA6AJ-333W	MG RESISTOR	33kΩ,1/16W
R4823	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4824	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R4825	NRSA6AJ-222W	MG RESISTOR,E,F,G	2.2kΩ,1/16W
R4826	NRSA6AJ-473W	MG RESISTOR,E,F,G	47kΩ,1/16W
R4827	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4828	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4833	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R4836	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4837	NRSA6AJ-0R0W	MG RESISTOR,E,F,G	0Ω,1/16W
R4841	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4842	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4843	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4844	NRSA6AJ-151W	MG RESISTOR	150Ω,1/16W
R4846	NRSA6AJ-0R0W	MG RESISTOR,E,F,G	0Ω,1/16W
R4854	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4856	NRSA63J-6R8X	MG RESISTOR	6.8Ω,1/16W
R4857	NRSA63J-6R8X	MG RESISTOR	6.8Ω,1/16W
R4858	NRSA6AJ-333W	MG RESISTOR	33kΩ,1/16W
R4859	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4860	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4862	NRSA63J-6R8X	MG RESISTOR	6.8Ω,1/16W
R4863	NRSA63J-6R8X	MG RESISTOR	6.8Ω,1/16W
R4864	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4865	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4866	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4867	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R4868	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4870	NRSA6AJ-271W	MG RESISTOR	270Ω,1/16W
R4871	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R4874	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R5501	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R5503	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R5504	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R5505	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R5506	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R5507	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R5509	NRSA6AJ-470W	MG RESISTOR	47Ω,1/16W
R5510	NRSA6AJ-470W	MG RESISTOR	47Ω,1/16W
R5511	NRSA6AJ-470W	MG RESISTOR	47Ω,1/16W
R5512	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R5513	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R5514	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R6001	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R6002	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R6003	NRSA6AJ-224W	MG RESISTOR	220kΩ,1/16W
R6004	NRSA6AJ-183W	MG RESISTOR	18kΩ,1/16W
R6005	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
⚠ R6009	NRSA63J-102X	MG RESISTOR	1kΩ,1/16W
R6010	NRSA6AJ-473W	MG RESISTOR	47kΩ,1/16W
R6011	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R6012	NRVA6AD-104W	CMF RESISTOR	100kΩ,1/16W
R6013	NRVA6AD-683W	CMF RESISTOR	68kΩ,1/16W
R6101	NRVA6AD-103W	CMF RESISTOR	10kΩ,1/16W
R6102	NRVA6AD-751W	CMF RESISTOR	750Ω,1/16W
R6103	NRVA6AD-103W	CMF RESISTOR	10kΩ,1/16W
R6106	NRSA6AJ-333W	MG RESISTOR	33kΩ,1/16W
R6107	NRVA6AD-562W	CMF RESISTOR	5.6kΩ,1/16W
R6108	NRSA6AJ-223W	MG RESISTOR	22kΩ,1/16W
R6113	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R6114	NRSA6AJ-823W	MG RESISTOR	82kΩ,1/16W
R6115	NRSA6AJ-823W	MG RESISTOR	82kΩ,1/16W
R6116	NRVA6AD-153W	CMF RESISTOR	15kΩ,1/16W
R6117	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R6118	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R6124	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R6201	NRVA6AD-223W	CMF RESISTOR	22kΩ,1/16W

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
R6202	NRSA6AJ-474W	MG RESISTOR	470kΩ,1/16W
R6203	NRVA6AD-103W	CMF RESISTOR	10kΩ,1/16W
R6204	NRSA6AJ-473W	MG RESISTOR	47kΩ,1/16W
R6205	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R6206	NRVA6AD-183W	CMF RESISTOR	18kΩ,1/16W
R6207	NRVA6AD-123W	CMF RESISTOR	12kΩ,1/16W
R6208	NRVA6AD-123W	CMF RESISTOR	12kΩ,1/16W
R6209	NRVA6AD-153W	CMF RESISTOR	15kΩ,1/16W
R6210	NRVA6AD-183W	CMF RESISTOR	18kΩ,1/16W
R6212	NRVA6AD-472W	CMF RESISTOR	4.7kΩ,1/16W
R6213	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R6214	NRSA6AJ-152W	MG RESISTOR	1.5kΩ,1/16W
R6215	NRSA6AJ-473W	MG RESISTOR	47kΩ,1/16W
R6217	NRSA6AJ-151W	MG RESISTOR,B,E,F,G	150Ω,1/16W
R6218	NRSA6AJ-104W	MG RESISTOR,B,E,F,G	100kΩ,1/16W
R6219	NRVA6AD-243W	CMF RESISTOR	24kΩ,1/16W
R6220	NRVA6AD-302W	CMF RESISTOR	3kΩ,1/16W
R6221	NRVA6AD-104W	CMF RESISTOR	100kΩ,1/16W
R6222	NRVA6AD-103W	CMF RESISTOR	10kΩ,1/16W
R6223	NRVA6AD-123W	CMF RESISTOR	12kΩ,1/16W
R6224	NRVA6AD-473W	CMF RESISTOR	47kΩ,1/16W
R6225	NRVA6AD-562W	CMF RESISTOR	5.6kΩ,1/16W
R6226	NRVA6AD-223W	CMF RESISTOR	22kΩ,1/16W
R6227	NRVA6AD-473W	CMF RESISTOR	47kΩ,1/16W
R6228	NRVA6AD-473W	CMF RESISTOR	47kΩ,1/16W
R6229	NRVA6AD-332W	CMF RESISTOR	3.3kΩ,1/16W
R6230	NRSA6AJ-272W	MG RESISTOR	2.7kΩ,1/16W
R6231	NRVA6AD-104W	CMF RESISTOR	100kΩ,1/16W
R6232	NRVA6AD-473W	CMF RESISTOR	47kΩ,1/16W
R6233	NRSA6AJ-822W	MG RESISTOR	8.2kΩ,1/16W
R6234	NRSA6AJ-273W	MG RESISTOR	27kΩ,1/16W
R6235	NRVA6AD-683W	CMF RESISTOR	68kΩ,1/16W
R6236	NRVA6AD-473W	CMF RESISTOR	47kΩ,1/16W
R6237	NRVA6AD-753W	CMF RESISTOR	75kΩ,1/16W
R6238	NRVA6AD-104W	CMF RESISTOR	100kΩ,1/16W
R6239	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R6240	NRSA6AJ-333W	MG RESISTOR	33kΩ,1/16W
R6241	NRSA6AJ-102W	MG RESISTOR	1kΩ,1/16W
R6242	NRSA6AJ-104W	MG RESISTOR	100kΩ,1/16W
R6243	NRSA6AJ-823W	MG RESISTOR	82kΩ,1/16W
R6244	NRSA6AJ-152W	MG RESISTOR,B,E,F,G	1.5kΩ,1/16W
R6245	NRSA6AJ-562W	MG RESISTOR,B,E,F,G	5.6kΩ,1/16W
R6246	NRSA6AJ-222W	MG RESISTOR,B,E,F,G	2.2kΩ,1/16W
R6701	NRZ0058-R20X	MG RESISTOR	0.2Ω,1/2W
R6702	NRVA6AD-104W	CMF RESISTOR	100kΩ,1/16W
R6703	NRVA6AD-123W	CMF RESISTOR	12kΩ,1/16W
R6704	NRVA6AD-823W	CMF RESISTOR	82kΩ,1/16W
R6705	NRVA6AD-333W	CMF RESISTOR	33kΩ,1/16W
RA1008	NRZ0034-104W	NETWORK RESISTOR	100kΩ
RA1009	NRZ0034-104W	NETWORK RESISTOR	100kΩ
RA1010	NRZ0034-104W	NETWORK RESISTOR	100kΩ
RA1401	NRZ0034-473W	NETWORK RESISTOR	47kΩ
RA3001	NRZ0034-100W	NETWORK RESISTOR	10Ω
RA3002	NRZ0034-100W	NETWORK RESISTOR	10Ω
RA3003	NRZ0034-100W	NETWORK RESISTOR	10Ω
RA3004	NRZ0034-103W	NETWORK RESISTOR	10kΩ
RA3005	NRZ0040-0R0X	NETWORK RESISTOR	0Ω
RA4301	NRZ0034-101W	NETWORK RESISTOR	100Ω
RA4302	NRZ0034-101W	NETWORK RESISTOR	100Ω
RA4303	NRZ0034-101W	NETWORK RESISTOR	100Ω
RA4307	NRZ0034-221W	NETWORK RESISTOR,E,F,G	220Ω
RA4308	NRZ0034-221W	NETWORK RESISTOR,E,F,G	220Ω
RA4309	NRZ0034-221W	NETWORK RESISTOR,E,F,G	220Ω
RA4310	NRZ0034-221W	NETWORK RESISTOR,E,F,G	220Ω
C1003	NBE20JM-106X	T CAPACITOR,F,G	10µF,6.3V
C1004	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C1006	NDCA1HJ-130W	CAPACITOR	13pF,50V
C1007	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1009	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1010	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1013	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1014	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1015	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1016	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1017	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1019	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1023	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C1026	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C1027	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1028	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1029	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1030	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1031	NCF31AZ-105X	CAPACITOR	1µF,10V
C1034	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1036	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1037	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1038	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1039	NCFA1HZ-103W	CAPACITOR	0.01µF,50V
C1301	NCFA1AZ-104W	CAPACITOR,A,B	0.1µF,10V
C1302	NCFA1AZ-104W	CAPACITOR,A,B	0.1µF,10V
C1303	NCFA1AZ-104W	CAPACITOR,A,B	0.1µF,10V
C1304	NCFA1AZ-104W	CAPACITOR,A,B	0.1µF,10V
C1305	NCFA1AZ-104W	CAPACITOR,A,B	0.1µF,10V
C1306	NCFA1AZ-104W	CAPACITOR,A,B	0.1µF,10V
C1307	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C1401	NDCA1HJ-150W	CAPACITOR	15pF,50V
C1402	NDCA1HJ-150W	CAPACITOR	15pF,50V
C1403	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C1404	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C1405	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C1406	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C1407	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C1409	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C1410	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C1411	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C1412	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C1413	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C1414	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C1415	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C1416	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C1601	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C1602	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C1603	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C1605	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C1606	NCBA1HK-152W	CAPACITOR	0.0015µF,50V
C1607	NCBA1AK-473W	CAPACITOR	0.047µF,10V
C1614	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C1618	NCBA1HK-222W	CAPACITOR	0.0022µF,50V
C1619	NCBA1HK-222W	CAPACITOR	0.0022µF,50V
C1620	NCBA1HK-222W	CAPACITOR	0.0022µF,50V
C1621	NCB30JK-105X	CAPACITOR	1µF,6.3V
C1622	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C1623	NCBA1AK-473W	CAPACITOR	0.047µF,10V
C1624	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C1625	NCBA1AK-473W	CAPACITOR	0.047µF,10V
C1626	NCBA1HK-331W	CAPACITOR	330pF,50V

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
C1627	NCBA1CK-822W	CAPACITOR	0.0082µF,16V
C1628	NCB21CK-224X	CAPACITOR	0.22µF,16V
C1632	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C1633	NCB21CK-474X	CAPACITOR	0.47µF,16V
C1641	NCB21CK-474X	CAPACITOR	0.47µF,16V
C2001	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C2002	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C2004	NCB21CK-105X	CAPACITOR	1µF,16V
C2005	NCB21CK-105X	CAPACITOR	1µF,16V
C2006	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C2007	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C2008	NCB21CK-105X	CAPACITOR	1µF,16V
C2009	NCB21CK-105X	CAPACITOR	1µF,16V
C2010	NCB21CK-105X	CAPACITOR	1µF,16V
C2011	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C2012	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C2013	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C2014	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C2015	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C2016	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2017	NCBA1AK-333W	CAPACITOR	0.033µF,10V
C2018	NCB31CK-104X	CAPACITOR	0.1µF,16V
C2019	NCB31CK-104X	CAPACITOR	0.1µF,16V
C2020	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C2021	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C2024	NCB21CK-105X	CAPACITOR	1µF,16V
C2025	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C2103	NCB21CK-105X	CAPACITOR	1µF,16V
C2104	NCB21CK-105X	CAPACITOR	1µF,16V
C2109	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C2110	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C2111	NCB31CK-104X	CAPACITOR	0.1µF,16V
C2112	NCB31CK-104X	CAPACITOR	0.1µF,16V
C2115	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2116	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2117	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2118	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2119	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2120	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2121	NCBA1EK-472W	CAPACITOR	0.0047µF,25V
C2122	NCBA1EK-472W	CAPACITOR	0.0047µF,25V
C2123	NCBA1EK-472W	CAPACITOR	0.0047µF,25V
C2124	NCBA1EK-472W	CAPACITOR	0.0047µF,25V
C2125	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2126	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C2127	NCB31CK-104X	CAPACITOR	0.1µF,16V
C2128	NCB31CK-104X	CAPACITOR	0.1µF,16V
C2201	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C2202	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3001	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C3003	NCB30JK-105X	CAPACITOR	1µF,6.3V
C3005	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C3006	NCB30JK-105X	CAPACITOR	1µF,6.3V
C3007	NCB10JK-106X	CAPACITOR	10µF,6.3V
C3008	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C3009	NCB30JK-105X	CAPACITOR	1µF,6.3V
C3011	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3012	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3013	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3015	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3016	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3017	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3020	NCBA1AK-104W	CAPACITOR	0.1µF,10V

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
C3021	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3022	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3023	NDCA1HJ-330W	CAPACITOR	33pF,50V
C3024	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C3025	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3026	NCB30JK-105X	CAPACITOR	1µF,6.3V
C3027	NCBA1EK-472W	CAPACITOR	0.0047µF,25V
C3028	NDCA1EJ-271W	CAPACITOR	270pF,25V
C3029	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3030	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3031	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3032	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C3033	NDCA1HJ-8R0W	CAPACITOR	8pF,50V
C3036	NDCA1HJ-8R0W	CAPACITOR	8pF,50V
C3037	NDCA1HJ-8R0W	CAPACITOR	8pF,50V
C3038	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3039	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3042	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3043	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3044	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3045	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3046	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3048	NCB31CK-473X	CAPACITOR	0.047µF,16V
C3049	NCBA1HK-222W	CAPACITOR	0.0022µF,50V
C3050	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3055	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3064	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C3066	NCB30JK-105X	CAPACITOR	1µF,6.3V
C3067	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C3069	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3501	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C3502	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C3503	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C3504	NCBA1AK-473W	CAPACITOR	0.047µF,10V
C3505	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C3506	NCB21AK-105X	CAPACITOR	1µF,10V
C3507	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3508	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3509	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3510	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3511	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3512	NCB31CK-104X	CAPACITOR	0.1µF,16V
C3513	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3514	NCBA1AK-473W	CAPACITOR	0.047µF,10V
C3515	NCBA1AK-473W	CAPACITOR	0.047µF,10V
C3516	NCBA1AK-473W	CAPACITOR	0.047µF,10V
C3517	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3518	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3519	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C3520	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3521	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C3522	NCB20JM-475X	CAPACITOR	4.7µF,6.3V
C3523	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3524	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3525	NCB20JM-475X	CAPACITOR	4.7µF,6.3V
C3526	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3527	NDCA1EJ-221W	CAPACITOR	220pF,25V
C3528	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3701	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C3702	NDCA1HJ-151W	CAPACITOR	150pF,50V
C3703	NDCA1HJ-330W	CAPACITOR	33pF,50V
C3704	NDCA1HJ-101W	CAPACITOR	100pF,50V
C3705	NDCA1HJ-330W	CAPACITOR	33pF,50V

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
C3706	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3707	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C3708	NCB30JK-105X	CAPACITOR	1µF,6.3V
C3709	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3710	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C3712	NEA70GM-337X	E CAPACITOR	330µF,4.0V
C3713	NEA70GM-337X	E CAPACITOR	330µF,4.0V
C4201	NBE40GM-107X	T CAPACITOR	100µF,4.0V
C4202	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4203	NCB30JK-105X	CAPACITOR	1µF,6.3V
C4204	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4205	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4206	NCB21CK-105X	CAPACITOR	1µF,16V
C4207	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4208	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4209	NCB30JK-105X	CAPACITOR	1µF,6.3V
C4210	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4211	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4212	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4213	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4214	NCB30JK-105X	CAPACITOR,A,B,E	1µF,6.3V
	NCBA1AK-104W	CAPACITOR,F,G	0.1µF,10V
C4215	NCB30JK-105X	CAPACITOR,A,B,E	1µF,6.3V
	NCBA1AK-104W	CAPACITOR,F,G	0.1µF,10V
C4216	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4217	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4218	NCB30JK-105X	CAPACITOR,A,B,E	1µF,6.3V
C4301	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4303	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4304	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4305	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4306	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4307	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4308	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4309	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4310	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4311	NCB30JK-105X	CAPACITOR	1µF,6.3V
C4312	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4313	NBE20JM-226X	T CAPACITOR	22µF,6.3V
C4314	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4315	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4317	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4318	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4319	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4320	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4321	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4323	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4324	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4325	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4327	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4328	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4329	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4330	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4331	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4332	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4333	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4334	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4335	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4336	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4337	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4338	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4339	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4340	NCBA1AK-104W	CAPACITOR	0.1µF,10V

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
C4341	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4342	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4343	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4344	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4345	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4346	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4347	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4348	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4349	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4350	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C4803	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4804	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C4806	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C4808	NCB30JK-105X	CAPACITOR	1µF,6.3V
C4809	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C4810	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C4811	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C4812	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C4813	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C4814	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C4815	NCB31HK-152X	CAPACITOR	0.0015µF,50V
C4819	NCB31CK-104X	CAPACITOR	0.1µF,16V
C4824	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C4851	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4852	NCFA1AZ-104W	CAPACITOR	0.1µF,10V
C4853	NBE21AM-335X	T CAPACITOR	3.3µF,10V
C4854	NBE21AM-106X	T CAPACITOR	10µF,10V
C4855	NCB31CK-104X	CAPACITOR	0.1µF,16V
C4858	NDCA1HJ-330W	CAPACITOR	33pF,50V
C4859	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C4860	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C4861	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C4862	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C4864	NBE20JM-106X	T CAPACITOR	10µF,6.3V
C4865	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5501	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5503	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5504	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5505	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5506	NBE40GM-476X	T CAPACITOR	47µF,4.0V
C5507	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5508	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5509	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5510	NBP21VM-105X	T CAPACITOR	1µF,35V
C5511	NBP21DM-475X	T CAPACITOR	4.7µF,20V
C5512	NBE21AM-106X	T CAPACITOR	10µF,10V
C5513	NCB31CK-104X	CAPACITOR	0.1µF,16V
C5514	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5515	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5516	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5517	NCB31CK-104X	CAPACITOR	0.1µF,16V
C5518	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C5519	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6001	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C6004	NCB30JK-105X	CAPACITOR	1µF,6.3V
C6005	NDCA1HJ-101W	CAPACITOR	100pF,50V
C6101	NCB21CK-105X	CAPACITOR	1µF,16V
C6102	NEA71CM-106X	E CAPACITOR	10µF,16V
C6103	NCB21CK-105X	CAPACITOR	1µF,16V
C6105	NCB21CK-105X	CAPACITOR	1µF,16V
C6106	NCB30JK-105X	CAPACITOR	1µF,6.3V
C6107	NCB30JK-105X	CAPACITOR	1µF,6.3V
C6108	NCB30JK-105X	CAPACITOR	1µF,6.3V

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
C6109	NCB30JK-105X	CAPACITOR	1µF,6.3V
C6110	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6111	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6112	NCBA1AK-333W	CAPACITOR	0.033µF,10V
C6113	NCBA1HK-561W	CAPACITOR	560pF,50V
C6114	NCBA1HK-272W	CAPACITOR	0.0027µF,50V
C6115	NCBA1HK-561W	CAPACITOR	560pF,50V
C6116	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C6117	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6118	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6119	NDCA1HJ-101W	CAPACITOR	100pF,50V
C6120	NCB30JK-105X	CAPACITOR	1µF,6.3V
C6121	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6122	NCBA1CK-223W	CAPACITOR	0.022µF,16V
C6123	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C6124	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C6125	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C6126	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C6127	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C6128	NCB21CK-105X	CAPACITOR	1µF,16V
C6129	NCBA1HK-561W	CAPACITOR	560pF,50V
C6130	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6131	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6132	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6134	NCBA1AK-104W	CAPACITOR	0.1µF,10V
C6201	NCB21CK-105X	CAPACITOR	1µF,16V
C6202	NCB10JK-106X	CAPACITOR	10µF,6.3V
C6203	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C6204	NCBA1HK-561W	CAPACITOR	560pF,50V
C6205	NCB30JK-105X	CAPACITOR	1µF,6.3V
C6206	NCB21CK-105X	CAPACITOR	1µF,16V
C6207	NCB10JK-106X	CAPACITOR	10µF,6.3V
C6208	NCBA1EK-472W	CAPACITOR	0.0047µF,25V
C6209	NCB21CK-105X	CAPACITOR	1µF,16V
C6210	NCB10JK-106X	CAPACITOR	10µF,6.3V
C6211	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C6212	NCB21CK-105X	CAPACITOR,B,E,F,G	1µF,16V
C6213	NCB30JK-105X	CAPACITOR,B,E,F,G	1µF,6.3V
C6214	NCB21CK-105X	CAPACITOR	1µF,16V
C6215	NCB21CK-105X	CAPACITOR	1µF,16V
C6216	NCBA1AK-683W	CAPACITOR	0.068µF,10V
C6217	NCB21CK-105X	CAPACITOR	1µF,16V
C6218	NCB21CK-105X	CAPACITOR	1µF,16V
C6219	NCB21CK-224X	CAPACITOR	0.22µF,16V
C6220	NCB21CK-105X	CAPACITOR	1µF,16V
C6221	NCB11EK-105X	CAPACITOR	1µF,25V
C6222	NCB11EK-105X	CAPACITOR	1µF,25V
C6224	NCBA1HK-102W	CAPACITOR	0.001µF,50V
C6225	NCBA1CK-103W	CAPACITOR	0.01µF,16V
C6226	NCB21CK-105X	CAPACITOR	1µF,16V
C6227	NCB11EK-105X	CAPACITOR	1µF,25V
C6228	NCB11EK-105X	CAPACITOR	1µF,25V
C6230	NCB21CK-105X	CAPACITOR	1µF,16V
C6231	NCBA1CK-103W	CAPACITOR,B,E,F,G	0.01µF,16V
C6701	NCB21CK-105X	CAPACITOR	1µF,16V
C6703	NCB21CK-105X	CAPACITOR	1µF,16V
L1002	NQL315K-100X	COIL	10µH
L1401	NQR0006-001X	FERRITE BEAD	
L2001	NQL315K-100X	COIL	10µH
L2002	NQL38DK-220X	COIL	22µH
L2101	NQR0269-013X	FERRITE BEAD	
L2102	NQR0269-013X	FERRITE BEAD	
L2103	NQR0269-013X	FERRITE BEAD	

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
L3001	NQR0129-002X	FERRITE BEAD	
L3002	NQR0129-002X	FERRITE BEAD	
L3004	NQR0006-001X	FERRITE BEAD	
L3005	NQR0006-001X	FERRITE BEAD	
L3007	NQL085J-2R2X	COIL	2.2µH
L3008	NQL085J-120X	COIL	12µH
L3012	NQR0129-002X	FERRITE BEAD	
L3015	NQR0006-001X	FERRITE BEAD	
L3501	NQR0129-002X	FERRITE BEAD	
L3502	NQL402M-100X	COIL	10µH
L3503	NQR0006-001X	FERRITE BEAD	
L3504	NQR0006-001X	FERRITE BEAD	
L3505	NQR0006-001X	FERRITE BEAD	
L3701	NQL38DK-100X	COIL	10µH
L4201	NQR0129-002X	FERRITE BEAD	
L4301	NQR0129-002X	FERRITE BEAD	
L4302	NQR0129-002X	FERRITE BEAD	
L4303	NQL315K-100X	COIL	10µH
L4304	NQL315K-220X	COIL	22µH
L4305	NQR0129-002X	FERRITE BEAD	
L4306	NQR0129-002X	FERRITE BEAD	
L4307	NQL315K-100X	COIL	10µH
L4802	NQL302N-100X	COIL	10µH
L4851	NQR0129-002X	FERRITE BEAD	
L4852	NQL315K-100X	COIL	10µH
L4853	NQL315K-100X	COIL	10µH
L5501	NQL315K-100X	COIL	10µH
L5502	NQR0129-002X	FERRITE BEAD	
L5503	NQR0129-002X	FERRITE BEAD	
L5504	NQR0129-002X	FERRITE BEAD	
L5505	NQL315K-100X	COIL	10µH
L5506	NQL315K-100X	COIL	10µH
L6101	NQLZ011-4R7X	COIL	4.7µH
L6102	NQLZ011-4R7X	COIL	4.7µH
L6201	NQL52EM-390X	COIL	39µH
L6202	NQL52EM-390X	COIL	39µH
L6203	NQL52EM-390X	COIL	39µH
L6204	NQL144K-220X	COIL	22µH
L6205	NQL64EM-220X	COIL,B,E,F,G	22µH
L6206	NQLZ011-470X	COIL	47µH
L6207	NQLZ011-470X	COIL	47µH
L6208	NQLZ011-221X	COIL	220µH
L6701	NQLZ010-100X	COIL	10µH
X1001	NAX0474-001X	C OSCILLATOR	
X1002	NAX0325-001X	CRYSTAL RESONATOR	
X1401	NAX0204-001X	CRYSTAL RESONATOR	
X3002	NAX0480-001X	CRYSTAL RESONATOR	
X5501	NAX0356-001X	CXO	
WR1	WJT0065-001A	E-CARD WIRE,CN102-JACK CN502	
WR2	WJJ0268-001A	E-SI C WIRE C-C,CN104-REAR CN552	
WR3	WJM0291-001A	E-S1 C WIRE C-F,C5506-CCD WR1	
CN101	QGF0508F1-40X	FPC CONNECTOR	
CN102	QGF0505F2-24X	FPC CONNECTOR	
CN103	QGF0503C1-12V	FFC/FPC CONNECTOR	
CN104	QGA1002C1-06X	CONNECTOR	
CN105	QGB0801K2-30X	CONNECTOR	
CN106	QGA1201C2-07X	CONNECTOR	
CN107	QGF0503C1-20X	FFC/FPC CONNECTOR	
CN108	QGF0512C1-24X	FPC CONNECTOR	
CN109	QGF0507F3-15X	FFC/FPC CONNECTOR,A,B	
	QGF0507F4-15X	FFC/FPC CONNECTOR,E,F,G	
CN110	QGF0505F1-08X	FPC CONNECTOR	
CN111	QGB0501L1-80X	CONNECTOR,E,F,G	

# ⚠	REF No.	PART No.	PART NAME, DESCRIPTION	
	CN112	QGF0505F2-18X	FPC CONNECTOR	
	CN113	QGF0508F1-33X	FPC CONNECTOR	
⚠	F6101	NMFZ007-2R0X-K	FUSE	T2.0A,50V
	OT1	LY43491-001A	SHEET(MAIN)	
	OT2	LY43549-001A	SHEET(MECHA)	
	SD1	LY32080-001A	SHIELD CASE	

TA E BOARD ASSY(A,B,E)

PW2	YB20932A	TA E BOARD ASSY	
C1	NE20JM-106X	T CAPACITOR	10µF,6.3V
J1	YU40017-045-8	THIN WIRE,RA1009 1-4 PIN	
J2	YU40017-020-1	THIN WIRE,CN111 1,2 PIN	
OT1	PU59915-105	#500 SPACER 0.01	
OT2	LY30029-0U4A	SPACER(A)	

****

MONITOR BOARD ASSEMBLY <02>

PW	YB10360A-02	MONITOR BOARD ASSY,A	
	YB10360B-02	MONITOR BOARD ASSY,B	
	YB10360D-02	MONITOR BOARD ASSY,G	
	YB10360G-02	MONITOR BOARD ASSY,E,F	
IC7101	TC7SH32FU	IC(DIGITAL)	
IC7601	AN2540FHQ	IC	
IC7602	BA4558F	IC	
IC7603	AT25040N-10SC-X	IC	
	or 25LC040-I/SN-X	IC	
IC7604	SN74LV08APW	IC	
Q7101	2SA1774/QR/-X	TRANSISTOR	
	or 2SA1832/YG/-X	TRANSISTOR,A,B,G	
Q7102	2SC4617/QR/-X	TRANSISTOR	
Q7601	2SC4617/QR/-X	TRANSISTOR	
	or 2SC4738/YG/-X	TRANSISTOR	
	or 2SD2216J/QR/-X	TRANSISTOR	
Q7602	2SA1774/QR/-X	TRANSISTOR	
	or 2SA1832/YG/-X	TRANSISTOR	
Q7603	2SC4617/QR/-X	TRANSISTOR	
	or 2SC4738/YG/-X	TRANSISTOR	
	or 2SD2216J/QR/-X	TRANSISTOR	
Q7604	2SA1774/QR/-X	TRANSISTOR	
	or 2SA1832/YG/-X	TRANSISTOR	
Q7608	DTC144EE	TRANSISTOR	
	or RN1104	TRANSISTOR	
	or UN9213J	TRANSISTOR	
Q7609	DTC144EE	TRANSISTOR	
	or RN1104	TRANSISTOR	
	or UN9213J	TRANSISTOR	
Q7610	DTA144EE	TRANSISTOR	
	or UN9113J	TRANSISTOR	
	or RN2104	TRANSISTOR	
D1	SML-110MT-X	LE DIODE	
D7601	FC806	SB DIODE	
D7602	UDZS6.8B	ZENER DIODE	
R1	NRSA63J-103X	MG RESISTOR	10kΩ,1/16W
R2	NRSA63J-103X	MG RESISTOR,B,E,F,G	10kΩ,1/16W
R3	NRSA63J-103X	MG RESISTOR	10kΩ,1/16W
R4	NRSA63J-152X	MG RESISTOR	1.5kΩ,1/16W
R5	NRSA63J-182X	MG RESISTOR	1.8kΩ,1/16W
R6	NRSA63J-272X	MG RESISTOR	2.7kΩ,1/16W

# ⚠	REF No.	PART No.	PART NAME, DESCRIPTION	
	R7	NRSA63J-103X	MG RESISTOR,E,F,G	10kΩ,1/16W
	R8	NRSA63J-152X	MG RESISTOR,E,F,G	1.5kΩ,1/16W
	R18	NRSA63J-473X	MG RESISTOR,E,F,G	47kΩ,1/16W
	R19	NRSA63J-103X	MG RESISTOR,E,F,G	10kΩ,1/16W
	R21	NRSA63J-103X	MG RESISTOR,E,F,G	10kΩ,1/16W
	R22	NRSA63J-473X	MG RESISTOR,E,F,G	47kΩ,1/16W
	R23	NRSA63J-104X	MG RESISTOR,E,F,G	100kΩ,1/16W
	R7110	NRSA63J-562X	MG RESISTOR	5.6kΩ,1/16W
	R7111	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
	R7113	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
	R7114	NRSA63J-271X	MG RESISTOR	270Ω,1/16W
	R7116	NRSA63J-102X	MG RESISTOR	1kΩ,1/16W
	R7601	NRVA63D-622X	CMF RESISTOR	6.2kΩ,1/16W
	R7602	NRSA63J-153X	MG RESISTOR	15kΩ,1/16W
	R7603	NRSA63J-683X	MG RESISTOR	68kΩ,1/16W
	R7605	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
	R7606	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
	R7608	NRSA63J-153X	MG RESISTOR	15kΩ,1/16W
	R7609	NRVA63D-223X	CMF RESISTOR	22kΩ,1/16W
	R7610	NRVA63D-433X	CMF RESISTOR	43kΩ,1/16W
	R7611	NRVA63D-821X	CMF RESISTOR	820Ω,1/16W
	R7612	NRVA63D-682X	CMF RESISTOR,G	6.8kΩ,1/16W
		NRVA63D-223X	CMF RESISTOR,A,B,E,F	22kΩ,1/16W
	R7613	NRVA63D-223X	CMF RESISTOR	22kΩ,1/16W
	R7614	NRVA63D-223X	CMF RESISTOR	22kΩ,1/16W
	R7615	NRSA63J-223X	MG RESISTOR	22kΩ,1/16W
	R7616	NRSA63J-223X	MG RESISTOR	22kΩ,1/16W
	R7617	NRSA02J-561X	MG RESISTOR	560Ω,1/10W
	R7618	NRSA02J-561X	MG RESISTOR	560Ω,1/10W
	R7621	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
	R7624	NRVA63D-223X	CMF RESISTOR,G	22kΩ,1/16W
	R7625	NRVA63D-223X	CMF RESISTOR,G	22kΩ,1/16W
	R7630	NRSA63J-223X	MG RESISTOR	22kΩ,1/16W
	R7631	NRSA63J-335X	MG RESISTOR	3.3MΩ,1/16W
	R7633	NRSA63J-103X	MG RESISTOR	10kΩ,1/16W
	R7636	NRSA63J-101X	MG RESISTOR	100Ω,1/16W
	R7637	NRSA63J-101X	MG RESISTOR	100Ω,1/16W
	R7638	NRSA63J-101X	MG RESISTOR	100Ω,1/16W
	R7650	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
	R7652	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
	C1	NCB31EK-103X	CAPACITOR	0.01µF,25V
	C11	NBE20JM-106X	T CAPACITOR,E,F,G	10µF,6.3V
	C7101	NDC31HJ-221X	CAPACITOR	220pF,50V
	C7102	NCF31CZ-104X	CAPACITOR	0.1µF,16V
	C7601	NCB21CK-105X	CAPACITOR	1µF,16V
	C7602	NCB31EK-103X	CAPACITOR	0.01µF,25V
	C7603	NCB11CK-225X	CAPACITOR	2.2µF,16V
	C7604	NCB11CK-225X	CAPACITOR	2.2µF,16V
	C7605	NCB11CK-225X	CAPACITOR	2.2µF,16V
	C7606	NCB31CK-104X	CAPACITOR	0.1µF,16V
	C7607	NCB41CK-106X	CAPACITOR	10µF,16V
	C7608	NCB31EK-103X	CAPACITOR	0.01µF,25V
	C7609	NCB31CK-104X	CAPACITOR	0.1µF,16V
	C7610	NCB11CK-225X	CAPACITOR	2.2µF,16V
	C7611	NCB11CK-225X	CAPACITOR	2.2µF,16V
	C7612	NCB11CK-225X	CAPACITOR	2.2µF,16V
	C7613	NCB11CK-225X	CAPACITOR	2.2µF,16V
	C7614	NCB31HK-152X	CAPACITOR	0.0015µF,50V
	C7615	NCB31EK-103X	CAPACITOR	0.01µF,25V
	C7616	NCB31EK-103X	CAPACITOR	0.01µF,25V
	C7617	NCB31EK-103X	CAPACITOR	0.01µF,25V
	C7618	NCB10JK-106X	CAPACITOR	10µF,6.3V
	C7619	NCB10JK-106X	CAPACITOR	10µF,6.3V

#	⚠	REF No.	PART No.	PART NAME, DESCRIPTION	
		C7620	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7621	NCB21CK-105X	CAPACITOR	1μF,16V
		C7622	NCB21CK-105X	CAPACITOR	1μF,16V
		C7623	NBE21AM-106X	T CAPACITOR	10μF,10V
		C7624	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7626	NCB31CK-104X	CAPACITOR	0.1μF,16V
		C7627	NCF31CZ-104X	CAPACITOR	0.1μF,16V
		C7628	NBP41EM-475X	T CAPACITOR	4.7μF,25V
		C7629	NBP21CM-335X	T CAPACITOR	3.3μF,16V
		C7630	NBP41EM-475X	T CAPACITOR	4.7μF,25V
		C7631	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7632	NBP41EM-475X	T CAPACITOR	4.7μF,25V
		C7633	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7634	NCB11CK-225X	CAPACITOR	2.2μF,16V
		C7635	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7636	NCF31CZ-104X	CAPACITOR,G	0.1μF,16V
		C7637	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7640	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7642	NCF31CZ-104X	CAPACITOR	0.1μF,16V
		L10	NQR0129-002X	FERRITE BEAD,E,F,G	
		L7601	NQL365K-100X	COIL	10μH
		L7602	NQL365K-470X	COIL	47μH
		L7603	NQL365K-100X	COIL	10μH
		L7604	NQL365K-100X	COIL	10μH
		L7605	NQL365K-100X	COIL,A,B,E,F	10μH
		L7606	NQL365K-100X	COIL,G	10μH
		L7607	NQL365K-100X	COIL	10μH
		SW1	NSW0092-001X	SLIDE SWITCH,VIDEO LIGHT,B,E,F,G	
		SW2	NSW0008-001X	TACT SWITCH,STOP/BACKLIGHT	
		SW3	NSW0008-001X	TACT SWITCH,REW/NIGHT	
		SW4	NSW0008-001X	TACT SWITCH,FF	
		SW5	NSW0008-001X	TACT SWITCH,PLAY/PAUSE	
		SW6	NSW0099-001X	SLIDE SWITCH,VIDEO/MEMORY,E,F,G	
		SW7	NSW0160-001X	TACT SWITCH,INFO,E,F,G	
		SW8	NSW0160-001X	TACT SWITCH,INDEX,E,F,G	
		SW7601	QSW0451-001	PUSH SWITCH,MONITOR OPEN	
		J7601	QND0087-001	S JACK	
	⚠	BT1	QAB0025-001	LI BATTERY	
		CN761	QGF0508F1-40X	FPC CONNECTOR	
		CN762	QGF0508F1-10X	FPC CONNECTOR,E,F,G	
		CN763	QGF0507F3-20X	FFC/FPC CONNECTOR	
		CN764	QGF0508F1-33X	FPC CONNECTOR	
		CN765	QGA1201F2-02X	CONNECTOR	
		CN766	NNZ0058-001X	SD CARD CONNECTOR,E,F,G	

****

LCD BL BOARD ASSEMBLY <03>

PW	YB10325D	LCD BL BOARD ASSY	
Q7501	2SD1664/QR/-W	TRANSISTOR	
Q7502	2SD1664/QR/-W	TRANSISTOR	
Q7503	DTA144EE	TRANSISTOR	
	or RN2104	TRANSISTOR	
	or UN9113J	TRANSISTOR	
Q7504	2SC4617/QR/-X	TRANSISTOR	
	or 2SD2216J/QR/-X	TRANSISTOR	
	or 2SC4738/YG/-X	TRANSISTOR	
R7501	NRSA63J-102X	MG RESISTOR	1kΩ,1/16W
R7502	NRSA63J-102X	MG RESISTOR	1kΩ,1/16W
R7503	NRSA63J-102X	MG RESISTOR	1kΩ,1/16W
R7506	NRSA63J-473X	MG RESISTOR	47kΩ,1/16W

#	⚠	REF No.	PART No.	PART NAME, DESCRIPTION	
		R7507	NRSA63J-473X	MG RESISTOR	47kΩ,1/16W
		R7511	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
		C7501	NCZ1016-180X	CAPACITOR	18pF,2kV
		C7503	NCB31EK-273X	CAPACITOR	0.027μF,25V
		C7504	NCB31EK-103X	CAPACITOR	0.01μF,25V
		C7505	NBE20JM-106X	T CAPACITOR	10μF,6.3V
		L7501	NQLZ010-680X	COIL	68μH
		T7501	NQS0048-001X	SW TRANSF	
		CN751	QGF0506F2-32X	FPC CONNECTOR	
		CN752	QGF0505F1-24X	FPC CONNECTOR	
		CN753	QGA5002F1-02X	CONNECTOR	
	⚠	F7501	NMFZ007-R40X-K	FUSE	T0.4A,50V
		OT1	LY41726-001A	PLATE(EARTH)	

****

CCD BOARD ASSEMBLY <04>

PW	YB20914A-01	CCD BOARD ASSY,A,B	
	YB20914B-01	CCD BOARD ASSY,E,F,G	
Q5201	2SC3931/CD/-X	TRANSISTOR	
Q5202	2SC4081/RS/-X	TRANSISTOR,E,F,G	
R5201	NRSA63J-472X	MG RESISTOR	4.7kΩ,1/16W
R5202	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R5203	NRSA63J-104X	MG RESISTOR	100kΩ,1/16W
R5204	NRS181J-0R0X	MG RESISTOR	0Ω,1/8W
R5205	NRSA63J-472X	MG RESISTOR,E,F,G	4.7kΩ,1/16W
C5201	NCB21CK-104X	CAPACITOR	0.1μF,16V
C5202	NBP41DM-106X	T CAPACITOR	10μF,20V
C5203	NCB21CK-104X	CAPACITOR	0.1μF,16V
C5204	NBE21AM-106X	T CAPACITOR	10μF,10V
C5205	NCB11EK-104X	CAPACITOR	0.1μF,25V
C5206	NCB21CK-104X	CAPACITOR	0.1μF,16V
C5207	NCB31EK-222X	CAPACITOR	0.0022μF,25V
C5211	NCB21CK-105X	CAPACITOR	1μF,16V
L5201	NQL315K-100X	COIL	10μH
WR1	WJM0290-001A	E-SI C WIRE C-F,C5202-MAIN WR3	

****

JUNCTION BOARD ASSEMBLY <05>

PW	YB10358A-01	JUNCTION BOARD ASSY	
SW571	NSW0120-002X	PUSH SWITCH,OPEN/EJECT	
CN571	QGF0508F1-33X	FPC CONNECTOR	
CN572	QGF0507F3-15X	FFC/FPC CONNECTOR	
CN573	QGF0505F2-11X	FPC CONNECTOR	
CN574	QGF0505F2-06X	FPC CONNECTOR	

****

JACK BOARD ASSEMBLY <06>

PW	YB10357A-01	JACK BOARD ASSY	
IC501	BA10358F-XE	IC	
IC502	RPM7138-V4	IR DETECT UNIT	
Q501	RPM-22PB	PHOTO TRANSISTOR	
D501	SML-010LT-X	LE DIODE	
D502	MA8068	ZENER DIODE	
D504	MA8068	ZENER DIODE	

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
D505	MA8068	ZENER DIODE	
D506	EMZ6.8N	ZENER DIODE	
R501	NRSA63J-103X	MG RESISTOR	10kΩ,1/16W
R502	NRSA63J-684X	MG RESISTOR	680kΩ,1/16W
R503	NRSA63J-182X	MG RESISTOR	1.8kΩ,1/16W
R504	NRSA63J-222X	MG RESISTOR	2.2kΩ,1/16W
R505	NRSA63J-103X	MG RESISTOR	10kΩ,1/16W
R506	NRSA63J-824X	MG RESISTOR	820kΩ,1/16W
R507	NRSA63J-104X	MG RESISTOR	100kΩ,1/16W
R508	NRSA63J-683X	MG RESISTOR	68kΩ,1/16W
R509	NRSA63J-822X	MG RESISTOR	8.2kΩ,1/16W
R510	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R511	NRSA63J-302X	MG RESISTOR	3kΩ,1/16W
R512	NRSA63J-470X	MG RESISTOR	47Ω,1/16W
R513	NRSA63J-101X	MG RESISTOR	100Ω,1/16W
R514	NRSA63J-101X	MG RESISTOR	100Ω,1/16W
R515	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R516	NRSA63J-221X	MG RESISTOR	220Ω,1/16W
R517	NRSA63J-331X	MG RESISTOR	330Ω,1/16W
R518	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R519	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
C501	NBE21AM-335X	T CAPACITOR	3.3µF,10V
C502	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C503	NCB31EK-153X	CAPACITOR	0.015µF,25V
C504	NCB31EK-153X	CAPACITOR	0.015µF,25V
C506	NBE21AM-106X	T CAPACITOR	10µF,10V
C509	NBE20JM-226X	T CAPACITOR	22µF,6.3V
C514	NCB31HK-103X	CAPACITOR	0.01µF,50V
C515	NCB31HK-103X	CAPACITOR	0.01µF,50V
L501	NQR0251-004X	FERRITE BEAD	
L502	NQR0251-004X	FERRITE BEAD	
L503	NQR0251-004X	FERRITE BEAD	
J501	QNS0078-001	3.5 JACK	
J503	PEMC1203	MINI JACK	
CN501	QGF0503C1-06V	FFC/FPC CONNECTOR	
CN502	QGF0508F1-24X	FPC CONNECTOR	
OT1	LY43515-001A	SHEET(IR)	

****

REAR BOARD ASSEMBLY <07>

PW	YB10362A-01	REAR BOARD ASSY,A,B	
	YB10362B-01	REAR BOARD ASSY,E,F,G	
D551	EMZ6.8N	ZENER DIODE,A,B	
D552	EMZ6.8N	ZENER DIODE,A,B	
D553	MA8068	ZENER DIODE	
R551	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R552	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R553	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R554	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R555	NRSA63J-331X	MG RESISTOR,A,B	330Ω,1/16W
R556	NRSA63J-331X	MG RESISTOR,A,B	330Ω,1/16W
R557	NRSA63J-0R0X	MG RESISTOR,E,F,G	0Ω,1/16W
R558	NRSA63J-0R0X	MG RESISTOR,E,F,G	0Ω,1/16W
R559	NRSA63J-0R0X	MG RESISTOR,E,F,G	0Ω,1/16W
R560	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
R561	NRSA63J-0R0X	MG RESISTOR	0Ω,1/16W
C551	NCF31CZ-104X	CAPACITOR	0.1µF,16V
WR1	WJT0064-001A	E-CARD WIRE,CN551-MAIN CN103	
J551	QNZ0557-001	D CONNECTOR	
J552	QNS0152-001	2.5 JACK,A,B	
J553	QNZ0497-001	USB CONNECTOR,E,F,G	
J554	QNA0027-001	DC JACK	
CN551	QGF0507F3-12X	FFC/FPC CONNECTOR	
CN552	QGA1002F1-06X	CONNECTOR	

****

B/W VF BOARD ASSEMBLY <08>

PW	YB20910A	B/W VF BOARD ASSY	
IC7001	MCVVQ111FB	IC	
Q7001	PUMX1	PAIR TRANSISTOR	
D7001	NSCW100A0/ST/-X	LE DIODE	
D7002	MA111	DIODE	
R7001	NRSA63J-103X	MG RESISTOR	10kΩ,1/16W
R7002	NRSA63J-182X	MG RESISTOR	1.8kΩ,1/16W
R7003	NRSA63J-183X	MG RESISTOR	18kΩ,1/16W
R7006	NRVA63D-333X	CMF RESISTOR	33kΩ,1/16W
R7007	NRVA63D-153X	CMF RESISTOR	15kΩ,1/16W
R7008	NRVA63D-473X	CMF RESISTOR	47kΩ,1/16W
R7009	NRSA63J-682X	MG RESISTOR	6.8kΩ,1/16W
R7010	NRSA63J-102X	MG RESISTOR	1kΩ,1/16W
R7011	NRSA63J-332X	MG RESISTOR	3.3kΩ,1/16W
R7012	NRSA63J-561X	MG RESISTOR	560Ω,1/16W
R7013	NRSA63J-470X	MG RESISTOR	47Ω,1/16W
VR7001	NVP0016-223X	TRIM RESISTOR,GAIN	
C7001	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7002	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7003	NCB21AK-105X	CAPACITOR	1µF,10V
C7004	NCB31EK-223X	CAPACITOR	0.022µF,25V
C7005	NCB31EK-103X	CAPACITOR	0.01µF,25V
C7006	NCF21CZ-105X	CAPACITOR	1µF,16V
C7007	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7008	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7009	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7010	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7011	NCB31HK-102X	CAPACITOR	0.001µF,50V
C7012	NCB31EK-103X	CAPACITOR	0.01µF,25V
C7013	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7014	NCF31CZ-104X	CAPACITOR	0.1µF,16V
C7015	NCB31EK-103X	CAPACITOR	0.01µF,25V
C7016	NCB11CK-475X	CAPACITOR	4.7µF,16V
C7017	NCB10JK-106X	CAPACITOR	10µF,6.3V
L7001	NQL38DK-100X	COIL	10µH
L7002	NQL38DK-100X	COIL	10µH
CN7001	QGF0517F1-06X	FPC CONNECTOR	
CN7002	QGF0517F2-20X	FPC CONNECTOR	

****

DSC BOARD ASSEMBLY <10> (E,F,G)

PW	YB20915A-03	DSC BOARD ASSY
IC8001	TMS320DSC24GHK	IC
	or TMX320DSC24GHK	IC
IC8002	K4S641632E-TC1H	IC
IC8003	MBV160TE90PTA11	IC(MICRO C ROM)
IC8004	S-80842ANNP-W	IC
IC8007	MM1385EN	IC
Q8001	DTA114EE	TRANSISTOR
D8001	RB751V-40-X	SB DIODE

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
R8001	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R8002	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R8003	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R8005	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8006	NRSA6AJ-153W	MG RESISTOR	15kΩ,1/16W
R8007	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R8009	NRSA6AJ-472W	MG RESISTOR	4.7kΩ,1/16W
R8016	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R8017	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R8022	NRSA6AJ-105W	MG RESISTOR	1MΩ,1/16W
R8025	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8026	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8027	NRSA6AJ-152W	MG RESISTOR	1.5kΩ,1/16W
R8028	NRS181J-270X	MG RESISTOR	27Ω,1/8W
R8029	NRS181J-270X	MG RESISTOR	27Ω,1/8W
R8030	NRSA6AJ-105W	MG RESISTOR	1MΩ,1/16W
R8031	NRSA6AJ-105W	MG RESISTOR	1MΩ,1/16W
R8034	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8036	NRSA6AJ-105W	MG RESISTOR	1MΩ,1/16W
R8037	NRSA6AJ-103W	MG RESISTOR	10kΩ,1/16W
R8038	NRSA6AJ-220W	MG RESISTOR	22Ω,1/16W
R8043	NRSA6AJ-220W	MG RESISTOR	22Ω,1/16W
R8046	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8048	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8050	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8051	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8053	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8054	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8055	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8057	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8058	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8060	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8061	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8062	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8063	NRSA6AJ-220W	MG RESISTOR	22Ω,1/16W
R8065	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8066	NRSA6AJ-473W	MG RESISTOR	47kΩ,1/16W
R8067	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8068	NRSA6AJ-561W	MG RESISTOR	560Ω,1/16W
R8069	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
R8071	NRSA6AJ-0R0W	MG RESISTOR	0Ω,1/16W
RA8001	NRZ0034-221W	NETWORK RESISTOR	220Ω
RA8002	NRZ0034-221W	NETWORK RESISTOR	220Ω
RA8003	NRZ0034-221W	NETWORK RESISTOR	220Ω
RA8004	NRZ0034-221W	NETWORK RESISTOR	220Ω
C8001	NBE20JM-106X	T CAPACITOR	10μF,6.3V
C8002	NBE20JM-106X	T CAPACITOR	10μF,6.3V
C8003	NBE20JM-106X	T CAPACITOR	10μF,6.3V
C8004	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8005	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8006	NBE20JM-106X	T CAPACITOR	10μF,6.3V
C8007	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8008	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8010	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8011	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8014	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8015	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8016	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8017	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8018	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8019	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8020	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8021	NBE20JM-106X	T CAPACITOR	10μF,6.3V

# ⚠ REF No.	PART No.	PART NAME, DESCRIPTION	
C8026	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8027	NCB30JK-105X	CAPACITOR	1μF,6.3V
C8028	NCBA1AK-104W	CAPACITOR	0.1μF,10V
C8029	NBE20JM-106X	T CAPACITOR	10μF,6.3V
C8030	NCBA1CK-103W	CAPACITOR	0.01μF,16V
L8001	NQR0129-002X	FERRITE BEAD	
L8002	NQR0129-002X	FERRITE BEAD	
L8003	NQR0129-002X	FERRITE BEAD	
L8004	NQR0129-002X	FERRITE BEAD	
L8005	NQR0129-002X	FERRITE BEAD	
X8002	NAX0398-001X	C OSCILLATOR	
CN8001	QGB0501M1-80X	CONNECTOR	
CN8002	QGF0508F1-10X	FPC CONNECTOR	

SECTION 4
CHARTS AND DIAGRAMS

NOTES OF SCHEMATIC DIAGRAM

Safety precautions
The Components identified by the symbol ⚠ are critical for safety. For continued safety, replace safety critical components only with manufacturer's recommended parts.

1. Units of components on the schematic diagram

Unless otherwise specified.

1) All resistance values are in ohm. 1/6 W, 1/8 W (refer to parts list).
   Chip resistors are 1/16 W.
   K: KΩ (1000Ω), M: MΩ (1000KΩ)
2) All capacitance values are in μF, (P: PF).
3) All inductance values are in μH, (m: mH).
4) All diodes are 1SS133, MA165 or 1N4148M (refer to parts list).

2. Indications of control voltage

AUX : Active at high.

$\overline{AUX}$ or AUX(L) : Active at low.

3. Interpreting Connector indications



4. Voltage measurement

1) Regulator (DC/DC CONV) circuits
   REC : Colour bar signal.
   PB : Alignment tape (Colour bar).
   — : Unmeasurable or unnecessary to measure.
4) Indication on schematic diagram
   Voltage Indications for REC and PB mode on the schematic diagram are as shown below.



Note: If the voltages are not indicated on the schematic diagram, refer to the voltage charts.

5. Signal path Symbols

The arrows indicate the signal path as follows.

NOTE : The arrow is DVC unique object.



6. Indication of the parts for adjustments

The parts for the adjustments are surrounded with the circle as shown below.



7. Indication of the parts not mounted on the circuit board

"OPEN" is indicated by the parts not mounted on the circuit board.

CIRCUIT BOARD NOTES

1. Foil and Component sides

1) Foil side (B side) :
   Parts on the foil side seen from foil face (pattern face) are indicated.
2) Component side (A side) :
   Parts on the component side seen from component face (parts face) indicated.

2. Parts location guides

Parts location are indicated by guide scale on the circuit board.



Note: For general information in service manual, please refer to the Service Manual of GENERAL INFORMATION Edition 4 No. 82054D (January 1994).

4.1 BOARD INTERCONNECTIONS

NOTE)* : The number of patch cords are indicated by interconnected.



4.2 MAIN IF SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*

TO DSC
CN8001

CN111

| | | |

4.3 SYSCON SCHEMATIC DIAGRAM

NOTES :
- *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
- *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*

01 MAIN (SYSCON)

IC1001
UPD70F3040F1-XX
UPD703039F1-XX

NOTE : The parts with marked (⁎) is not used.

: Exchange Parts List

	IC101 ROM No.	R1059
With DSC MODEL	-A25	⁎
Without DSC MODEL	-A22	0Ω

y10250001a_rev0.0

A	B	C	D	4-7	4-8	E	F	G	H

4.4 PC IF SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (*) is not used.

Exchange Parts List

	IC1301	IC1302	C1301~C1306	R1307/R1308
With DSC MODEL	*	*	*	0
Without DSC MODEL	SN74LV08APW-X	MAX3221CAE-X	0.1	*

y30159001a_rev0.0

4.5 DECKCPU SCHEMATIC DIAGRAM

NOTES :
- *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
- *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



Exchange Parts List

	IC1402	R1416/R1417	R1427
With DSC MODEL	*	4.7k	*
Without DSC MODEL	TC7W66FU-X	*	100k

	R1425	R1426
DV INPUT MODEL	47k	*
NON DV INPUT MODEL	*	47k

4.6 MDA SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (✻) is not used.

y20171001a_rev0.0

4.7 AUDIO SCHEMATIC DIAGRAM

NOTES :
- *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
- *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



EXCHANGE PARTS LIST

	EXT_MIC IN	
	YES	NO
Q2101	2SC4617/RSI-X	✻
Q2102	2SC4617/RSI-X	✻
Q2103	DTC144EE-X	✻
R2004	✻	0 Ω
R2005	100k	✻
R2125	0 Ω	✻
R2126	0 Ω	✻
R2127	✻	0 Ω
R2128	✻	0 Ω
R2129	100k	✻
R2203	0 Ω	✻
C2107	1 µ	✻
C2108	1 µ	✻

	with E-Mail/WEB_Cam				
	YES	NO		YES	NO
IC2501	AK4550VT-X	✻	C2504	0.1 µ	✻
L2501	NQL38DK-220X	✻	C2505	0.1 µ	✻
Q2501	UMX18N-W	✻	C2506	0.0022 µ	✻
R2501	0 Ω	✻	C2507	0.0022 µ	✻
R2502	0 Ω	✻	C2508	10 µ	✻
R2504	0 Ω	✻	C2509	4.7 µ	✻
R2505	27k	✻	C2510	1 µ	✻
R2506	27k	✻	C2511	1 µ	✻
R2507	22k	✻	C2512	1 µ	✻
R2508	22k	✻	C2513	1 µ	✻
R2509	560k	✻	C2514	1 µ	✻
R2510	560k	✻	C2515	1 µ	✻
R2511	10k	✻	C2516	0.1 µ	✻
R2512	10k	✻	C2517	0.1 µ	✻
R2513	3.3k	✻			

NOTE : The parts with marked (✻) is not used.

y10252001a_rev0.0

4.8 DVMAIN SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



4.9 PRE/REC SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (⁎) is not used.

4.10 V OUT SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*

0 1 MAIN (V OUT)

TO REG
REG_4.8V
GND
L3701 10µ
C3701 10 /6.3
C3707 0.1
IC3701 BA7665FS-X
Mute
R3703 4.7k
C3708 1
C3702 150p
R3702 240
Q3701 UMT2N-W
R3701 240
C3703 33p
C3709 0.01
20k
Chroma Mute
R3708 4.7k
C3704 100p
R3707 220
Q3701
R3724 3.9k
R3706 220
C3705 33p
C3706 0.01
C3713 330 /4
R3711 68
C3712 330 /4
R3712 68
C3710 0.01
R3713 68
D3701 *
R3716 *
Q3702 UMZ1N-W
R3714 12k
R3715 10k
C3715 *
R3717 560
R3718 560
R3719 10k
TO CAM.DSP
DV_Y
DV_C
TO SYSCON
ASPECT1
ASPECT2
S_DET
Y_OUT
C_OUT
TO MAIN IF CN101
GND — TO REG
S_DET — TO MAIN IF CN101
V_OUT — TO MAIN IF CN102

NOTE : The parts with marked (*) is not used.

y30160001a_rev0.0

4.11 CAM.DSP SCHEMATIC DIAGRAM

NOTES :
- *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
- *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



Difference Point

	R4303	R4304
NTSC	0Ω	*
PAL	*	0Ω

NOTE : The parts with marked (*) is not used.

Exchange Parts List

	RA4307~RA4310	R4302
With DSC MODEL	10	22
Without DSC MODEL	*	*

y10254001a_rev0.0

4.12 OP DRV SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (*) is not used.

Exchange Parts List

	Q4803	Q4804	Q4805	R4825	R4826	R4837, R4846
With DSC MODEL	DTC143EE-X	DTA144EE-X	DTA143EE-X	2.2k	47k	0
Without DSC MODEL	*	*	*	*	*	*

y20173001a_rev0.0

4.13 TG SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (*) is not used.

4.14 REGULATOR SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*


01 MAIN (REG)
IC6101
FA3698F
IC6001
S-80842ANNP-W
TO MAIN IF CN104 BATT_+
TO MAIN IF CN103 BATT_CHK
TO MAIN IF CN104 ADP_DC
TO MAIN IF CN101-CN106, CN109, CN111-CN113, SYSCON, PC IF, DECKCPU, AUDIO, DVMAIN, PRE/REC, V OUT, CAM.DSP, OP DRV, TG GND
TO SYSCON CHRG_EVR
TO MAIN IF CN105 SYSCON I_MTR
TO SYSCON V_BATT
TO DECKCPU M_UNREG
CJIG_RST TO MAIN IF CN105
AREG_SO
AREG_CLK TO SYSCON
REG_CS
REG_3V TO MAIN IF CN101, CN105, CN109, CN111, CN112, SYSCON, DECKCPU, AUDIO, DVMAIN, PRE/REC, CAM.DSP, OP DRV, TG
TO DVMAIN, PRE/REC, CAM.DSP REG_2.5V
TO MAIN IF CN111, DVMAIN, CAM.DSP REG_1.8V
REG_4.8V TO MAIN IF CN101, CN102, CN111, AUDIO, PRE/REC, V OUT, CAM.DSP OP DRV
M_REG4.8 TO DECKCPU, AUDIO, OP DRV
VF_CTL TO SYSCON
VFREG4.8 TO MAIN IF CN101
LAMP_4.5V TO MAIN IF CN106
TO SYSCON LAMP_ON
TO DECKCPU DRUM_PWR
DRUM_ERR
D_GAIN
CAP_PWR
CAP_ERR
TO MAIN IF CN101 REG_1.5V
TO MAIN IF CN101 TG REG_1.2V
TO TG REG-CCD
REG_-1.5V TO MAIN IF CN101
LIT_3V TO SYSCON
LITHIUM TO MAIN IF CN101
AL_3V TO SYSCON

NOTE : The parts with marked (⁎) is not used.

y10255001a_rev0.0

EXCHANGE PARTS LIST

	L6205	Q6207	Q6217	R6217	R6218	R6244	R6245	R6246	C6212	C6213	C6231
With DC LIGHT	22µ	2SD2444K-X	UMZ1N-W	150	100k	1.5k	5.6k	2.2k	1	1	0.01
Without DC LIGHT	open	open	open	open	open	open	open	open	open	open	open

	R6237
680k CCD	75k
Mega CCD	82k

4.15 MONITOR SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (⁎) is not used.

y10256001a_rev0.0

Exchange Parts List

	Q7605	Q7606	L7605	L7606	R7612	R7621	R7622	R7623	R7624	R7625	C7636
2.5inch MODEL	*	*	10μ	*	22K	0	*	*	*	*	*
3inch MODEL	DTA144EE-X	DTC144EE-X	*	10μ	6.8K	*	22K	22K	22K	22K	0.1
3.5inch MODEL	*	*	*	10μ	6.8K	0	*	*	22K	22K	0.1

	R7604	R7626	R7627	R7634	R7635	R7640	R7643	R7644	R7646	C7638	C7639	Q7101	R7110	R7111	R7645	R7113	IC7101	C7102	R7114	C7101	Q7102	R7116
BW VF MODEL	*	*	*	*	*	*	*	*	*	*	*	2SA1774-QR(K	5.6K	0	*	0	TC75W52FU-X	0.1	270	220p	2SC4617TQR-X	1k
COLOR VF MODEL	0	19K	330K	0	0	0	0	0	0	2.2	10/10	*	*	*	0	*	*	*	*	*	*	*

	CN762	CN766	SW6	SW7	SW8	SW9	SW10	R7	R8	R9	R10	R18	R19	R21	R22	R23	C11	L10
DSC MODEL [WITH E-MAIL/WEB CAM]	QGF0508F1-10X	VNZ0358-001X	VNS0339-001X	VNS0180-001X	VNS0180-001X	VNS0180-001X	VNS0180-001X	10K	1.5K	1.8K	2.7K	47K	10K	10K	47K	100K	10/6.3	NQR0129-001X
DSC MODEL [WITHOUT E-MAIL/WEB CAM]	QGF0508F1-10X	VNZ0358-001X	VNS0339-001X	VNS0180-001X	VNS0180-001X	VNS0180-001X	VNS0180-001X	*	*	10K	1.5K	*	*	47K	10K	10K	47K	100K	10/6.3	NQR0129-001X
Without DSC MODEL		*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*

	SW1	R2
With LIGHT MODEL	SVS0402-001X	10K
Without LIGHT MODEL	*	*

4.16 LCD BL SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (*) is not used.

y30162001a_rev0.0

Exchange Prats List

	IC751	D751	L751	L752	R751	C751	C752	C753	C754	CN754	F751
With EL MODEL	MIP805-X	1SS376-X	680	10	100K	10/6	10/6	2200p	2200p	QGF0505F2-06X	NMFZ007-R40X-K
Without EL MODEL	*	*	*	*	*	*	*	*	*	*	*

4.17 CCD SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*

● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*

● *IC5201 is incorporated in the CCD base assembly. When IC5201 needs replacement, replace the CCD base assembly in whole because it cannot be replaced alone.*



Difference point

	IC5201
NTSC	ICX220AK-K
PAL	ICX221BK-K

NOTE : The parts with marked (*) is not used.

y30163001a_rev0.0

Exchange Parts List

	Q5202	R5202
With DSC MODEL	2SC4081/RS/-X	4.7K
Without DSC MODEL	*	*

4.18 JUNCTION SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



4.19 JACK SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (*) is not used.

y40092001a_rev0.0

EXCHANGE PARTS LIST

	J502	L504 ~ L506
Without MIC JACK	*	*
With MIC JACK	QNS0005-001	NQR0251-004X

4.20 REAR SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



NOTE : The parts with marked (*) is not used.

y40094001a_rev0.0

EXCHANGE PARTS LIST

	J552	J553	R555, R556	R557~R559	D551, D552
Without DSC MODEL	QNS0152-001	*	330	*	EMZ6.8N-X
With DSC MODEL	*	QNZ0497-001	*	0W	*

4.21 B/W VF SCHEMATIC DIAGRAM

NOTES : ● *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
● *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*



Difference table

	R7004
NTSC	*
PAL	0

NOTE : The parts with marked (*) is not used.

y30149001a_rev0.0

4.22 DSC SCHEMATIC DIAGRAM [DVL520/DVL522/DVL720]

NOTES :
- *For the destination of each signal and further line connections that are cut off from this diagram, refer to "4.1 BOARD INTERCONNECTIONS".*
- *When ordering parts, be sure to order according to the Part Number indicated in the Parts List.*

10 DSC

TMS320DSC24GHK

IC8001

IC8003
MBV160TE90PTA11
[FLASH_MEMORY]

IC8002
K4S641632E-TC1H

IC8004
S-80942ANNP-W

IC8006

IC8007
MM1385EN-X

CN8001
[4, 43] REG_4.8V
[7, 46, 47] REG_1.8V
[5, 6, 45] REG_3V
[1, 2, 8, 9, 12, 13, 14, 41, 42, 44, 48, 49, 52, 53] GND

CN8001
[50] USBSENS
[11] USB_DN_TX
[51] USB_DP_RX

CN8001
[80] DSC07
[40] DSC06
[79] DSC05
[39] DSC04
[78] DSC03
[38] DSC02
[77] DSC01
[37] DSC00
[76] DSY07
[36] DSY06
[75] DSY05
[35] DSY04
[74] DSY03
[34] DSY02
[73] DSY01
[33] DSY00
[72] FLDSC
[32] HDDSC
[71] VDDSC
[31] CLKDSC
[3] CLK27

CN8001
44.1KHZ DOLRCK2 [60]
11.2896MHZ DOMCK2 [21]
32*44.1KHZ DOBCK2 [61]
DODAT2 [22]
AIDAT2 [62]

CN8001
FLSH_RST [55]
DSC_RST [16]
DSC_CS [56]
DSC_CLK [17]
DSC_DT_IN [57]
DSC_DT_OUT [18]
MXDT_OUT [58]
CAPT_REQ [19]
DSC_WKUP [59]
DSC_STS [20]
USBDOWN [15]
P_MEDIA [54]
MMC_CD [10]

TO MAIN IF
CN111

CN8001
GND 1 41 GND
2 42 GND
CLK27 3 43 REG_4.8V
REG_4.8V 4 44 GND
REG_3V 5 45 REG_3V
6 46 REG_1.8V
REG_1.8V 7 47 REG_1.8V
8 48 GND
9 49 GND
MMC_CD 10 50 USBSENS
USBSENS 11 51 USB_DN_TX
USB_DN_RX 12 52 GND
USB_DP_TX 13 53 GND
14 54 P_MEDIA
P_MEDIA 54 15 USBDOWN
USBDOWN 15 55 FLSH_RST
FLSH_RST 55 16 DSC_RST
DSC_RST 16 56 DSC_CS
DSC_CS 56 17 DSC_CLK
DSC_CLK 17 57 DSC_DT_IN
DSC_DT_IN 57 18 DSC_DT_OUT
DSC_DT_OUT 18 58 MXDT_OUT
MXDT_OUT 58 19 CAPT_REQ
CAPT_REQ 19 59 DSC_WKUP
DSC_WKUP 59 20 DSC_STS
DSC_STS 20 60 DOLRCK2
DOLRCK2 60 21 DOMCK2
DOMCK2 21 61 DOBCK2
DOBCK2 61 22 DODAT2
DODAT2 22 62 AIDAT2
AIDAT2 62 23 DSCIO0
DSCIO0 23 63 DSCIO1
DSCIO1 63 24 DSCIO2
DSCIO2 24 64 DSCIO3
DSCIO3 64 25 DSCIO4
DSCIO4 25 65 DSCIO5
DSCIO5 65 26 DSCIO6
DSCIO6 26 66 DSCIO7
DSCIO7 66 27 DSIY00
DSIY00 27 67 DSIY01
DSIY01 67 28 DSIY02
DSIY02 28 68 DSIY03
DSIY03 68 29 DSIY04
DSIY04 29 69 DSIY05
DSIY05 69 30 DSIY06
DSIY06 30 70 DSIY07
DSIY07 70 31 CLKDSC
CLKDSC 31 71 VDDSC
VDDSC 71 32 HDDSC
HDDSC 32 72 FLDSC
FLDSC 72 33 DSY00
DSY00 33 73 DSY01
DSY01 73 34 DSY02
DSY02 34 74 DSY03
DSY03 74 35 DSY04
DSY04 35 75 DSY05
DSY05 75 36 DSY06
DSY06 36 76 DSY07
DSY07 76 37 DSC00
DSC00 37 77 DSC01
DSC01 77 38 DSC02
DSC02 38 78 DSC03
DSC03 78 39 DSC04
DSC04 39 79 DSC05
DSC05 79 40 DSC06
DSC06 40 80 DSC07
DSC07 80

TO MONITOR
CN762

CN8002
SD_WP
Data2Host [SD/MMC_D_OUT]
MMC_CD
DSC_3V
MMC_CLK
DSC_GND
Data2MMC [SD/MMC_D_IN]
P_MEDIA
SD/MMC_CS
NC

NOTE : The parts with marked (*) is not used.

y10257001a_rev0.0

4.23 MAIN CIRCUIT BOARD [DVL220/DVL320/DVL520]

FOIL SIDE(B)



COMPONENT PARTS LOCATION GUIDE <MAIN/YB10359-01-01> (1/2)

REF.NO.	LOCATION		
CAPACITOR			
C1002	B	C	3A
C1004	B	C	4A
C1006	A	C	5A
C1007	B	C	5B
C1009	B	C	4A
C1010	B	C	4A
C1013	B	C	4A
C1014	B	C	4A
C1015	B	C	4A
C1016	B	C	4A
C1017	B	C	4A
C1019	B	C	4A
C1020	B	C	4A
C1021	B	C	4A
C1023	B	C	4B
C1026	B	C	4A
C1027	B	C	4A
C1028	B	C	3A
C1029	B	C	4A
C1030	B	C	4A
C1031	B	C	5B
C1034	B	C	4A
C1036	B	C	4A
C1037	B	C	4A
C1038	B	C	4A
C1039	B	C	4A
C1301	B	C	3C
C1302	B	C	3C
C1303	B	C	3C
C1304	B	C	3B
C1305	B	C	3C
C1306	B	C	3C
C1307	B	C	2C
C1401	B	C	4B
C1402	B	C	4B
C1403	B	C	5B
C1404	B	C	4B
C1405	B	C	4B
C1406	B	C	5B
C1407	B	C	4B
C1408	B	C	5B
C1409	B	C	4B
C1410	B	C	4B
C1411	B	C	4B
C1412	B	C	4B
C1413	B	C	3B
C1414	B	C	4B
C1415	B	C	4B
C1601	B	C	2C
C1602	B	C	2D
C1603	B	C	2D
C1605	B	C	2C
C1606	B	C	2C
C1607	B	C	3D
C1614	B	C	3C
C1618	B	C	3C
C1619	B	C	3C
C1620	B	C	3C
C1621	B	C	3C
C1622	B	C	3D
C1623	B	C	3D
C1624	B	C	3D
C1625	B	C	2D
C1626	B	C	2C
C1627	B	C	2C
C1628	B	C	2D
C1632	B	C	3D
C1633	B	C	2C
C1641	B	C	2C
C1642	B	C	3C
C2001	B	C	2C
C2002	B	C	2B
C2003	B	C	1D
C2004	B	C	1C
C2005	B	C	2C
C2006	B	C	2C
C2007	B	C	2C
C2008	B	C	2C
C2009	B	C	2C
C2010	B	C	2C
C2011	B	C	2D
C2012	B	C	1D
C2013	B	C	1D
C2014	B	C	1D
C2015	B	C	1D
C2016	B	C	2C
C2017	B	C	2C
C2018	B	C	1C
C2019	B	C	2C
C2020	B	C	2C
C2021	B	C	2C
C2024	B	C	1C
C2025	B	C	1C
C2026	B	C	2C
C2027	B	C	2D
C2028	B	C	2D
C2103	B	C	1C
C2104	B	C	1C
C2105	B	C	1C
C2106	B	C	1C
C2107	B	C	1C
C2108	B	C	1C
C2109	B	C	1C
C2110	B	C	1C
C2111	B	C	1C
C2112	B	C	1C
C2113	B	C	1C
C2114	B	C	1C
C2115	B	C	1C
C2116	B	C	1C
C2117	B	C	1C
C2118	B	C	1C
C2119	B	C	1C
C2120	B	C	1C
C2121	B	C	1D
C2122	B	C	1C
C2123	B	C	1D
C2124	B	C	1C
C2125	B	C	1C
C2126	B	C	1C
C2127	B	C	1C
C2128	B	C	1C
C2201	A	C	1C
C2202	A	C	1C
C2501	B	C	1B
C2502	B	C	1B
C2503	B	C	1B
C2504	B	C	1B
C2505	B	C	1C
C2506	B	C	1C
C2507	B	C	1B
C2508	B	C	1B
C2509	B	C	1C
C2510	B	C	1C
C2511	B	C	2C
C2512	B	C	2C
C2513	B	C	1C
C2514	B	C	1C
C2515	B	C	1B
C2516	B	C	2C
C2517	B	C	2C
C3001	B	C	3C
C3003	B	C	5B
C3004	B	C	4B
C3005	B	C	4C
C3006	B	C	4C
C3007	B	C	5B
C3008	B	C	4C
C3009	B	C	4C
C3011	B	C	5C
C3012	B	C	4C
C3013	B	C	4C
C3014	B	C	4D
C3015	B	C	4C
C3016	B	C	4C
C3017	B	C	4C
C3020	B	C	5C
C3021	B	C	5C
C3022	B	C	4C
C3023	B	C	4C
C3024	B	C	4C
C3025	B	C	4B
C3026	B	C	5C
C3027	B	C	5C
C3028	B	C	5C
C3029	B	C	5C
C3030	B	C	4C
C3031	B	C	4C
C3032	B	C	4C
C3033	B	C	4C
C3034	B	C	4C
C3035	B	C	4C
C3036	B	C	4C
C3037	B	C	4C
C3038	B	C	4B
C3039	B	C	5C
C3040	B	C	4B
C3041	B	C	4B
C3042	B	C	5C
C3043	B	C	5C
C3044	B	C	5C
C3045	B	C	5C
C3046	B	C	5C
C3047	B	C	4B
C3048	B	C	5D
C3049	B	C	5D
C3050	B	C	5C
C3051	B	C	3D
C3052	B	C	3D
C3053	B	C	3C
C3054	B	C	3C
C3055	B	C	5C
C3056	B	C	3C
C3057	B	C	4C
C3058	B	C	4D
C3061	B	C	4C
C3064	B	C	4C
C3066	B	C	3C
C3067	B	C	4D
C3068	B	C	4D
C3069	B	C	4D
C3501	A	C	3C
C3502	A	C	3C
C3503	A	C	2D
C3504	A	C	2C
C3505	A	C	2C
C3506	A	C	2C
C3507	A	C	2C
C3508	A	C	2C
C3509	A	C	2C
C3510	A	C	2C
C3511	A	C	3C
C3512	A	C	3C
C3513	A	C	3C
C3514	A	C	3C
C3515	A	C	3C
C3516	A	C	3C
C3517	A	C	3C
C3518	A	C	3C
C3519	A	C	3C
C3520	A	C	3C
C3521	A	C	2C
C3522	A	C	2C
C3523	A	C	2C
C3524	A	C	2C
C3525	A	C	2C
C3526	A	C	2C
C3527	A	C	3C
C3528	A	C	3C
C3701	A	C	2B
C3702	A	C	3B
C3703	A	C	3B
C3704	A	C	3B
C3705	A	C	3B
C3706	A	C	3B
C3707	A	C	3B
C3708	A	C	3B
C3709	A	C	3B
C3710	A	C	2B
C3712	A	C	3C
C3713	A	C	3B
C3715	A	C	2B
C4201	B	C	2B
C4202	B	C	2B
C4203	B	C	2B
C4204	B	C	2B
C4205	B	C	2B
C4206	B	C	2B
C4207	B	C	2B
C4208	B	C	2B
C4209	B	C	2B
C4210	B	C	2A
C4211	B	C	2A
C4212	B	C	2A
C4213	B	C	2A
C4214	B	C	2A
C4215	B	C	2A
C4216	B	C	2A
C4217	B	C	2A
C4218	B	C	2A
C4301	B	C	3B
C4302	B	C	3A
C4303	B	C	3A
C4304	B	C	2B
C4305	B	C	2B
C4306	B	C	2B
C4308	B	C	3A
C4309	B	C	2B
C4310	B	C	2B
C4311	B	C	2B
C4312	B	C	2C
C4313	B	C	2B
C4314	B	C	2B
C4315	B	C	2B
C4316	B	C	2B
C4317	B	C	2B
C4318	B	C	2B
C4319	B	C	2B
C4320	B	C	2B
C4321	B	C	2B
C4322	B	C	3B
C4323	B	C	3A
C4324	B	C	3A
C4325	B	C	3B
C4326	B	C	3B
C4327	B	C	3B
C4328	B	C	3B
C4329	B	C	3B
C4330	B	C	2A
C4331	B	C	2A
C4332	B	C	2A
C4333	B	C	3A
C4334	B	C	3A
C4335	B	C	2B
C4336	B	C	3B
C4337	B	C	2B
C4338	B	C	2B
C4339	B	C	2A
C4340	B	C	3A
C4341	B	C	3A
C4342	B	C	3A
C4343	B	C	3A
C4344	B	C	3A
C4345	B	C	3A
C4346	B	C	3A
C4347	B	C	3B
C4348	B	C	3B
C4349	B	C	3B
C4350	B	C	2B
C4803	A	C	1C
C4804	A	C	1C
C4806	A	C	1C
C4807	A	C	1C
C4808	A	C	1C
C4809	A	C	1C
C4810	A	C	1C
C4811	A	C	1C
C4812	A	C	1C
C4813	A	C	1C
C4814	A	C	2C
C4815	A	C	1C
C4819	A	C	2C
C4820	A	C	1C
C4822	A	C	1C
C4823	A	C	2C
C4851	A	C	2B
C4852	A	C	2B
C4853	A	C	2B
C4854	A	C	2B
C4855	A	C	2B
C4858	A	C	1C
C4859	A	C	1C
C4860	A	C	1C
C4861	A	C	1C
C4862	A	C	1C
C4863	A	C	1C
C4864	A	C	1B
C4865	A	C	1B
C4866	A	C	1B
C5501	A	C	2A
C5503	A	C	2B
C5504	A	C	2B
C5505	A	C	2A
C5506	A	C	2A
C5507	A	C	2B
C5508	A	C	2B
C5509	A	C	3A
C5510	A	C	2A
C5511	A	C	2A
C5512	A	C	2A
C5513	A	C	3A
C5514	A	C	2A
C5515	A	C	2A
C5516	A	C	2A
C5517	A	C	3A
C5518	A	C	2A
C5519	A	C	2A
C6001	A	C	3B
C6004	A	C	4B
C6005	A	C	4B
C6101	A	C	4C
C6102	A	C	5D
C6103	A	C	4C
C6105	A	C	4D
C6106	A	C	4B
C6107	A	C	4A
C6108	A	C	4A
C6109	A	C	4A
C6110	A	C	3A
C6111	A	C	3A
C6112	A	C	3A
C6113	A	C	3A
C6114	A	C	3A
C6115	A	C	3A
C6116	A	C	3A
C6117	A	C	3A
C6118	A	C	3A
C6119	A	C	3A
C6120	A	C	3A
C6121	A	C	3B
C6122	A	C	3B
C6123	A	C	3B
C6124	A	C	3B
C6125	A	C	3B
C6126	A	C	3B
C6127	A	C	3B
C6128	A	C	3B
C6129	A	C	3B
C6130	A	C	4B
C6131	A	C	5B
C6132	A	C	5C
C6134	A	C	4B
C6201	A	C	5C
C6202	A	C	4B
C6203	A	C	4B
C6204	A	C	4B
C6205	A	C	4B
C6206	A	C	5C
C6207	A	C	4A
C6208	A	C	5B
C6701	A	C	3C
C6702	A	C	4C
C6222	A	C	5C
C6224	A	C	4A
C6225	A	C	4A
C6226	A	C	4A
C6227	A	C	5B
C6228	A	C	4B
C6230	A	C	4A
C6231	A	C	4B
C6701	A	C	4C
C6703	A	C	3C
C6704	A	C	3C

CONNECTOR

CN101	A	C	3D
CN102	B	C	1C
CN103	A	C	5B
CN104	A	C	5C
CN105	B	C	5B
CN106	A	C	1C
CN107	A	C	2B
CN108	A	C	1B
CN109	A	C	5C
CN110	A	C	2D
CN111	A	C	4A
CN112	B	C	4D
CN113	A	C	1C

DIODE

D1001	B	C	5B
D1301	B	C	2C
D1302	B	C	2C
D1602	B	C	2C
D1603	B	C	2C
D1604	B	C	3D
D3001	B	C	4C
D3002	B	C	4C
D3003	B	C	4C
D3004	B	C	3C
D3701	A	C	2B
D5501	A	C	3A
D6002	A	C	4B
D6201	A	C	4C
D6202	A	C	4C
D6203	A	C	4C
D6204	A	C	4B
D6205	A	C	4B
D6206	A	C	5C
D6207	A	C	4A
D6208	A	C	5B
D6701	A	C	3C
D6702	A	C	4C

FUSE

F6101	A	C	5C

IC

IC1001	B	C	4A
IC1002	A	C	4A
IC1003	B	C	5B
IC1004	B	C	4A
IC1005	B	C	4A
IC1006	B	C	4B
IC1007	B	C	3A
IC1008	B	C	5B
IC1301	B	C	3C
IC1302	B	C	3C
IC1303	B	C	2C
IC1401	B	C	4B
IC1402	B	C	4B
IC1601	B	C	2C
IC1602	B	C	3C
IC2001	B	C	1C
IC2501	B	C	1B
IC3001	B	C	4C
IC3004	B	C	4D
IC3005	B	C	3D
IC3007	B	C	3D
IC3501	A	C	2C
IC3502	A	C	3C
IC3701	A	C	3B
IC4201	B	C	2C
IC4202	B	C	2B
IC4301	B	C	3B
IC4302	B	C	2A
IC4304	B	C	2B
IC4802	A	C	1C
IC4803	A	C	1C
IC4804	A	C	2C
IC4807	A	C	2C
IC4851	A	C	1C
IC5501	A	C	2A
IC6001	A	C	3B
IC6101	A	C	3A

COIL

L1002	B	C	3A
L1401	B	C	5B
L2001	B	C	2B
L2002	B	C	1D
L2101	A	C	1C
L2102	A	C	1C
L2103	A	C	1C
L2501	B	C	1B
L3001	B	C	3C
L3002	B	C	5B
L3003	B	C	4B
L3004	B	C	3C
L3005	B	C	5B
L3006	B	C	3C
L3007	B	C	4C
L3008	B	C	4C
L3009	B	C	4C
L3012	B	C	3C
L3015	B	C	3C
L3501	A	C	3C
L3502	A	C	3C
L3503	A	C	2B
L3504	A	C	2C
L3505	A	C	2C
L3701	A	C	2B
L4201	B	C	2B
L4301	B	C	2B
L4302	B	C	2C
L4303	B	C	2B
L4304	B	C	2B
L4305	B	C	2A
L4306	B	C	3A
L4307	B	C	4A
L4802	A	C	1C
L4851	A	C	2B
L4852	A	C	2B
L4853	A	C	1C
L5501	A	C	2A
L5502	A	C	2A
L5503	A	C	2A
L5504	A	C	3A
L5505	A	C	2A
L5506	A	C	2A
L6101	A	C	5C
L6102	A	C	4C
L6201	A	C	4C
L6202	A	C	4C
L6203	A	C	4C
L6204	A	C	3C
L6205	A	C	4B
L6206	A	C	4B
L6207	A	C	4B
L6208	A	C	5B
L6701	A	C	4C

TRANSISTOR

Q1001	B	C	5B
Q1002	B	C	5B
Q1003	B	C	3A
Q1005	B	C	4A
Q1006	B	C	4A
Q1007	B	C	4A
Q1008	B	C	4A
Q1009	B	C	4A
Q1301	B	C	2C
Q1401	B	C	4B
Q1402	B	C	4B
Q1403	B	C	4B
Q1601	B	C	2C
Q2001	B	C	2C
Q2002	B	C	1D
Q2101	B	C	1D
Q2102	B	C	1C
Q2103	B	C	1C
Q2501	B	C	2C
Q3001	B	C	3C
Q3002	B	C	4C
Q3701	A	C	3B
Q3702	A	C	2B
Q4301	B	C	2B
Q4302	B	C	3B
Q4303	B	C	3B
Q4801	A	C	1C
Q4802	A	C	2C
Q4803	A	C	2C
Q4804	A	C	2C
Q4805	A	C	2C
Q4806	A	C	2C
Q4851	A	C	2C
Q6001	A	C	3B
Q6002	A	C	3B
Q6004	A	C	4B
Q6201	A	C	4C
Q6202	A	C	4B
Q6203	A	C	4C
Q6204	A	C	4C
Q6205	A	C	3C
Q6206	A	C	3C
Q6207	A	C	3B
Q6208	A	C	4B
Q6210	A	C	4B
Q6211	A	C	5C
Q6212	A	C	4A
Q6213	A	C	4A
Q6214	A	C	4A
Q6215	A	C	4A
Q6216	A	C	4A
Q6217	A	C	4B
Q6701	A	C	4C

RESISTOR

R101	A	C	5B
R102	A	C	5B
R1001	B	C	5B
R1002	B	C	3A
R1003	B	C	4A
R1004	B	C	4A
R1005	B	C	4A
R1006	B	C	4A
R1007	B	C	3A
R1008	B	C	4A
R1009	B	C	4A
R1010	B	C	4A
R1011	B	C	4A
R1012	B	C	4A
R1014	B	C	4A
R1015	B	C	4A
R1016	B	C	3A
R1017	B	C	5B
R1018	B	C	5B
R1019	B	C	4A
R1020	B	C	4B
R1021	B	C	5B
R1022	B	C	5B
R1023	B	C	4A
R1024	B	C	4A
R1026	B	C	3A
R1027	B	C	4A
R1028	B	C	4A
R1029	B	C	4A
R1030	B	C	4A
R1031	B	C	4A
R1032	B	C	4A
R1036	B	C	4A
R1037	B	C	4A
R1038	B	C	4A
R1039	B	C	4B
R1044	B	C	4A
R1045	B	C	4A
R1046	B	C	3A
R1047	B	C	4A
R1048	B	C	3A
R1049	B	C	4A
R1050	B	C	4A
R1051	B	C	5B
R1052	B	C	5B
R1053	B	C	5B
R1054	B	C	5B

COMPONENT PARTS LOCATION GUIDE <MAIN/YB10359-01-01> (2/2)

REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION		
R1055	B	C	5B	R2009	B	C	2C	R3036	B	C	5C	R4321	B	C	2B	R4864	A	C	1B	R6238	A	C	4A	TL1609	A	C	3D
R1056	B	C	5B	R2014	B	C	2D	R3037	B	C	5D	R4322	B	C	3B	R4865	A	C	1B	R6239	A	C	4A	TL1610	A	C	3D
R1057	B	C	4A	R2015	B	C	2D	R3040	B	C	3D	R4323	B	C	3C	R4866	A	C	1B	R6240	A	C	4A	TL1611	B	C	3C
R1058	B	C	4A	R2016	B	C	2D	R3041	B	C	3D	R4324	B	C	3B	R4867	A	C	1B	R6241	A	C	4A	TL1612	B	C	3D
R1059	B	C	4A	R2017	B	C	2D	R3042	B	C	3D	R4325	B	C	2B	R4868	A	C	1B	R6242	A	C	4A	TL1613	B	C	3D
R1060	B	C	4A	R2018	B	C	2C	R3043	B	C	3C	R4326	B	C	2C	R4870	A	C	2C	R6243	A	C	4A	TL1614	B	C	2C
R1066	B	C	5B	R2019	B	C	1D	R3044	B	C	3D	R4327	B	C	3B	R4871	A	C	1B	R6244	A	C	4B	TL1617	B	C	3D
R1071	B	C	4A	R2020	B	C	1D	R3045	B	C	3C	R4328	B	C	2B	R4872	A	C	2C	R6245	A	C	4B	TL1618	A	C	3D
R1072	B	C	4B	R2023	B	C	2C	R3046	B	C	3C	R4329	B	C	2B	R4874	A	C	1B	R6246	A	C	4B	TL1619	A	C	3D
R1076	B	C	4B	R2024	B	C	2C	R3047	B	C	4D	R4330	B	C	3C	R5501	A	C	2A	R6247	A	C	4A	TL1620	A	C	3D
R1077	B	C	4A	R2025	B	C	2C	R3048	B	C	4D	R4331	B	C	3B	R5503	A	C	2B	R6701	A	C	3C	TL1621	A	C	3D
R1078	B	C	4A	R2028	B	C	2C	R3049	B	C	4D	R4332	B	C	3B	R5504	A	C	2B	R6702	A	C	3C	TL1622	A	C	3D
R1079	B	C	4A	R2029	B	C	1D	R3050	B	C	4D	R4333	B	C	3B	R5505	A	C	2B	R6703	A	C	3C	TL3001	B	C	4C
R1080	B	C	4A	R2103	B	C	1C	R3051	B	C	4D	R4334	B	C	3B	R5506	A	C	2B	R6704	A	C	5B	TL3005	B	C	4C
R1081	B	C	4A	R2104	B	C	1C	R3057	B	C	4D	R4335	B	C	3B	R5507	A	C	2B	R6705	A	C	5B	TL3006	B	C	4C
R1082	B	C	4A	R2105	B	C	1C	R3059	B	C	4B	R4336	B	C	3B	R5509	A	C	3B	RA1008	B	C	5B	TL3501	B	C	5B
R1083	B	C	4A	R2106	B	C	1C	R3066	B	C	4D	R4337	B	C	3B	R5510	A	C	3A	RA1009	B	C	4A	TL4201	B	C	2B
R1302	B	C	2C	R2107	B	C	1C	R3067	B	C	4D	R4338	B	C	3A	R5511	A	C	3A	RA1010	B	C	4A	TL4202	B	C	2A
R1305	B	C	2C	R2108	B	C	1C	R3068	B	C	4D	R4339	B	C	3B	R5512	A	C	3B	RA1401	B	C	4B	TL4301	B	C	3B
R1306	B	C	2C	R2109	B	C	1C	R3069	B	C	4D	R4340	B	C	3B	R5513	A	C	3B	RA3001	B	C	4C	TL4302	B	C	3B
R1307	B	C	2C	R2110	B	C	1C	R3070	B	C	3C	R4341	B	C	3B	R5514	A	C	3B	RA3002	B	C	4C	TL4303	B	C	3B
R1308	B	C	2C	R2111	B	C	1C	R3071	B	C	5D	R4342	B	C	2B	R5515	A	C	2B	RA3003	B	C	4C	TL4304	B	C	3A
R1401	B	C	4B	R2112	B	C	1C	R3072	B	C	4D	R4343	B	C	2B	R5516	A	C	2B	RA3004	B	C	5C	TL4305	B	C	3B
R1402	B	C	4B	R2113	B	C	1C	R3073	B	C	4C	R4344	B	C	2B	R6001	A	C	3B	RA3005	B	C	5C	TL4306	B	C	3B
R1403	B	C	4B	R2114	B	C	1C	R3074	B	C	4C	R4345	B	C	3A	R6002	A	C	3B	RA4301	B	C	3A	TL4307	B	C	3B
R1404	B	C	4B	R2115	B	C	1C	R3075	B	C	4D	R4346	B	C	2B	R6003	A	C	3B	RA4302	B	C	3A	TL4308	B	C	3B
R1405	B	C	4B	R2116	B	C	1C	R3501	A	C	2C	R4347	B	C	2B	R6004	A	C	3B	RA4303	B	C	3A	TL4309	B	C	3B
R1406	B	C	4B	R2117	B	C	1C	R3502	A	C	2C	R4348	B	C	2B	R6005	A	C	3B	RA4307	B	C	3A	TL4310	B	C	3B
R1407	B	C	4B	R2118	B	C	1C	R3503	A	C	2C	R4349	B	C	2B	R6009	A	C	4A	RA4308	B	C	3A	TL4311	B	C	3B
R1408	B	C	4B	R2119	B	C	1D	R3504	A	C	2C	R4350	B	C	2B	R6010	A	C	4B	RA4309	B	C	3A	TL4312	B	C	3B
R1409	B	C	4B	R2120	B	C	1C	R3505	A	C	2C	R4351	B	C	3B	R6011	A	C	4B	RA4310	B	C	3A	TL4313	B	C	3B
R1410	B	C	4B	R2121	B	C	1D	R3506	A	C	2C	R4804	A	C	2C	R6012	A	C	4B	**OTHER**				TL4314	B	C	3B
R1411	B	C	4B	R2122	B	C	1C	R3507	A	C	2C	R4805	A	C	1C	R6013	A	C	4B					TL4316	B	C	3B
R1412	B	C	4B	R2123	B	C	1D	R3508	A	C	3C	R4806	A	C	1C	R6101	A	C	4A	TL1001	B	C	4A	TL4317	B	C	3B
R1413	B	C	4B	R2124	B	C	1C	R3509	A	C	2C	R4807	A	C	1C	R6102	A	C	4A	TL1002	B	C	4A	TL4405	B	C	3B
R1414	B	C	4B	R2125	B	C	1D	R3510	A	C	2B	R4808	A	C	1C	R6103	A	C	4A	TL1003	B	C	4A	TL4801	A	C	1C
R1415	B	C	4B	R2126	B	C	1C	R3511	A	C	3C	R4809	A	C	1C	R6106	A	C	3A	TL1004	B	C	4A	TL5501	A	C	3A
R1416	B	C	4B	R2127	B	C	1D	R3512	A	C	3C	R4810	A	C	1C	R6107	A	C	3A	TL1005	B	C	4A	TL5502	A	C	3A
R1417	B	C	5B	R2128	B	C	1C	R3521	A	C	3C	R4811	A	C	1C	R6108	A	C	3A	TL1006	B	C	4A	TL5503	A	C	3A
R1420	B	C	4B	R2129	B	C	1C	R3522	A	C	2C	R4812	A	C	1C	R6113	A	C	3A	TL1007	B	C	4A	TL5504	A	C	3A
R1421	B	C	4B	R2201	A	C	1C	R3701	A	C	3B	R4813	A	C	1C	R6114	A	C	3B	TL1009	B	C	4A	TM01	A	C	1?
R1422	B	C	4B	R2202	A	C	1C	R3702	A	C	3B	R4814	A	C	1C	R6115	A	C	3B	TL1010	B	C	4A	TM1	A	C	1?
R1423	B	C	4B	R2203	B	C	1C	R3703	A	C	3B	R4815	A	C	1C	R6116	A	C	3A	TL1021	B	C	4B	TM03	A	C	5?
R1424	B	C	4B	R2501	B	C	1B	R3706	A	C	3B	R4816	A	C	1C	R6117	A	C	3B	TL1022	B	C	5B	TM3	A	C	5?
R1425	B	C	4B	R2502	B	C	1B	R3707	A	C	3B	R4817	A	C	2C	R6118	A	C	3B	TL1023	B	C	4B	X1001	B	C	4B
R1426	B	C	4B	R2503	B	C	1B	R3708	A	C	3B	R4818	A	C	2C	R6124	A	C	4B	TL1024	B	C	5A	X1002	A	C	4A
R1427	A	C	5B	R2504	B	C	1B	R3711	A	C	3B	R4819	A	C	1C	R6201	A	C	4B	TL1025	B	C	5B	X1401	B	C	4B
R1601	B	C	2D	R2505	B	C	1C	R3712	A	C	3C	R4820	A	C	1C	R6202	A	C	4B	TL1026	B	C	5B	X3001	B	C	4C
R1602	B	C	2D	R2506	B	C	2C	R3713	A	C	2B	R4821	A	C	1C	R6203	A	C	4B	TL1027	B	C	4B	X3002	B	C	4C
R1603	B	C	2C	R2507	B	C	1C	R3714	A	C	2B	R4822	A	C	2C	R6204	A	C	4B	TL1029	B	C	4B	X5501	A	C	2A
R1604	B	C	2D	R2508	B	C	2C	R3715	A	C	2B	R4823	A	C	2C	R6205	A	C	4B	TL1030	B	C	4B				
R1605	B	C	2C	R2509	B	C	2C	R3716	A	C	2B	R4824	A	C	1C	R6206	A	C	4B	TL1031	B	C	4B				
R1609	B	C	3C	R2510	B	C	2C	R3717	A	C	2B	R4825	A	C	2C	R6207	A	C	4B	TL1032	B	C	4A				
R1610	B	C	3C	R2511	B	C	2C	R3718	A	C	2B	R4826	A	C	2C	R6208	A	C	4B	TL1033	B	C	4A				
R1611	B	C	3C	R2512	B	C	2C	R3719	A	C	2B	R4827	A	C	1C	R6209	A	C	4B	TL1034	B	C	4B				
R1612	B	C	3C	R2513	B	C	2C	R3724	A	C	3B	R4828	A	C	2C	R6210	A	C	3C	TL1035	B	C	4B				
R1613	B	C	3C	R3002	B	C	4C	R4201	B	C	2B	R4829	A	C	1C	R6211	A	C	3C	TL1401	B	C	4B				
R1614	B	C	3C	R3003	B	C	4D	R4202	B	C	2B	R4830	A	C	2C	R6212	A	C	3C	TL1402	B	C	4B				
R1615	B	C	3C	R3004	B	C	4C	R4203	B	C	2B	R4831	A	C	2C	R6213	A	C	3C	TL1403	B	C	4B				
R1616	B	C	3D	R3005	B	C	4C	R4205	B	C	2A	R4833	A	C	2C	R6214	A	C	3C	TL1404	B	C	4B				
R1617	B	C	3C	R3006	B	C	4C	R4206	B	C	2A	R4836	A	C	2C	R6215	A	C	3C	TL1405	B	C	5B				
R1618	B	C	3C	R3007	B	C	4C	R4207	B	C	3A	R4837	A	C	2C	R6216	A	C	3C	TL1406	B	C	4B				
R1619	B	C	2C	R3008	B	C	4C	R4208	B	C	2A	R4839	A	C	2C	R6217	A	C	4B	TL1407	B	C	4B				
R1620	B	C	2C	R3009	B	C	4C	R4301	B	C	3B	R4840	A	C	2C	R6218	A	C	4B	TL1408	B	C	5B				
R1621	B	C	2D	R3010	B	C	4C	R4302	B	C	3A	R4841	A	C	2C	R6219	A	C	5B	TL1409	B	C	5B				
R1622	B	C	3C	R3011	B	C	4C	R4303	B	C	2B	R4842	A	C	2C	R6220	A	C	5B	TL1410	B	C	5B				
R1624	B	C	2C	R3013	B	C	5C	R4304	B	C	2B	R4843	A	C	2C	R6221	A	C	5B	TL1411	B	C	5B				
R1625	A	C	2C	R3014	B	C	5C	R4305	B	C	2B	R4844	A	C	2C	R6222	A	C	5B	TL1412	A	C	3B				
R1626	A	C	2C	R3015	B	C	5C	R4306	B	C	2B	R4845	A	C	2C	R6223	A	C	5B	TL1413	A	C	3B				
R1628	B	C	2C	R3016	B	C	5C	R4307	B	C	2B	R4846	A	C	2B	R6224	A	C	4B	TL1414	B	C	4B				
R1629	B	C	2D	R3017	B	C	5C	R4308	B	C	2B	R4847	A	C	2C	R6225	A	C	4B	TL1415	B	C	5B				
R1630	B	C	3D	R3018	B	C	5C	R4309	B	C	2B	R4849	A	C	2C	R6226	A	C	4B	TL1416	B	C	4B				
R1631	B	C	3D	R3019	B	C	5C	R4310	B	C	2B	R4850	A	C	2C	R6227	A	C	4A	TL1417	A	C	4B				
R1635	B	C	2C	R3020	B	C	5C	R4311	B	C	2B	R4852	A	C	1B	R6228	A	C	4A	TL1418	B	C	4B				
R1636	B	C	2C	R3025	B	C	3C	R4312	B	C	2B	R4854	A	C	1C	R6229	A	C	4A	TL1419	B	C	4B				
R1637	B	C	2C	R3026	B	C	3C	R4313	B	C	2B	R4855	A	C	1C	R6230	A	C	4A	TL1420	A	C	5B				
R1643	B	C	2C	R3027	B	C	4C	R4314	B	C	2B	R4856	A	C	1C	R6231	A	C	4A	TL1601	B	C	2C				
R2001	B	C	1D	R3029	B	C	4C	R4315	B	C	2B	R4857	A	C	2C	R6232	A	C	4A	TL1602	B	C	3C				
R2004	B	C	1D	R3030	B	C	4C	R4316	B	C	2B	R4858	A	C	2C	R6233	A	C	4A	TL1603	B	C	3C				
R2005	B	C	1D	R3031	B	C	4C	R4317	B	C	2C	R4859	A	C	2C	R6234	A	C	4A	TL1604	B	C	2C				
R2006	B	C	2C	R3032	B	C	4C	R4318	B	C	2B	R4860	A	C	2C	R6235	A	C	4A	TL1605	A	C	3D				
R2007	B	C	2C	R3033	B	C	4C	R4319	B	C	2C	R4862	A	C	1B	R6236	A	C	4A	TL1606	A	C	3D				
R2008	B	C	2C	R3034	B	C	4C	R4320	B	C	2C	R4863	A	C	1B	R6237	A	C	4A	TL1607	A	C	3D				
																				TL1608	B	C	3C				

COMPONENT SIDE(A)

01 MAIN PWB
YB10359-01-01



4.24 MAIN CIRCUIT BOARD [DVL522/DVL720]

FOIL SIDE(B)



COMPONENT PARTS LOCATION GUIDE <MAIN/YB10359-01-02> (1/2)

REF.NO.	LOCATION
CAPACITOR	
C1002	B C 3A
C1003	B C 4A
C1004	B C 4A
C1006	A C 5A
C1007	B C 5B
C1009	B C 4A
C1010	B C 4A
C1013	B C 4A
C1014	B C 4A
C1015	B C 4A
C1016	B C 4A
C1017	B C 4A
C1019	B C 4A
C1020	B C 4A
C1021	B C 4A
C1023	B C 4B
C1026	B C 4A
C1027	B C 4A
C1028	B C 3A
C1029	B C 4A
C1030	B C 4A
C1031	B C 5B
C1034	B C 4A
C1036	B C 4A
C1037	B C 4A
C1038	B C 4A
C1039	B C 4A
C1301	B C 3C
C1302	B C 3C
C1303	B C 3C
C1304	B C 3B
C1305	B C 3C
C1306	B C 3C
C1307	B C 2C
C1401	B C 4B
C1402	B C 4B
C1403	B C 5B
C1404	B C 4B
C1405	B C 4B
C1406	B C 5B
C1407	B C 4B
C1408	B C 5B
C1409	B C 4B
C1410	B C 4B
C1411	B C 4B
C1412	B C 4B
C1413	B C 3B
C1414	B C 4B
C1415	B C 4B
C1416	B C 4B
C1601	B C 2C
C1602	B C 2D
C1603	B C 2D
C1605	B C 2C
C1606	B C 2C
C1607	B C 3D
C1614	B C 3C
C1618	B C 3C
C1619	B C 3C
C1620	B C 3C
C1621	B C 3C
C1622	B C 3D
C1623	B C 3D
C1624	B C 3D
C1625	B C 2D
C1626	B C 2C
C1627	B C 2C
C1628	B C 2D
C1632	B C 3D
C1633	B C 2C
C1641	B C 2C
C1642	B C 3C
C2001	B C 2C
C2002	B C 2B
C2003	B C 1D
C2004	B C 1C
C2005	B C 2C
C2006	B C 2C
C2007	B C 2C
C2008	B C 2C
C2009	B C 2C
C2010	B C 2C
C2011	B C 2D
C2012	B C 1D
C2013	B C 1D
C2014	B C 1D
C2015	B C 1D
C2016	B C 2C
C2017	B C 2C
C2018	B C 1C
C2019	B C 2C
C2020	B C 2C
C2021	B C 2C
C2024	B C 1C
C2025	B C 1C
C2026	B C 2C
C2027	B C 2D
C2028	B C 2D
C2103	B C 1C
C2104	B C 1C
C2105	B C 1C
C2106	B C 1C
C2107	B C 1C
C2108	B C 1C
C2109	B C 1C
C2110	B C 1C
C2111	B C 1C
C2112	B C 1C
C2113	B C 1C
C2114	B C 1C
C2115	B C 1C
C2116	B C 1C
C2117	B C 1C
C2118	B C 1C
C2119	B C 1C
C2120	B C 1C
C2121	B C 1D
C2122	B C 1C
C2123	B C 1D
C2124	B C 1C
C2125	B C 1C
C2126	B C 1C
C2127	B C 1C
C2128	B C 1C
C2201	A C 1C
C2202	A C 1C
C2501	B C 1B
C2502	B C 1B
C2503	B C 1B
C2504	B C 1B
C2505	B C 1C
C2506	B C 1C
C2507	B C 1B
C2508	B C 1B
C2509	B C 1C
C2510	B C 1C
C2511	B C 2C
C2512	B C 2C
C2513	B C 1C
C2514	B C 1C
C2515	B C 1B
C2516	B C 2C
C2517	B C 2C
C3001	B C 3C
C3003	B C 5B
C3004	B C 4B
C3005	B C 4C
C3006	B C 4C
C3007	B C 5B
C3008	B C 4C
C3009	B C 4C
C3011	B C 5C
C3012	B C 4C
C3013	B C 4C
C3014	B C 4D
C3015	B C 4C
C3016	B C 4C
C3017	B C 4C
C3020	B C 5C
C3021	B C 5C
C3022	B C 4C
C3023	B C 4C
C3024	B C 4C
C3025	B C 4B
C3026	B C 5C
C3027	B C 5C
C3028	B C 5C
C3029	B C 5C
C3030	B C 4C
C3031	B C 4C
C3032	B C 4C
C3033	B C 4C
C3034	B C 4C
C3035	B C 4C
C3036	B C 4C
C3037	B C 4C
C3038	B C 4B
C3039	B C 5C
C3040	B C 4B
C3041	B C 4B
C3042	B C 5C
C3043	B C 5C
C3044	B C 5C
C3045	B C 5C
C3046	B C 5C
C3047	B C 4B
C3048	B C 5D
C3049	B C 5D
C3050	B C 5C
C3051	B C 3D
C3052	B C 3D
C3053	B C 3C
C3054	B C 3C
C3055	B C 5C
C3056	B C 3C
C3057	B C 4C
C3058	B C 4D
C3061	B C 4C
C3064	B C 4C
C3066	B C 3C
C3067	B C 4D
C3068	B C 4D
C3069	B C 4D
C3070	B C 4D
C3501	A C 3C
C3502	A C 3C
C3503	A C 2D
C3504	A C 2C
C3505	A C 2C
C3506	A C 2C
C3507	A C 2C
C3508	A C 2C
C3509	A C 2C
C3510	A C 2C
C3511	A C 3C
C3512	A C 3C
C3513	A C 3C
C3514	A C 3C
C3515	A C 3C
C3516	A C 3C
C3517	A C 3C
C3518	A C 3C
C3519	A C 3C
C3520	A C 3C
C3521	A C 2C
C3522	A C 2C
C3523	A C 2C
C3524	A C 2C
C3525	A C 2C
C3526	A C 2C
C3527	A C 3C
C3528	A C 3C
C3701	A C 2B
C3702	A C 3B
C3703	A C 3B
C3704	A C 3B
C3705	A C 3B
C3706	A C 3B
C3707	A C 3B
C3708	A C 3B
C3709	A C 3B
C3710	A C 2B
C3712	A C 3C
C3713	A C 3B
C3715	A C 2B
C4201	B C 2B
C4202	B C 2B
C4203	B C 2B
C4204	B C 2B
C4205	B C 2B
C4206	B C 2B
C4207	B C 2B
C4208	B C 2B
C4209	B C 2B
C4210	B C 2A
C4211	B C 2A
C4212	B C 2A
C4213	B C 2A
C4214	B C 2A
C4215	B C 2A
C4216	B C 2A
C4217	B C 2A
C4301	B C 3B
C4302	B C 3A
C4303	B C 3B
C4304	B C 2B
C4305	B C 2B
C4306	B C 2B
C4307	B C 3A
C4308	B C 3A
C4309	B C 2B
C4310	B C 2B
C4311	B C 2B
C4312	B C 2C
C4313	B C 2B
C4314	B C 2B
C4315	B C 2B
C4316	B C 2B
C4317	B C 2B
C4318	B C 2B
C4319	B C 2B
C4320	B C 2B
C4321	B C 2B
C4322	B C 3B
C4323	B C 3A
C4324	B C 3A
C4325	B C 3B
C4326	B C 3B
C4327	B C 3B
C4328	B C 3B
C4329	B C 3B
C4330	B C 2A
C4331	B C 2A
C4332	B C 2A
C4333	B C 3A
C4334	B C 3A
C4335	B C 2B
C4336	B C 3B
C4337	B C 2B
C4338	B C 2B
C4339	B C 2A
C4340	B C 3A
C4341	B C 3A
C4342	B C 3A
C4343	B C 3A
C4344	B C 3A
C4345	B C 3A
C4346	B C 3A
C4347	B C 3B
C4348	B C 3B
C4349	B C 3B
C4350	B C 2B
C4803	A C 1C
C4804	A C 1C
C4806	A C 1C
C4807	A C 1C
C4808	A C 1C
C4809	A C 1C
C4810	A C 1C
C4811	A C 1C
C4812	A C 1C
C4813	A C 1C
C4814	A C 2C
C4815	A C 1C
C4819	A C 2C
C4820	A C 1C
C4822	A C 1C
C4823	A C 2C
C4851	A C 2B
C4852	A C 2B
C4853	A C 2B
C4854	A C 2B
C4855	A C 2B
C4858	A C 1C
C4859	A C 1C
C4860	A C 1C
C4861	A C 1C
C4862	A C 1C
C4863	A C 1C
C4864	A C 1B
C4865	A C 1B
C4866	A C 1B
C5501	A C 2A
C5503	A C 2B
C5504	A C 2B
C5505	A C 2A
C5506	A C 2A
C5507	A C 2B
C5508	A C 2B
C5509	A C 3A
C5510	A C 2A
C5511	A C 2A
C5512	A C 2A
C5513	A C 3A
C5514	A C 2A
C5515	A C 2A
C5516	A C 2A
C5517	A C 3A
C5518	A C 2A
C5519	A C 2A
C6001	A C 3B
C6004	A C 4B
C6005	A C 4B
C6101	A C 4C
C6102	A C 5D
C6103	A C 4C
C6105	A C 4D
C6106	A C 4B
C6107	A C 4A
C6108	A C 4A
C6109	A C 4A
C6110	A C 3A
C6111	A C 3A
C6112	A C 3A
C6113	A C 3A
C6114	A C 3A
C6115	A C 3A
C6116	A C 3A
C6117	A C 3A
C6118	A C 3A
C6119	A C 3A
C6120	A C 3A
C6121	A C 3B
C6122	A C 3B
C6123	A C 3B
C6124	A C 3B
C6125	A C 3B
C6126	A C 3B
C6127	A C 3B
C6128	A C 3B
C6129	A C 3B
C6130	A C 4B
C6131	A C 5B
C6132	A C 5C
C6134	A C 4B
C6201	A C 5C
C6202	A C 4B
C6203	A C 4B
C6204	A C 4B
C6205	A C 4B
C6206	A C 4C
C6207	A C 4B
C6208	A C 4B
C6209	A C 4C
C6210	A C 3C
C6211	A C 3C
C6212	A C 3B
C6213	A C 4B
C6214	A C 4B
C6215	A C 5B
C6216	A C 5B
C6217	A C 4B
C6218	A C 4B
C6219	A C 4B
C6220	A C 5C
C6221	A C 5C
C6222	A C 5C
C6224	A C 4A
C6225	A C 4A
C6226	A C 4A
C6227	A C 5B
C6228	A C 4B
C6230	A C 4A
C6231	A C 1C
C6701	A C 4C
C6703	A C 3C
C6704	A C 3C
CONNECTOR	
CN101	A C 3D
CN102	B C 1C
CN103	A C 5B
CN104	A C 5C
CN105	B C 5B
CN106	A C 1C
CN107	A C 2B
CN108	A C 1B
CN109	A C 5C
CN110	A C 2D
CN111	A C 4A
CN112	B C 4D
CN113	A C 1C
DIODE	
D1001	B C 5B
D1301	B C 2C
D1302	B C 2C
D1602	B C 2C
D1603	B C 2C
D1604	B C 3D
D3001	B C 4C
D3002	B C 4C
D3003	B C 4C
D3004	B C 3C
D3701	A C 2B
D5501	A C 3A
D6002	A C 4B
D6201	A C 4C
D6202	A C 4C
D6203	A C 4C
D6204	A C 4B
D6205	A C 4B
D6206	A C 5C
D6207	A C 4A
D6208	A C 5B
D6701	A C 3C
D6702	A C 4C
FUSE	
F6101	A C 5C
IC	
IC1001	B C 4A
IC1002	A C 4A
IC1003	B C 5B
IC1004	B C 4A
IC1005	B C 4A
IC1006	B C 4B
IC1007	B C 3A
IC1008	B C 5B
IC1301	B C 3C
IC1302	B C 3C
IC1303	B C 2C
IC1401	B C 4B
IC1402	B C 4B
IC1601	B C 2C
IC1602	B C 3C
IC2001	B C 1C
IC2501	B C 1B
IC3001	B C 4C
IC3004	B C 4D
IC3005	B C 3D
IC3007	B C 3D
IC3501	A C 2C
IC3502	A C 3C
IC3701	A C 3B
IC4201	B C 2B
IC4202	B C 2B
IC4301	B C 3B
IC4302	B C 2A
IC4304	B C 2B
IC4802	A C 1C
IC4803	A C 1C
IC4804	A C 2C
IC4807	A C 2C
IC4851	A C 1C
IC5501	A C 2A
IC6001	A C 3B
IC6101	A C 3A
COIL	
L1002	B C 3A
L1401	B C 5B
L2001	B C 2B
L2002	B C 1D
L2101	A C 1C
L2102	A C 1C
L2103	A C 1C
L2501	B C 1B
L3001	B C 3C
L3002	B C 5B
L3003	B C 4B
L3004	B C 3C
L3005	B C 5B
L3006	B C 3C
L3007	B C 4C
L3008	B C 4C
L3009	B C 4C
L3012	B C 3C
L3015	B C 3C
L3501	A C 3C
L3502	A C 3C
L3503	A C 2B
L3504	A C 2C
L3505	A C 2C
L3701	A C 2B
L4201	B C 2B
L4301	B C 2B
L4302	B C 2C
L4303	B C 2B
L4304	B C 2B
L4305	B C 2A
L4306	B C 3A
L4307	B C 4A
L4802	A C 1C
L4851	A C 2B
L4852	A C 2B
L4853	A C 1C
L5501	A C 2A
L5502	A C 2A
L5503	A C 2A
L5504	A C 3A
L5505	A C 2A
L5506	A C 2A
L6101	A C 5C
L6102	A C 4C
L6201	A C 4C
L6202	A C 4C
L6203	A C 4C
L6204	A C 3C
L6205	A C 4B
L6206	A C 4B
L6207	A C 4B
L6208	A C 5B
L6701	A C 4C
TRANSISTOR	
Q1001	B C 5B
Q1002	B C 5B
Q1003	B C 3A
Q1005	B C 4A
Q1006	B C 4A
Q1007	B C 4A
Q1008	B C 4A
Q1009	B C 4A
Q1301	B C 2C
Q1401	B C 4B
Q1402	B C 4B
Q1403	B C 4B
Q1601	B C 2C
Q2001	B C 2C
Q2002	B C 1D
Q2101	B C 1D
Q2102	B C 1C
Q2103	B C 1C
Q2501	B C 2C
Q3001	B C 3C
Q3002	B C 4C
Q3701	A C 3B
Q3702	A C 2B
Q4301	B C 2B
Q4302	B C 3B
Q4303	B C 3B
Q4801	A C 1C
Q4802	A C 2C
Q4803	A C 2C
Q4804	A C 2C
Q4805	A C 2C
Q4806	A C 2C
Q4851	A C 2C
Q6001	A C 3B
Q6002	A C 3B
Q6004	A C 4B
Q6201	A C 4C
Q6202	A C 4B
Q6203	A C 4C
Q6204	A C 4C
Q6205	A C 3C
Q6206	A C 3C
Q6207	A C 3B
Q6208	A C 4B
Q6210	A C 4B
Q6211	A C 5C
Q6212	A C 4A
Q6213	A C 4A
Q6214	A C 4A
Q6215	A C 4A
Q6216	A C 4A
Q6217	A C 4B
Q6701	A C 4C
RESISTOR	
R101	A C 5B
R102	A C 5B
R1001	B C 5B
R1002	B C 3A
R1003	B C 4A
R1004	B C 4A
R1005	B C 4A
R1006	B C 4A
R1007	B C 3A
R1008	B C 4A
R1009	B C 4A
R1010	B C 4A
R1011	B C 4A
R1012	B C 4A
R1014	B C 4A
R1015	B C 4A
R1016	B C 3A
R1017	B C 5B
R1018	B C 5B
R1019	B C 4A
R1020	B C 4B
R1021	B C 5B
R1022	B C 5B
R1023	B C 4A
R1024	B C 4A
R1026	B C 3A
R1027	B C 4A
R1028	B C 4A
R1029	B C 4A
R1030	B C 4A
R1031	B C 4A
R1032	B C 4A
R1036	B C 4A
R1037	B C 4A
R1038	B C 4A
R1039	B C 4B
R1044	B C 4A
R1045	B C 4A
R1046	B C 3A
R1047	B C 4A
R1048	B C 3A
R1049	B C 4A
R1050	B C 4A
R1051	B C 5B
R1052	B C 5B

COMPONENT PARTS LOCATION GUIDE <MAIN/YB10359-01-02> (2/2)

REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION			REF.NO.	LOCATION		
R1053	B	C	5B	R2007	B	C	2C	R3033	B	C	4C	R4319	B	C	2C	R4862	A	C	1B	R6236	A	C	4A	TL1607	A	C	3D
R1054	B	C	5B	R2008	B	C	2C	R3034	B	C	4C	R4320	B	C	2C	R4863	A	C	1B	R6237	A	C	4A	TL1608	B	C	3C
R1055	B	C	5B	R2009	B	C	2C	R3036	B	C	5C	R4321	B	C	2B	R4864	A	C	1B	R6238	A	C	4A	TL1609	A	C	3D
R1056	B	C	5B	R2014	B	C	2D	R3037	B	C	5D	R4322	B	C	3B	R4865	A	C	1B	R6239	A	C	4A	TL1610	A	C	3D
R1057	B	C	4A	R2015	B	C	2D	R3040	B	C	3D	R4323	B	C	3C	R4866	A	C	1B	R6240	A	C	4A	TL1611	B	C	3C
R1058	B	C	4A	R2016	B	C	2D	R3041	B	C	3D	R4324	B	C	3B	R4867	A	C	1B	R6241	A	C	4A	TL1612	B	C	3D
R1059	B	C	4A	R2017	B	C	2D	R3042	B	C	3D	R4325	B	C	2B	R4868	A	C	1B	R6242	A	C	4A	TL1613	B	C	3D
R1060	B	C	4A	R2018	B	C	2C	R3043	B	C	3C	R4326	B	C	2C	R4870	A	C	2C	R6243	A	C	4A	TL1614	B	C	2C
R1066	B	C	5B	R2019	B	C	1D	R3044	B	C	3D	R4327	B	C	3B	R4871	A	C	1B	R6244	A	C	4B	TL1617	B	C	3D
R1071	B	C	4A	R2020	B	C	1D	R3045	B	C	3C	R4328	B	C	2B	R4872	A	C	2C	R6245	A	C	4B	TL1618	A	C	3D
R1072	B	C	4B	R2023	B	C	2C	R3046	B	C	3C	R4329	B	C	2B	R4874	A	C	1B	R6246	A	C	4B	TL1619	A	C	3D
R1076	B	C	4A	R2024	B	C	2C	R3047	B	C	4D	R4330	B	C	3C	R5501	A	C	2A	R6247	A	C	4A	TL1620	A	C	3D
R1077	B	C	4A	R2025	B	C	2C	R3048	B	C	4D	R4331	B	C	3B	R5503	A	C	2B	R6701	A	C	3C	TL1621	A	C	3D
R1078	B	C	4A	R2028	B	C	2C	R3049	B	C	4D	R4332	B	C	3B	R5504	A	C	2B	R6702	A	C	3C	TL1622	A	C	3D
R1079	B	C	4A	R2029	B	C	1D	R3050	B	C	4D	R4333	B	C	3B	R5505	A	C	2B	R6703	A	C	3C	TL3001	B	C	4C
R1080	B	C	4A	R2103	B	C	1C	R3051	B	C	4D	R4334	B	C	3B	R5506	A	C	2B	R6704	A	C	5B	TL3005	B	C	4C
R1081	B	C	4A	R2104	B	C	1C	R3057	B	C	4D	R4335	B	C	3B	R5507	A	C	2B	R6705	A	C	5B	TL3006	B	C	4C
R1082	B	C	4A	R2105	B	C	1C	R3059	B	C	4B	R4336	B	C	3B	R5509	A	C	3B	RA1008	B	C	5B	TL3501	B	C	5B
R1083	B	C	4A	R2106	B	C	1C	R3066	B	C	4D	R4337	B	C	3B	R5510	A	C	3A	RA1009	B	C	4A	TL4201	B	C	2B
R1302	B	C	2C	R2107	B	C	1C	R3067	B	C	4D	R4338	B	C	3A	R5511	A	C	3A	RA1010	B	C	4A	TL4202	B	C	2A
R1305	B	C	2C	R2108	B	C	1C	R3068	B	C	4D	R4339	B	C	3B	R5512	A	C	3B	RA1401	B	C	4B	TL4301	B	C	3B
R1306	B	C	2C	R2109	B	C	1C	R3069	B	C	4D	R4340	B	C	3B	R5513	A	C	3B	RA3001	B	C	4C	TL4302	B	C	3B
R1307	B	C	2C	R2110	B	C	1C	R3070	B	C	3C	R4341	B	C	3B	R5514	A	C	3B	RA3002	B	C	4C	TL4303	B	C	3B
R1308	B	C	2C	R2111	B	C	1C	R3071	B	C	5D	R4342	B	C	2B	R5515	A	C	2B	RA3003	B	C	4C	TL4304	B	C	3A
R1401	B	C	4B	R2112	B	C	1C	R3072	B	C	4D	R4343	B	C	2B	R5516	A	C	2B	RA3004	B	C	5C	TL4305	B	C	3B
R1402	B	C	4B	R2113	B	C	1C	R3073	B	C	4C	R4344	B	C	2B	R6001	A	C	3B	RA3005	B	C	5C	TL4306	B	C	3B
R1403	B	C	4B	R2114	B	C	1C	R3074	B	C	4C	R4345	B	C	3A	R6002	A	C	3B	RA4301	B	C	3A	TL4307	B	C	3B
R1404	B	C	4B	R2115	B	C	1C	R3075	B	C	4D	R4346	B	C	2B	R6003	A	C	3B	RA4302	B	C	3A	TL4308	B	C	3B
R1405	B	C	4B	R2116	B	C	1C	R3501	A	C	2C	R4347	B	C	2B	R6004	A	C	3B	RA4303	B	C	3A	TL4309	B	C	3B
R1406	B	C	4B	R2117	B	C	1C	R3502	A	C	2C	R4348	B	C	2B	R6005	A	C	3B	RA4307	B	C	3A	TL4310	B	C	3B
R1407	B	C	4B	R2118	B	C	1C	R3503	A	C	2C	R4349	B	C	2B	R6009	A	C	4A	RA4308	B	C	3A	TL4311	B	C	3B
R1408	B	C	4B	R2119	B	C	1D	R3504	A	C	2C	R4350	B	C	2B	R6010	A	C	4B	RA4309	B	C	3A	TL4312	B	C	3B
R1409	B	C	4B	R2120	B	C	1C	R3505	A	C	2C	R4351	B	C	3B	R6011	A	C	4B	RA4310	B	C	3A	TL4313	B	C	3B
R1410	B	C	4B	R2121	B	C	1D	R3506	A	C	2C	R4804	A	C	2C	R6012	A	C	4B	**OTHER**				TL4314	B	C	3B
R1411	B	C	4B	R2122	B	C	1C	R3507	A	C	2C	R4805	A	C	1C	R6013	A	C	4B	TL1001	B	C	4A	TL4316	B	C	3B
R1412	B	C	4B	R2123	B	C	1D	R3508	A	C	3C	R4806	A	C	1C	R6101	A	C	4A	TL1002	B	C	4A	TL4317	B	C	3B
R1413	B	C	4B	R2124	B	C	1C	R3509	A	C	2C	R4807	A	C	1C	R6102	A	C	4A	TL1003	B	C	4A	TL4405	B	C	3B
R1414	B	C	4B	R2125	B	C	1D	R3510	A	C	2B	R4808	A	C	1C	R6103	A	C	4A	TL1004	B	C	4A	TL4801	A	C	1C
R1415	B	C	4B	R2126	B	C	1C	R3511	A	C	3C	R4809	A	C	1C	R6106	A	C	3A	TL1005	B	C	4A	TL5501	A	C	3A
R1416	B	C	4B	R2127	B	C	1D	R3512	A	C	3C	R4810	A	C	1C	R6107	A	C	3A	TL1006	B	C	4A	TL5502	A	C	3A
R1417	B	C	5B	R2128	B	C	1C	R3521	A	C	3C	R4811	A	C	1C	R6108	A	C	3A	TL1007	B	C	4A	TL5503	A	C	3A
R1420	B	C	4B	R2129	B	C	1C	R3522	A	C	2C	R4812	A	C	1C	R6113	A	C	3A	TL1009	B	C	4A	TL5504	A	C	3A
R1421	B	C	4B	R2201	A	C	1C	R3701	A	C	3B	R4813	A	C	1C	R6114	A	C	3B	TL1010	B	C	4A	TM01	A	C	1?
R1422	B	C	4B	R2202	A	C	1C	R3702	A	C	3B	R4814	A	C	1C	R6115	A	C	3B	TL1021	B	C	4B	TM1	A	C	1?
R1423	B	C	4B	R2203	B	C	1C	R3703	A	C	3B	R4815	A	C	1C	R6116	A	C	3A	TL1022	B	C	5B	TM03	A	C	5?
R1424	B	C	4B	R2501	B	C	1B	R3706	A	C	3B	R4816	A	C	1C	R6117	A	C	3B	TL1023	B	C	4B	TM3	A	C	5?
R1425	B	C	4B	R2502	B	C	1B	R3707	A	C	3B	R4817	A	C	2C	R6118	A	C	3B	TL1024	B	C	5A	X1001	B	C	4B
R1426	B	C	4B	R2503	B	C	1B	R3708	A	C	3B	R4818	A	C	2C	R6124	A	C	4B	TL1025	B	C	5B	X1002	A	C	4A
R1427	A	C	5B	R2504	B	C	1B	R3711	A	C	3B	R4819	A	C	1C	R6201	A	C	4B	TL1026	B	C	5B	X1401	B	C	4B
R1601	B	C	2D	R2505	B	C	1C	R3712	A	C	3C	R4820	A	C	1C	R6202	A	C	4B	TL1027	B	C	4B	X3001	B	C	4C
R1602	B	C	2D	R2506	B	C	2C	R3713	A	C	2B	R4821	A	C	1C	R6203	A	C	4B	TL1029	B	C	4A	X3002	B	C	4C
R1603	B	C	2C	R2507	B	C	1C	R3714	A	C	2B	R4822	A	C	2C	R6204	A	C	4B	TL1030	B	C	4B	X5501	A	C	2A
R1604	B	C	2D	R2508	B	C	2C	R3715	A	C	2B	R4823	A	C	2C	R6205	A	C	4B	TL1031	B	C	4B	ZP-GND	A	C	2A
R1605	B	C	2C	R2509	B	C	2C	R3716	A	C	2B	R4824	A	C	1C	R6206	A	C	4B	TL1032	B	C	4A				
R1609	B	C	3C	R2510	B	C	2C	R3717	A	C	2B	R4825	A	C	2C	R6207	A	C	4B	TL1033	B	C	4A				
R1610	B	C	3C	R2511	B	C	2C	R3718	A	C	2B	R4826	A	C	2C	R6208	A	C	4B	TL1034	B	C	4A				
R1611	B	C	3C	R2512	B	C	2C	R3719	A	C	2B	R4827	A	C	1C	R6209	A	C	4B	TL1035	B	C	4B				
R1612	B	C	3C	R2513	B	C	2C	R3724	A	C	3B	R4828	A	C	2C	R6210	A	C	3C	TL1401	B	C	4B				
R1613	B	C	3C	R3002	B	C	4C	R4201	B	C	2B	R4829	A	C	1C	R6211	A	C	3C	TL1402	B	C	4B				
R1614	B	C	3C	R3003	B	C	4D	R4202	B	C	2B	R4830	A	C	2C	R6212	A	C	3C	TL1403	B	C	4B				
R1615	B	C	3C	R3004	B	C	4C	R4203	B	C	2B	R4831	A	C	2C	R6213	A	C	3C	TL1404	B	C	4B				
R1616	B	C	3D	R3005	B	C	4C	R4205	B	C	2A	R4833	A	C	2C	R6214	A	C	3C	TL1405	B	C	5B				
R1617	B	C	3C	R3006	B	C	4C	R4206	B	C	2A	R4836	A	C	2C	R6215	A	C	3C	TL1406	B	C	4B				
R1618	B	C	3C	R3007	B	C	4C	R4207	B	C	3A	R4837	A	C	2C	R6216	A	C	3C	TL1407	B	C	4B				
R1619	B	C	2C	R3008	B	C	4C	R4208	B	C	2A	R4839	A	C	2C	R6217	A	C	4B	TL1408	B	C	5B				
R1620	B	C	2C	R3009	B	C	4C	R4301	B	C	3B	R4840	A	C	2C	R6218	A	C	4B	TL1409	B	C	5B				
R1621	B	C	2D	R3010	B	C	4C	R4302	B	C	3A	R4841	A	C	2C	R6219	A	C	5B	TL1410	B	C	5B				
R1622	B	C	3C	R3011	B	C	4C	R4303	B	C	2B	R4842	A	C	2C	R6220	A	C	5B	TL1411	B	C	5B				
R1624	B	C	2C	R3013	B	C	5C	R4304	B	C	2B	R4843	A	C	2C	R6221	A	C	5B	TL1412	A	C	3B				
R1625	A	C	2C	R3014	B	C	5C	R4305	B	C	2B	R4844	A	C	2C	R6222	A	C	5B	TL1413	A	C	3B				
R1626	A	C	2C	R3015	B	C	5C	R4306	B	C	2B	R4845	A	C	2C	R6223	A	C	5B	TL1414	B	C	4B				
R1628	B	C	2C	R3016	B	C	5C	R4307	B	C	2B	R4846	A	C	2B	R6224	A	C	4B	TL1415	B	C	5B				
R1629	B	C	2D	R3017	B	C	5C	R4308	B	C	2B	R4847	A	C	2C	R6225	A	C	4B	TL1416	B	C	4B				
R1630	B	C	3D	R3018	B	C	5C	R4309	B	C	2B	R4849	A	C	2C	R6226	A	C	4B	TL1417	A	C	4B				
R1631	B	C	3D	R3019	B	C	5C	R4310	B	C	2B	R4850	A	C	2C	R6227	A	C	4A	TL1418	B	C	4B				
R1635	B	C	2C	R3020	B	C	5C	R4311	B	C	2B	R4852	A	C	1B	R6228	A	C	4A	TL1419	B	C	4B				
R1636	B	C	2C	R3025	B	C	3C	R4312	B	C	2B	R4854	A	C	1C	R6229	A	C	4A	TL1420	A	C	5B				
R1637	B	C	2C	R3026	B	C	3C	R4313	B	C	2B	R4855	A	C	1C	R6230	A	C	4A	TL1601	B	C	2C				
R1643	B	C	2C	R3027	B	C	4C	R4314	B	C	2B	R4856	A	C	1C	R6231	A	C	4A	TL1602	B	C	3C				
R2001	B	C	1D	R3029	B	C	4C	R4315	B	C	2B	R4857	A	C	2C	R6232	A	C	4A	TL1603	B	C	3C				
R2004	B	C	1D	R3030	B	C	4C	R4316	B	C	2B	R4858	A	C	2C	R6233	A	C	4A	TL1604	B	C	2C				
R2005	B	C	1D	R3031	B	C	4C	R4317	B	C	2C	R4859	A	C	2C	R6234	A	C	4A	TL1605	A	C	3D				
R2006	B	C	2C	R3032	B	C	4C	R4318	B	C	2B	R4860	A	C	2C	R6235	A	C	4A	TL1606	A	C	3D				

COMPONENT SIDE(A)

0 1 MAIN PWB
YB10359-01-02



4.25 MONITOR CIRCUIT BOARD

FOIL SIDE(B)



COMPONENT SIDE(A)



COMPONENT PARTS LOCATION GUIDE <MONITOR/YB10360-01-03>

REF.NO.	LOCATION
CAPACITOR	
C1	A C 2A
C10	B C 3C
C11	B C 3C
C7101	B C 4B
C7102	A C 4A
C7601	B C 3B
C7602	A C 3A
C7603	B C 2A
C7604	B C 2A
C7605	B C 2A
C7606	B C 2A
C7607	B C 2A
C7608	B C 2A
C7609	B C 2A
C7610	B C 2A
C7611	B C 3A
C7612	B C 3A
C7613	B C 3A
C7614	B C 3A
C7615	B C 3A
C7616	B C 3B
C7617	A C 3A
C7618	A C 3A
C7619	B C 3B
C7620	B C 3A
C7621	B C 3B
C7622	B C 3B
C7623	B C 3B
C7624	B C 4B
C7625	B C 4B
C7626	B C 4B
C7627	B C 3B
C7628	A C 3B
C7629	A C 2B
C7630	B C 2C
C7631	B C 2C
C7632	B C 3C
C7633	B C 3C
C7634	B C 2B
C7635	B C 2C
C7636	A C 2B
C7637	B C 2C
C7638	B C 3B
C7639	B C 4B
C7640	B C 3B
C7641	B C 1C
C7642	A C 4A
C7643	A C 3B
C7644	A C 3B
C7645	A C 2B
CONNECTOR	
CN761	B C 4C
CN762	B C 3C
CN763	B C 4A
CN764	B C 2C
CN765	B C 2B
CN766	A C 4D
DIODE	
D1	A C 4A
D10	B C 3C
D11	B C 3C
D7601	B C 2C
D7602	B C 5C
IC	
IC7101	A C 4A
IC7601	B C 3A
IC7602	B C 4B
IC7603	B C 3B
IC7604	A C 3A
COIL	
L10	B C 3C
L7601	B C 2A
L7602	B C 3B
L7603	A C 3A
L7604	B C 2C
L7605	B C 3C
L7606	B C 3C
L7607	B C 2B
TRANSISTOR	
Q10	B C 4C
Q7101	B C 4B
Q7102	B C 4B
Q7601	A C 3B
Q7602	A C 3B
Q7603	A C 2B
Q7604	A C 2B
Q7605	B C 2C
Q7606	B C 2C
Q7607	B C 4A
Q7608	B C 4A
Q7609	B C 3B
Q7610	B C 3B
RESISTOR	
R1	A C 3B
R2	A C 4B
R3	A C 2A
R4	A C 2A
R5	A C 3A
R6	A C 3A
R7	A C 3B
R8	A C 3B
R9	A C 3B
R10	A C 3B
R18	B C 4C
R19	B C 4C
R20	B C 3C
R21	B C 3C
R22	B C 3C
R23	B C 3C
R25	B C 3C
R26	B C 4C
R28	B C 3C
R7101	B C 4B
R7110	B C 4B
R7111	B C 4B
R7113	B C 4B
R7114	B C 4B
R7115	B C 4B
R7116	B C 4B
R7601	A C 3A
R7602	B C 3A
R7603	B C 3A
R7604	B C 4B
R7605	B C 4C
R7606	B C 5C
R7608	B C 4B
R7609	B C 4B
R7610	B C 3B
R7611	B C 3B
R7612	A C 3B
R7613	A C 3B
R7614	A C 3B
R7615	A C 3B
R7616	A C 3B
R7617	A C 2B
R7618	A C 3B
R7619	A C 2B
R7621	B C 2C
R7622	B C 2C
R7623	B C 2C
R7624	A C 2B
R7625	B C 2B
R7626	B C 3A
R7627	B C 3B
R7628	B C 4A
R7629	B C 4A
R7630	A C 4A
R7631	A C 2B
R7632	B C 3B
R7633	A C 1C
R7634	B C 4B
R7635	B C 4B
R7636	B C 3A
R7637	A C 3A
R7638	B C 3A
R7640	A C 3A
R7643	A C 4A
R7644	B C 4A
R7646	A C 3A
R7650	A C 3C
R7651	B C 4C
R7652	B C 4C
OTHER	
BT1	A C 2C
J7601	A D 5C
SW1	A C 4B
SW2	A C 2A
SW3	A C 2A
SW4	A C 4A
SW5	A C 3A
SW6	A C 4B
SW7	A C 3A
SW8	A C 3A
SW9	A C 3B
SW10	A C 3B
SW7601	A D 1C
TM04	A C 5D
TM4	A C 5D
ZP1-2	B C 4C
ZP1-3	B C 4C
ZP1-4	B C 4C
ZP1-5	B C 4A
ZP1-7	B C 3B
ZP1-9	B C 4B
ZP3-9	B C 4A
ZP4-9	B C 1A
ZP4-9	B C 2C
ZP1-11	B C 3B
ZP1-12	B C 3B
ZP1-13	B C 3A
ZP1-14	B C 3B
ZP1-15	B C 3B
ZP1-17	B C 3B
ZP1-18	B C 3B
ZP1-19	B C 3B
ZP1-20	B C 3B
ZP1-21	B C 3B
ZP1-22	B C 3C
ZP1-23	B C 3C
ZP1-36	B C 2C
ZP2-10	B C 2C
ZP3-13	B C 4A
ZP3-17	B C 4A
ZP3-18	B C 4A
ZP3-19	B C 4A
ZP3-20	B C 4B
ZP4-17	B C 2C
ZP4-18	B C 3A
ZP4-22	B C 2B
ZP4-23	B C 3B
ZP4-24	B C 2B
ZP4-25	B C 2B
ZP4-33	B C 3A

FOIL SIDE(B)

03 LCD BL PWB
YB10325-01-03



COMPONENT SIDE(A)

03 LCD BL PWB
YB10325-01-03



4.27 CCD AND JUNCTION CIRCUIT BOARDS

-CCD-

FOIL SIDE(B)



COMPONENT SIDE(A)



-JUNCTION-

FOIL SIDE(B)



COMPONENT SIDE(A)



4.28 JACK AND VF CIRCUIT BOARDS

-JACK-

FOIL SIDE(B)

0 6 JACK PWB
YB10357-01-01



COMPONENT SIDE(A)

0 6 JACK PWB
YB10357-01-01



-VF-

FOIL SIDE(B)

0 8 VF PWB
YB20910



COMPONENT SIDE(A)

0 8 VF PWB
YB20910



4.29 REAR CIRCUIT BOARD

FOIL SIDE(B)



COMPONENT SIDE(A)



FOIL SIDE(B)

1 0 DSC PWB
YB20915-01-03



COMPONENT PARTS LOCATION GUIDE
<DSC/YB20915-01-03>

REF.NO.	LOCATION		
CAPACITOR			
C8001	B	C	2C
C8002	B	C	2C
C8003	A	C	1B
C8004	A	C	1B
C8005	A	C	1B
C8006	A	C	2B
C8007	A	C	1B
C8008	A	C	2B
C8010	B	C	1B
C8011	B	C	1B
C8014	B	C	2B
C8015	B	C	1B
C8016	B	C	1B
C8017	B	C	1B
C8018	B	C	1B
C8019	B	C	2B
C8020	B	C	2C
C8021	B	C	1C
C8022	B	C	1A
C8023	B	C	1A
C8024	B	C	2A
C8025	B	C	1A
C8026	B	C	2A
C8027	B	C	1A
C8028	B	C	1A
C8029	B	C	1A
C8030	B	C	1B
C8301	A	C	1A
C8302	A	C	1A
C8303	A	C	1A
C8304	A	C	1A
C8305	A	C	1A
C8306	A	C	1A
C8307	A	C	1A
C8308	A	C	1A
C8309	A	C	1A
C8310	A	C	1A
C8311	A	C	1A
CONNECTOR			
CN8001	B	C	2B
CN8002	A	C	2A
DIODE			
D8001	B	C	1A
IC			
IC8001	B	C	1B
IC8002	A	C	2B
IC8003	A	C	1B
IC8004	B	C	1A
IC8006	B	C	1A
IC8007	B	C	1A
IC8301	A	C	1A
COIL			
L8001	B	C	2C
L8002	B	C	2C
L8003	A	C	1B
L8004	A	C	2B
L8005	B	C	2C
L8006	B	C	1A
L8301	A	C	1A
L8302	A	C	1A
TRANSISTOR			
Q8001	B	C	1A
Q8002	B	C	1A
RESISTOR			
R8001	B	C	1B
R8002	B	C	1C
R8003	B	C	1C
R8005	B	C	1A
R8006	B	C	1A
R8007	B	C	1A
R8008	B	C	1A
R8009	B	C	1A
R8010	B	C	1A
R8016	B	C	1A
R8017	B	C	1C
R8020	B	C	1A
R8022	B	C	1A
R8025	B	C	1A
R8026	B	C	1B
R8027	B	C	1A
R8028	B	C	1A
R8029	B	C	1A
R8030	B	C	1A
R8031	B	C	1A
R8032	B	C	1A
R8034	B	C	1B
R8036	B	C	1B
R8037	B	C	1A
R8038	B	C	1C
R8042	B	C	1B
R8043	B	C	1C
R8046	B	C	1A
R8048	B	C	1B
R8050	B	C	1B
R8051	B	C	1B
R8053	B	C	1B
R8054	B	C	1B
R8055	B	C	1B
R8056	B	C	1A
R8057	B	C	1A
R8058	B	C	1B
R8059	B	C	1A
R8060	B	C	1C
R8061	B	C	1B
R8062	B	C	1C
R8063	B	C	1B
R8064	B	C	1A
R8065	B	C	1B
R8066	B	C	1A
R8067	A	C	1B
R8068	B	C	2A
R8069	B	C	2B
R8070	B	C	2A
R8071	B	C	1A
R8073	B	C	1A
R8074	B	C	1A
R8075	B	C	1A
R8076	B	C	2A
R8301	A	C	1A
R8302	A	C	1A
R8303	A	C	1A
R8305	A	C	1A
R8306	A	C	1A
R8307	A	C	1A
R8308	A	C	1A
R8309	A	C	1A
R8310	A	C	1A
R8311	A	C	1A
RA8001	B	C	1A
RA8002	B	C	1A
RA8003	B	C	1A
RA8004	B	C	1A
OTHER			
TL8001	B	C	1C
TL8002	B	C	1C
TL8003	B	C	1A
TL8004	B	C	1B
TL8005	B	C	2B
TL8006	B	C	2B
TL8007	B	C	1C
TL8008	B	C	1C
TL8009	B	C	1C
TL8010	B	C	1B
TL8011	B	C	1C
TL8012	B	C	1C
TL8013	A	C	1C
TL8014	B	C	1B
TL8016	B	C	1B
TL8017	B	C	1A
TL8018	B	C	2B
TL8019	B	C	1B
TL8020	B	C	2B
TL8021	B	C	2B
TL8302	A	C	1A
TL8303	A	C	1A
TL8304	A	C	1A
TM03	A	C	2C
TM3	A	C	2C
X8002	B	C	1C
X8301	A	C	1A

COMPONENT SIDE(A)

1 0 DSC PWB
YB20915-01-03



4.31 VOLTAGE CHARTS

<SYSCON>

MODE PIN NO.	REC	PLAY
IC1001	-	-
IC1002	-	-
IC1003		
1	3.0	3.0
2	0.7	0.7
3	3.1	3.1
4	0	0
5	0.6	0.6
6	3.0	3.0
7	3.0	3.0
8	3.1	3.1
IC1004		
1	1.4	1.4
2	0	0
3	1.3	1.3
4	0	0
5	3.0	3.0
IC1005		
1	0	0
2	3.0	3.0
3	0	0
4	3.0	3.0
5	3.0	3.0
IC1006		
1	2.7	2.7
2	0	0
3	0.4	0.4
4	3.0	3.1
5	3.1	3.1
6	3.1	3.1
7	1.4	1.4
8	1.4	1.4
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	3.0	3.0
20	2.9	2.8
IC1007		
1	3.0	3.0
2	3.0	3.0
3	3.0	3.0
4	3.0	3.0
5	3.0	3.0
6	3.0	3.0
7	0	0
8	3.0	3.0
9	3.0	3.0
10	3.0	3.0
11	0	0
12	0	0
13	3.0	3.0
14	3.0	3.0

MODE PIN NO.	REC	PLAY
IC1008		
1	3.0	3.0
2	3.0	3.0
3	0	0
4	0	0
Q1001		
E	0	0
C	0	0
B	0	0
Q1002		
E	0	0
C	3.1	3.1
B	0.6	0.5
Q1003		
E	0	0
C	0	0.4
B	0	0
Q1005		
D	3.0	3.0
S	0	0
G	3.0	3.0
Q1006		
E	3.1	3.1
C	3.0	0
B	0	3.0
Q1007		
E	0	0
C	0	3.1
B	3.0	0
Q1008		
E	3.0	3.0
C	0	0
B	3.0	3.0
Q1009		
E	0	0
C	3.0	3.0
B	0	0

<PC IF>

MODE PIN NO.	REC	PLAY
IC1301	-	-
IC1302	-	-
IC1303		
1	0	0
2	3.0	3.0
3	0	0
4	0	0
5	0	0
6	3.0	3.0
7	0	0
8	0	0
9	0	0
10	3.0	3.0
11	0	0
12	0	0
13	3.0	3.0
14	3.0	3.0
Q1301		
E	0	0
C	0.4	0
B	0	0

<DECK CPU>

MODE PIN NO.	REC	PLAY
IC1401	-	-
IC1402	-	-
Q1401		
E	3.1	3.1
C	3.1	3.1
B	3.1	3.1
Q1402		
1(E)	0	0
2(B)	3.1	3.1
3(E)	3.1	3.1
4(C)	2.8	2.8
5(C)	0	0
Q1403		
1(E)	0	0
2(B)	0	0
3(E)	3.0	3.0
4(C)	0	0
5(C)	3.1	3.1

<MDA>

MODE PIN NO.	REC	PLAY
IC1601		
1	0	0
2	0.8	0.8
3	0.8	0.8
4	0.8	0.8
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	4.8	4.8
13	0.4	0.4
14	0.4	0.4
15	0.4	0.5
16	0	0.6
17	0.7	0.8
18	11.1	11.1
19	1.5	1.5
20	1.5	1.5
21	1.5	1.5
22	1.5	1.5
23	1.5	1.5
24	1.5	1.5
25	1.5	1.5
26	1.6	1.5
27	1.5	1.5
28	1.5	1.5
29	3.1	3.1
30	0	0
31	0.7	0.7
32	0.6	0.6
33	1.6	1.6
34	3.1	3.1
35	0	0
36	0	0
37	0	0
38	0	0
39	0	0

MODE PIN NO.	REC	PLAY
40	1.7	1.7
41	0.7	0.7
42	0.7	0.7
43	0	1.0
44	0.6	0.7
45	0	0
46	0	0
47	2.8	2.8
48	1.2	1.2
49	1.6	1.5
50	1.5	1.5
51	1.5	1.5
52	1.5	1.5
53	1.6	1.5
54	0.4	0.4
55	0	0
56	0.8	0.8
57	0.8	0.8
58	0.8	0.8
59	0.8	0.8
60	1.2	1.1
61	0.4	0.4
62	0	0
63	11.1	11.1
64	1.7	1.7
IC1602		
1	-	-
2	3.1	3.1
3	-	-
4	0	0
5	-	-
6	0	0
7	-	-
8	3.1	3.1
Q1601		
1(E)	0	0
2(B)	0	0
3(E)	4.8	4.8
4(C)	0	0
5(C)	4.8	4.8

<AUDIO>

MODE PIN NO.	REC	PLAY
IC2001		
1	2.1	0.7
2	2.0	0
3	2.0	0
4	2.1	0
5	1.5	1.5
6	1.5	1.5
7	1.5	1.5
8	0	0
9	3.1	3.1
10	0.7	1.5
11	0.7	1.5
12	0.7	1.5
13	0.7	1.5
14	1.5	1.5
15	1.5	1.5
16	0.6	1.5
17	1.4	1.5
18	1.5	1.5

MODE PIN NO.	REC	PLAY
19	1.3	1.5
20	1.5	1.5
21	1.3	1.3
22	2.4	2.4
23	4.8	4.8
24	0	0
25	0	0
26	0	0
27	3.1	3.1
28	0	0
29	1.5	0
30	1.3	1.3
31	1.5	0
32	2.9	2.9
33	3.0	3.0
34	1.5	1.5
35	1.5	1.6
36	1.5	1.4
37	3.0	3.0
38	0	2.4
39	0	0
40	0	2.4
41	0	0
42	0	0
43	4.8	4.8
44	1.5	1.5
45	2.0	0
46	2.0	0
47	2.1	0
48	2.0	0.6
49	2.1	0.5
50	2.1	0.5
51	2.1	0
52	2.7	0
53	2.0	0
54	2.0	0
55	4.1	4.2
56	2.0	2.1
57	0	0
58	4.1	4.2
59	2.0	0
60	2.0	0
61	2.0	0
62	2.0	0
63	2.0	1.0
64	2.0	0
Q2001		
1(E)	0	0
2(E)	0	0
3(B)	0	0
4(C)	0	0
5(B)	0	0
6(C)	0	0
Q2002		
E	4.1	4.2
C	4.8	4.8
B	4.8	4.8

<DVMAIN>

MODE PIN NO.	REC	PLAY
IC3001	-	-
IC3005		
1	0	0.4
2	0	0.4
3	0	0
4	2.1	2.1
5	1.1	1.2
6	1.2	1.6
7	3.1	3.1
8	1.2	1.6
Q3001	-	-
Q3002	-	-

<PRE/REC>

MODE PIN NO.	REC	PLAY
IC3501		
1	0	0
2	0.5	0.5
3	0	0
4	0	1.6
5	2.5	2.5
6	2.3	1.6
7	1.4	0
8	0	0
9	1.4	3.1
10	1.9	1.9
11	3.1	3.1
12	0	0
13	4.8	4.8
14	0	0
15	0	0
16	0	0
17	0	0
18	3.6	1.7
19	3.3	1.7
20	3.3	1.7
21	3.6	1.7
22	0	0
23	3.6	1.7
24	3.3	1.7
25	3.4	1.7
26	3.6	1.7
27	0	0
28	1.9	2.3
29	3.3	1.7
30	3.3	1.7
31	2.2	2.7
32	0	0
33	0	0
34	0	0
35	1.8	1.8
36	0.4	0.4
37	3.1	3.1
38	0	3.1
39	3.1	3.1
40	1.5	1.5
41	0	3.1
42	3.1	0
43	4.8	4.8
44	3.0	0
45	0.6	0

MODE PIN NO.	REC	PLAY
46	0	2.0
47	0	2.1
48	4.4	3.1
49	4.6	2.8
50	0	1.6
51	1.2	1.2
52	1.1	1.7
53	0	0
54	3.1	2.6
55	2.4	1.9
56	1.1	1.1
57	2.5	1.9
58	2.5	1.3
59	0	0
60	1.2	1.2
61	3.6	1.9
62	2.4	1.9
63	2.5	1.3
64	2.5	1.9
IC3502		
1	0.5	0
2	0.5	0
3	0	0
4	0.7	0
5	3.1	3.1

<V OUT>

MODE PIN NO.	REC	PLAY
IC3701		
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-
8	-	-
9	2.3	2.3
10	0	0
11	2.1	2.1
12	2.1	2.1
13	4.8	4.8
14	1.9	1.9
15	1.9	1.9
16	4.8	4.8
Q3701	-	-
Q3702		
1(E)	0	0
2(B)	0	0
3(C)	0	0
4(E)	4.8	4.8
5(B)	4.4	4.4
6(C)	4.4	4.4

<CAM.DSP>

MODE PIN NO.	REC	PLAY
IC4201		
1	0	0
2	1.3	0
3	1.8	3.0
4	1.8	3.0
5	1.5	3.1
6	1.3	3.1
7	0	0
8	0.4	0
9	0.6	0
10	0.4	0
11	0	0
12	0	0
13	3.1	3.0
14	0	0
15	0	0
16	1.2	1.2
17	3.0	3.1
18	3.1	3.1
19	2.5	2.5
20	3.0	3.0
21	2.2	2.2
22	2.2	2.2
23	0	0
24	3.0	3.0
25	0	0
26	0	0
27	3.0	3.0
28	2.0	0.4
29	2.0	0.4
30	2.0	1.7
31	2.0	0.5
32	1.3	0
33	3.0	3.1
34	0	0
35	0	0
36	0	0
37	1.5	0.4
38	2.0	0.4
39	0.9	0.5
40	3.0	3.0
41	0	0
42	0	0
43	3.0	3.0
44	3.0	3.0
45	0	0
46	3.0	3.0
47	1.5	0
48	3.0	3.0
IC4202		
1	4.8	4.8
2	0	0
3	1.2	1.2
4	3.0	3.0
5	4.8	4.8
IC4301	-	-
IC4302		
1	1.2	0.8
2	0	0
3	1.5	1.4
4	0.7	0.9
5	0.6	0.8
6	0.7	0.9

MODE PIN NO.	REC	PLAY
7	0.7	0.8
8	1.0	1.2
9	0.9	1.2
10	1.3	1.8
11	1.7	1.1
12	1.7	1.2
13	1.4	1.1
14	1.4	1.2
15	1.3	1.3
16	0	0.4
17	2.8	2.8
18	0	3.0
19	3.1	3.1
20	0.8	0
21	3.1	3.1
22	2.8	2.8
23	2.8	2.8
24	0	0
25	1.3	1.3
26	1.5	1.4
27	1.4	1.4
28	1.6	1.4
29	1.8	1.5
30	1.5	1.8
31	1.0	1.4
32	1.2	1.6
33	0.8	1.1
34	0.9	1.2
35	0.8	1.1
36	0.8	1.2
37	1.6	1.6
38	0	0
Q4301		
1(E)	0.9	0.9
2(E)	0.9	0.9
3(B)	0	0
4(C)	0	0
5(B)	0	0.4
6(C)	0	0
Q4302		
1(E)	1.1	1.1
2(E)	1.9	0.9
3(B)	0	0
4(C)	0	0
5(B)	0.5	0.6
6(C)	0	0

<OP DRV>

MODE PIN NO.	REC	PLAY
IC4802		
1	2.9	2.9
2	2.6	2.6
3	2.6	0
4	0	0
5	2.6	2.6
6	2.6	2.6
7	2.6	2.6
8	4.8	4.8
IC4803		
1	1.0	1.0

MODE PIN NO.	REC	PLAY
2	0	0
3	0	0
4	0	0
5	2.6	2.6
6	2.6	2.6
7	2.1	2.9
8	4.8	4.8
IC4804		
1	0.9	3.5
2	2.0	3.0
3	2.0	3.0
4	0	0
5	1.2	3.0
6	1.2	3.0
7	1.8	0
8	4.8	4.8
IC4851		
1	0	0
2	0.6	0.6
3	0	0.4
4	0	0
5	0	0.4
6	0.4	0
7	0	0
8	3.1	3.1
9	4.7	4.8
10	0	0
11	0	0
12	0	0
13	4.7	4.8
14	0	0
15	0	0
16	0	0.4
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	4.8	4.8
24	2.1	1.1
25	0	0
26	2.2	0.5
27	4.8	4.8
28	2.1	0.5
29	0	0
30	1.8	0.5
31	3.1	3.1
32	0	0
33	0	0
34	0	0
35	3.0	3.0
36	1.5	1.5
37	1.5	1.5
38	3.0	3.0
Q4801		
E	0	0
C	2.3	2.3
B	1.0	1.0
Q4802		
E	0	0
C	1.2	3.0
B	0	0

MODE PIN NO.	REC	PLAY
Q4803		
E	0	0
C	4.8	4.8
B	0	0
Q4804		
E	4.8	4.8
C	1.2	3.0
B	4.8	4.8
Q4805		
E	4.8	4.8
C	1.2	3.0
B	4.8	4.8
Q4806		
E	1.2	0
C	4.8	4.8
B	1.8	0
Q4851		
E	0	0
C	3.5	3.5
B	0	0

<TG>

MODE PIN NO.	REC	PLAY
IC5501	-	-

<REG>

MODE PIN NO.	REC	PLAY
IC6001	-	-
IC6101	-	-
Q6001		
E	0	0
C	-	-
B	3.1	3.1
Q6002	-	-
Q6004	-	-
Q6201		
D	11.1	11.1
S	7.8	7.8
G	3.1	3.1
Q6202		
E	3.1	3.1
C	2.5	2.5
B	2.4	2.4
Q6203		
D	11.1	11.1
S	9.1	9.1
G	1.8	1.8
Q6204		
D	11.1	11.0
S	6.1	6.0
G	4.9	4.9
Q6205		
E	4.8	4.8
C	0	0
B	4.8	4.8
Q6206		
E	0	0
C	4.8	4.8
B	0	0

MODE PIN NO.	REC	PLAY
Q6207	-	-
Q6208		
D	11.1	11.1
S	-	-
G	-	-
Q6210		
D	11.1	11.1
S	10.1	10.1
G	-	-
Q6211		
D	11.1	11.1
S	7.7	7.7
G	0	0
Q6212	-	-
Q6213	-	-
Q6214	-	-
Q6215	-	-
Q6216	-	-
Q6217	-	-
Q6701		
D	11.1	11.1
S	11.1	11.1
G	0	0

<JACK>

MODE PIN NO.	REC	PLAY
IC501		
1	1.9	1.9
2	2.0	1.9
3	1.9	1.9
4	0	0
5	1.9	1.9
6	1.9	1.9
7	1.5	1.5
8	4.8	4.8
IC502		
1	4.6	4.6
2	0	0
3	4.8	4.8
Q501		
E	0	0
C	4.3	4.3
B	-	-

<DSC>

MODE PIN NO.	REC	PLAY
IC8001	-	-
IC8002		
1	3.1	3.1
2	0	0
3	3.1	3.1
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	3.1	3.1
10	0	0
11	0	0

MODE PIN NO.	REC	PLAY
12	0	0
13	0	0
14	3.1	3.1
15	0	0
16	3.1	3.1
17	3.1	3.1
18	3.1	3.1
19	3.1	3.1
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0
27	3.1	3.1
28	0	0
29	0	0
30	0	0
31	0	0
32	0	0
33	0	0
34	0	0
35	0	0
36	0	0
37	0	0
38	0	0
39	0	0
40	0	0.4
41	0	0
42	0	0
43	3.1	3.1
44	0	0
45	0	0
46	0	0
47	0	0
48	0	0
49	3.1	3.1
50	0	0
51	0	0
52	0	0
53	0	0
54	0	0
IC8003		
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	3.1	3.1
12	3.0	3
13	0	0
14	0	0
15	3.5	0.5
16	0	0
17	0	0
18	0	0
19	0	0

MODE PIN NO.	REC	PLAY
20	0	0
21	0	0
22	0	0
23	0	0
24	3.1	3.1
25	0	0
26	3.1	3.1
27	0	0
28	3.1	3.1
29	0.9	0.6
30	0	0
31	0	0
32	0	0
33	0	0
34	0	0
35	0	0
36	0	0
37	3.1	3.1
38	0	0
39	0	0
40	0	0.4
41	0	0.4
42	0	0.4
43	0	0
44	0	0
45	0	0
46	0	0
47	3.1	3.1
48	0	0
IC8004	-	-
IC8007	-	-
Q8001	-	-

<CCD>

MODE PIN NO.	EE
IC5201	
1	-6.2
2	0
3	0
4	0
5	0
6	8.3
7	12.0
8	8.0
9	0
10	9.9
11	1.5
12	1.2
13	7.8
14	-6.6
Q5201	
E	7.3
C	12.0
B	8.0
Q5202	
E	0
C	8.3
B	0

<BW VF>

MODE PIN NO.	EE
IC7001	
1	3.0
2	3.0
3	0
4	0
5	1.0
6	2.2
7	1.6
8	1.5
9	1.3
10	0
11	0
12	0
13	3.0
14	7.5
15	3.0
16	3.0
17	5.8
18	2.0
19	1.9
20	9.1
21	0
22	1.6
23	3.0
24	1.5
25	1.8
26	1.8
27	3.5
28	0
29	11.0
30	0
31	0
32	0
33	0
34	0

MODE PIN NO.	EE
35	0
36	0.8
37	0
38	0
39	0
40	11.2
41	0
42	0
43	3.0
44	3.0
45	1.5
46	0.6
47	0
48	0
Q7001	
1(E)	0.6
2(E)	1.2
3(B)	0
4(C)	0
5(B)	1.2
6(C)	1.2

<LCD BL>

MODE PIN NO.	EE
Q7501	
E	0
C	4.4
B	0.4
Q7502	
E	0
C	4.4
B	0.4
Q7503	
E	4.6
C	4.5
B	0
Q7504	
E	0
C	0
B	0.6

<MONITOR>

MODE PIN NO.	EE
IC7101	-
IC7601	
1	2.5
2	7.2
3	2.4
4	2.4
5	2.4
6	2.4
7	2.4
8	2.4
9	2.4
10	12.0
11	0
12	5.8
13	6.0
14	6.1

MODE PIN NO.	EE
15	6.0
16	6.1
17	6.0
18	6.1
19	6.1
20	1.6
21	1.5
22	1.5
23	1.2
24	0.4
25	0
26	0
27	0.8
28	1.4
29	0
30	0.7
31	0
32	0.5
33	0
34	1.5
35	0
36	3.0
37	0
38	0
39	3.0
40	0.7
41	1.5
42	3.0
43	3.1
44	0
45	3.0
46	2.8
47	2.5
48	2.5
IC7602	
1	11.8
2	1.7
3	1.9
4	0
5	4.8
6	4.8
7	7.2
8	12.0
IC7603	
1	3.0
2	0.7
3	3.0
4	0
5	0.7
6	3.0
7	3.1
8	3.0
IC7604	
1	0
2	3.0
3	2.4
4	0.4
5	3.0
6	0
7	0
8	0
9	0.5
10	0

MODE PIN NO.	EE
11	0
12	0
13	0
14	3.0
Q7101	
E	0
C	0
B	1.1
Q7102	-
Q7601	
E	-9.1
C	0
B	-8.6
Q7602	
E	-8.1
C	-15.3
B	-8.6
Q7603	
E	-8.6
C	-0.5
B	-8.1
Q7604	
E	-8.6
C	-14.7
B	-9.1
Q7605	
E	3.0
C	3.0
B	0
Q7606	
E	-15.3
C	-15.3
B	3.0
Q7608	
E	0
C	0
B	3.0
Q7609	
E	0
C	4.7
B	0
Q7610	
E	4.8
C	1.2
B	4.8

4.32 POWER SYSTEM BLOCK DIAGRAM



4.33 VIDEO SYSTEM BLOCK DIAGRAM



A | B | C | D 4-73 4-74 | E | F | G | H

0 1 MAIN

IC3001(DVMAIN)

TO CAM.DSP

TO CAM.DSP

TO CAM.DSP

TO TG

TO CAM.DSP

TO VTRCPU

TO CAM.DSP

YSO0 YSO3 BRSO0 BRSO3 OUTH OUTV YSI0 YSI3 BRSI0 BRSI3 INH INV

CLK27 OSC27I

AD0 AD15 XRST CPUALE XCPUDSTB0 XCPUDSTB1 XCPURW CPUWAIT

HOST CPU I/F

VIDEO I/F (VBID DET RAM)

COMPRESS (DCT.VLC VLD WORK RAM)

OUTER ECC (ENC/DET)

RAM (SUB/AUX)

INNER ECC (ENC/DEC)

FORMATTER (Formatting Sync Detect ID Protect De-formatting)

RAM (CLOCK CONV)

RAM (CLOCK CONV)

RAM (CLOCK CONV)

RAM (CLOCK CONV)

D-RAM I/F

IEE1394 LINK (ISO/ ASYNC FIFO)

AUDIO (WORK RAM PROGRAM RISC CORE)

(DECK_DSP)

PWMAUDIO RECCTL RECDATA RECCLK SPA HSP HID TRKREF FRREF

FSPLLCTL RECCTL RECDATA RECCLK SPA

TO VTRCPU

TSR FRP

DAAOUT0 DAAOUT1 DISCRI

IC3005 AMP+ AMP- AMPB

TO VTRCPU

HID3 PBH RECH HID1 REC_CLK REC_DTA REC_CTL

IC3502

REC_CTL

TO JIG CONN. (CN105)

ENV_OUT

AGC_OUT RECCADJ

(TO CAM.DSP)

IC3501

HID3 PB_H REC_H HID1 REC_CLK REC_DATA R_CTL MONI_CHG

(PRE/REC)

PB_MONI AGC_BUFF_OUT REC_GAIN

Y2 X2 X1 Y1

2F 2S 1S 1F

HEAD

CN110

6 2F 7 2S 3 1S 2 1F

∗2 WITHOUT DSC MODEL

WITH DSC MODEL

1 0 DSC

TO CAM.DSP

TO SYSCON

CN111 CN8001

DSYIO0 DSYIO7 DSCIO0 DSCIO7 DSYO0 DSYO7 DSCO0 DSCO7 CLKDSC HDDSC VDDSC FLDDSC CLK27 DSC_WKUP DSC_CS DSC_CLK DSC_DT_OUT DSC_DT_IN USBDOWN DSC_RST MXDT_OUT CAPT_REQ DSC_STS USB_DN_RX USBDOWN USB_DP_TX FLSH_RST

TO CN103-7PIN

TO CN103-6PIN

TO IC8003-12PIN

R8068 C8126 R8029 D8001 IC8004

IC8001

YIO0 YIO7 CIO0 CIO7 YIN0 YIN7 CIN0 CIN7 CLKIN1 HDIN VDIN FID MXI CLKIN2 GIO0 GIO18 SCLK1 SDI1 SDO1 GIO13 RESET GIO16 GIO7 GIO11 USB_DN USB_DP

SDI3 SCK3 SDO3 GIO20

Data2Host MMC_CLK Data2MMC SD/MMC_CS

CN8002

TO MONITOR

ARM_D15 ARM_D0 DSC R/D_DATA

ARM_A19 ARM_A0 DSC R/D_ADRESS

IC8003 (16M_FLASH RAM)

A0~A19 DQ0~DQ15 FLSH_CE FLSH_OE FLSH_WE RESET

EM_CS_O EM_OE EM_WE

FROM CN8001-55PIN

X8002 CXO 48MHz

M48XI M48XO

SDR_DQ0 SDR_DQ15 SDRAM_DATA

SDR_A0 SDR_A11 SDRAM_ADRESS

SDR_CKE SDR_CLK SDR_CS SDR_CAS SDR_DQMLH SDR_RAS SDR_WE SDR_DQMLL

IC8002 16M SDRAM

DQ0 DQ15 A0 A11 CKE CLK CS CAS LDQM RAS WE UDQM

IC1401(VTRCPU)

MONI_CHG

CAM_VD EEP_WRITE EEP_CLK EEP_READ SYS_CLK SYS_IN SYS_OUT MSELECT READY RESET

TO CAM.DSP

TO SYSCON(IC1003)

TO SYSCON

SRV_CS SRV_RDY SRV_RST

TO SYSCON (IC1007)

(IC1001)

SRV_TX IF_RX TXD RXD

TO SYSCON (IC1007) (IC1001)

SRV_JTX SRV_JRX

TO JIG CONN.

X1401 OSCO OSCI

IC1402 ∗2

DV_RST DV_WAIT ADDT00 ADDT15 DALE DRWSEL DRE DWE CLK27SEL HID HID PBH RECH HID_3 SPA FRP TSR

TO IC3001 TO IC3001 TO IC3001 TO IC3001 TO IC3501 TO IC3501 TO IC3001

TO IC3001

AIMCK AILRCK AIBCK AIDAT ADDAT

TO AUDIO

PD_L CLK_OUT DATA_OUT AUDIO_CS

TO AUDIO

S_SHUT

TO CAM.DSP

0 7 REAR

CN103 CN551

TPA+ TPA- TPB+ TPB-

DV IN/OUT

DV J551

A B C D 4-75 4-76 E F G H

4.34 REGULATOR SYSTEM SCHEMATIC DIAGRAM